



Software Manual

FOR DUET AD



Motor Power Company s.r.l.
 Via Leonardo Da Vinci, 4
 42024 Castelnovo Sotto Reggio Emilia - Italia
 Tel. +39 0522 682710 - Fax +39 0522 683552
 info@motorpowerco.it - motorpowerco.com
 Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
 Iscr.Reg.Impr. di RE n.01308390358 - N. Mec. RE 010210
 C.F. e P.IVA IT 01308390358



**MOTOR
POWER**
COMPANY

Index

Index	2
1. Introduction	4
Scope.....	4
Software organization	4
2. Communication with the Host	5
The RS-485 Protocol (Modbus - RTU)	5
Command Supported	5
MODBUS TCP/IP Protocol.....	6
Command Supported	6
3. Drive Memory Organization	7
Layout for standard address	7
Parameters	7
Inputs.....	7
Outputs	8
32 bit Parameters and Variables.....	8
4. Main Parameters Table.....	9
Generic Parameters.....	16
CanBus Parameters.....	17
Axis Parameters	25
Motor Data	25
Feedback Data.....	29
Current Gains	32
Velocity Gains	33
Position Gains	34
Other controller parameters	35
Conversion Factors	37
Analog Input Functionality	40
Brake Parameters	43
Safety Parameters.....	44
Homing Parameters	45
Profile Parameters	50
Software Position Limits	57
Position Modulo	58
Other Axis Parameters	59
Static PDO Mapping	61

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
 42024 Castelnovo Sotto Reggio Emilia - Italia
 Tel. +39 0522 682710 - Fax +39 0522 683552
 info@motorpowerco.it - motorpowerco.com
 Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
 Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
 C.F. e P.IVA IT 01308390358



Torque Limits	63
JOG Parameters.....	64
Generic Inputs	65
Axis Inputs.....	68
Targets.....	71
Generic Outputs.....	73
Can Bus Outputs.....	77
Axis Outputs	80
Current Output	83
Velocity Outputs.....	85
Position Outputs.....	87
Other Output Parameters.....	90
User Program Functionality.....	93
Ethernet Fieldbus Parameters.....	94

Notice:

- This guide is delivered subject to the following conditions and restrictions: This guide contains proprietary information belonging to Motor power Company Srl. Such information is supplied solely for the purpose of assisting users of the Motor Power Company servo drives in its installation and configuration.
- The text and graphics included in this manual are for the purpose of illustration and reference only. The specifications on which they are based are subject to change without notice.
- Motor power Company and the Motor power Company logo are trademarks of Motor power Company Srl.
- Information in this document is subject to change without notice.

Version	Date	Author	Note
1.0	19/01/2023	Michele Piacentini	Second release


Introduction

Scope

This manual describes, in detail, the software used with the Motor Power Company drive DUET AD. It is an integral part of the drives documentation set.

DUET AD is an Integrated motor drive 48V operation up to 700W nominal power.

The UI support a set of devices from Motor Power Company, for more information regarding single supported drive please visit: <http://www.motorpowergroup.com>.



Software organization

The internal software is organized into 3 different layers

- Boot loader
- Motion Control Firmware
- Application Software
- Ethernet Fieldbus Stack (if preset).

The Boot Loader is the software who is taking care of the device boot-up. If no firmware is present the bootloader will wait until a new firmware is loaded on the device. The boot loader always ensure a save restore of the device under any condition.

The Motion Control Firmware, is the software that take care of the Device communications RS-485 Modbus and CanOpen/Industrial Ethernet communication, and the implementation of the Motion control Functionality.

The Application software is an additional software that use the Communication and Motion Control functionality of the Device to solve dedicated application. Check <http://www.motorpowergroup.com> for existing advanced functionality.

Communication with the Host

The Motor Power Company drives can operate via MODBUS (RTU via RS-485 or TCP/IP) or CANopen communication or many industrial Ethernet fieldbus (EtherCAT-PROFINET-Ethernet I/P) depending on the device and part number.

This chapter discusses MODBUS communication. Refer to the specific device fieldbus Implementation manual for detailed information about operation with CANopen/Industrial Ethernet networking.

The RS-485 Protocol (Modbus - RTU)

The protocol that is actually running on the RS-485, is the Standard MODBUS RTU.



For more information on this protocol, please refer to the official website (<http://www.modbus.org/>)

The standard parameter for RS-485 configuration are

Parameter	Value
Speed (baud/s)	460800
Parity	None
Stop Bits	1
Data bits	8

The Device Explorer interface can communicate via MODBUS with many baud rates,



NOTE: Only expert operators have to change this value. Changing and saving slave ID or baud rate for ModBus RTU communication could cause device to not working properly.

The modbus slave address is 247 and actually is a fixed value.

Command Supported

Actually not all the command implemented in the modbus protocol are available. Here below you can find a list of the supported commands

Command Code	Command Description
3	<i>READ_HOLDING_REGISTERS</i>
6	<i>WRITE_SINGLE_REGISTER</i>
16	<i>WRITE_MULTIPLE_REGISTERS</i>

For more information regarding Modbus protocol, please refer to Modbus official documentation (<http://www.modbus.org/>)

Each Register is the minimum information that you can store into the drive and it's size is 16 bits (WORD)

MODBUS TCP/IP Protocol.

The protocol that is actually running on the TCP/IP connection, is the Standard MODBUS TCP/IP.



Only devices with Industrial Ethernet communication such as PROFINET, Ethernet/IP and EtherCAT (via EoE) support MODBUS TCP/IP.

The IP address of the device depends on the network configuration actually used for the device.

For more information on this protocol, please refer to the official website (<http://www.modbus.org/>)

The modbus slave address is 247 and actually is a fixed value.

Command Supported

Actually not all the command implemented in the modbus protocol are available. Here below you can find a list of the supported commands

Command Code	Command Description
3	<i>READ_HOLDING_REGISTERS</i>
6	<i>WRITE_SINGLE_REGISTER</i>
16	<i>WRITE_MULTIPLE_REGISTERS</i>

For more information regarding Modbus protocol, please refer to Modbus official documentation (<http://www.modbus.org/>)

Each Register is the minimum information that you can store into the drive and it's size is 16 bits (WORD).

Drive Memory Organization

Device Explorer UI exchange information via ModBus to drive for diagnostic/configuration or other desired operation. All the parameters necessary to run the drive are mapped into the Modbus address. The maximum number of allowable registers are 65.535, actually only a few are used and described in this manual.

Layout for standard address

The memory of any supported Motor Power Company Drive is organized into 3 different area, Parameters, Input and Outputs.

Address	Length	Memory Area	Saved to Flash	Type
0-511	512	Parameters	YES	RW
512-639	128	Inputs	NO	RW
640-767	128	Outputs	NO	RO

Parameters

The device Parameters memory values are used for general, axis1 or axis2 parametrization. All the parameters can be stored into the Serial Flash of the Drive and will be restored at next boot.

Note: not all devices support Axis2 parameters. Not all the registers per memory area are used.

Address	Length	Memory Area
0-127	128	Generic Parameters
128-319	192	Axis Parameters
320-511	192	Unusedf

Inputs

This memory area is used to send general, axis1 and axis2 commands to the Drive, like Servo On or Target Position. These values can be read and Written, but not saved on the flash.

Note: not all devices support Axis2 inputs. Not all the registers per memory area are used.

Address	Length	Memory Area
512-539	28	Generic Inputs

540-589	50	<i>Axis1 Inputs</i>
590-639	50	<i>Unused</i>

Outputs

This memory area is used to show the general, axis1 or axis2 status of the Drive. All the data present in this memory are updated real time and can be read and shown to the user. This memory is read Only and not saved on the Flash

Note: not all devices support Axis2 Outputs. Not all the registers per memory area are used.

	Address	Length	Memory Area
	640-667	28	<i>Generic Outputs</i>
	668-717	50	<i>Axis1 Outputs</i>
	668-717	50	<i>Unused</i>

32 bit Parameters and Variables

When is necessary to provide the storage to la long (32bit) variable, 2 consecutive memory area of 16bits will be used

	Space	Variable
	16bit	VARIABLE_LOW_VALUE
	16bit	VARIABLE_HIGH_VALUE

Main Parameters Table

Parameter Name	Modbus Addr	CO Addr	Modbus Type	CO Type	Access	Min	Max	Default	Change	Description	Notes
Acceleration	0x009B (154)	0x6083	U32	UINT32	r/w	0	UINT32	3000	IMM/BEG	[rpm/s] The object profile_acceleration determines the maximum acceleration used during a positioning motion	
Acceleration Factor Div	0x00F2 (242)	0x6097 0x02	U32	UINT32	r/w	1	UINT32	60	IMM		
Acceleration Factor Num	0x00F0 (240)	0x6097 0x01	U32	UINT32	r/w		UINT32	4096	IMM		
Analog Input	0x029F (671)	0x2205 0x01	S16	INT16	r	-	-	-	-	Actual value for analog input in mV	
Analog Input Offset	0x0083 (132)	-	U16	-	r/w	0	1000	0	IMM	[mV]	
Analog Input Filter	0x0084 (133)	-	U16	-	r/w	0	U16	100	IMM	[Hz]	
Analog Input Safe Zero	0x0083 (131)	-	U16	-	r/w	0	1000	0	IMM	[mV]	
Begin	0x0223 (547)	-	U16	-	w	-	-	-	IMM	Bit4 of ControlWord. On Profile Position Mode: A rising edge signals that a new position parameter set should be taken over. On Homing Mode: A rising edge starts the configured search for reference. A falling edge stops the search immediately. On Interpolated Position Mode: This bit has to be set to evaluate the interpolation data. It will be acknowledged by the bit ip_mode_active in the statusword.	
Bootloader Version	0x0295 (664)	-	U16	-	r	-	-	-	-	Bootloader FW version of the device	
Brake Turn Off Delay	0x00C7 (199)	-	U16	-	r/w	0	3000	50	IMM	[ms]	
Brake Turn On Delay	0x00C6 (198)	-	U16	-	r/w	0	3000	50	IMM	[ms]	
BUS Nominal Voltage	0x0002 (2)	0x2201	U16		r/w	12	65	48	IMM	DC BUS working voltage for the device in Volts	
Can BitRate	0x000A (10)	-	U16	-	r/w	0	3	1	BOOT	0 = 1000 kbps 1 = 500 kbps 2 = 250 kbps 3 = 125 kbps	
CO_Node_ID	0x0008 (8)	-	U16	-	r/w	1	127	1	BOOT	Can open node ID of the device	

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Control Mode	0x0080 (128)	0x6060	S16	INT8	r/w	0	-	3	BEG	1 = Profile Positioning Mode (position controller with positioning operation). 3 = Profile Velocity Mode (speed controller with setpoint ramp). 4 = Torque Profile Mode (torque controller with setpoint ramp). 6 = Homing mode (homing operation). 7 = Interpolated Position Mode. 8 = Cyclic Synchronous Position Mode	Do not is effective while the motor is enabled.
Control Mode Display	0x029E (670)	0x6061	S16	INT8	r	-	-	-	-	The current operating mode of the servo controller.	
Control Word	0x021C (540)	0x6040	U16	UINT16	r/w	-	-	-	IMM	DS-402 ControlWord	
Current Actual Value	0x02A2 (674)	0x6078	S16	INT16	r	-	-	-	-	The actual current value of the motor can be read via this object in thousandths of the nominal current (object 6075h). In A/100 with MODBUS Parameters.	In A/100 with MODBUS Parameters
Current Demand	0x02A4 (676)	0x6074	S16	INT16	r	-	-	-	-	The current demand torque can be read in thousandths of motor_rated_torque (6076h) via this object. The internal limitations of the servo controller will be considered (current limit values and lift control). In A/100 with MODBUS Parameters.	In A/100 with MODBUS Parameters
Current Ki	0x0087 (135)	0x60F6 0x02	U16	UINT16	r/w	0	65535	500	IMM	Current control loop integral gain.	
Current Kp	0x0086 (134)	0x60F6 0x01	U16	UINT16	r/w	0	65535	400	IMM	Current control loop proportional gain.	
Current Target	0x0228 (552)	0x6071	S16	INT16	r/w	-	-	-	BEG	This parameter is the input value for the torque controller in Profile Torque Mode. It is specified as thousandths of the nominal torque (object 6076h). In A/100 with MODBUS Parameters.	In A/100 with MODBUS Parameters
DC Bus Voltage	0x028D (653)	0x6079	U16	UINT16	r	24	65	48	-	DC Bus Voltage. Specified in mV.	
Deceleration	0x009D (156)	0x6084	U32	UINT32	r/w	0	65535	3000	IMM/BEG	[rpm/s] The object profile_deceleration specifies the maximum deceleration used during a positioning motion	
Drive Temperature	0x0296 (662)	0x2220	S16	INT16	r	-	-	-	-	Actual drive temperature in C°/100	
Enable	0x0222 (546)	-	U16	-	w	-	-	-	IMM	Rising edge: Put the servo in OPERATION_ENABLE Falling edge: Put the servo in SWITCH_ON_DISABLED	
Enable Analog Input	0x0081 (129)	-	U16	-	r/w	0	1	1	IMM		
Encoder Lines per Revolution	0x0094 (148)	0x605A	U32	UINT32	r/w	1024	1024	1024	IMM	Encoder Lines per revolution	
Fault Register	0x029D (669)	0x60F3	U16	UINT16	R	-	-	-	-	Bit 0 = Over Voltage	
Fault Reset	0x0224 (548)	-	U16	-	w	-	-	-	IMM		

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Firmware Version	0x0280 (640)	0x100A	U16	VS	r	-	-	-	-	FW version of the device	
Following Error TimeOut	0X00AE (174)	0x6066	U16	UINT16	-	-	-	-	IMM	[ms] When a following error occurs longer than the defined value of the time-out given in multiples of milliseconds, the corresponding bit 13 following error in the status word will be set to one. The reaction of the drive when a following error occurs, is manufacturer specific.	
Following Error Window	0x00A2(162)	0x6065	U32	UINT32	-	-	-	-	IMM	If the actual position is outside the following error window[cnt], for a longer time than following error timeout[ms], a trailing error occurs and statusword bit 13 will be set.	
Halt	0x0225 (549)	-	U16	-	w	-	-	-	IMM	Bit8 of ControlWord.	
Home Offset	0x00A7 (190)	0x607C	S32	UINT32	r/w	-	-	-	IMM	The home offset object is the difference between the zero position for the application and the machine home position (found during homing), if is measured in position units. During homing the machine home position is found and once the homing is completed the zero position is offset from the home position by adding the home offset to the home position. All subsequent absolute moves shall be taken relative to this new zero position.	
Homing Acceleration	0x00B2 (186)	0x609A	U32	UINT32	r/w	-	-	-	IMM/B EG	The homing acceleration establishes the acceleration to be used for all accelerations and decelerations with the standard homing modes and is given in acceleration units.	
Homing I²T Threshold	0x00C4 (196)	-	U16	-	r/w	0	100	100	IMM/B EG	I ² T threshold time parameters for Homing [%]	
Homing I²T Threshold Timeout	0x00C5 (197)	-	U16	-	r/w	-	-	-	IMM/ BEG	I ² T threshold time parameters [ms]	
Homing Mode	0x00A5 (179)	0x6098	S16	INT8	r/w	-	-	-	IMM/ BEG	-17 See the functional description -18 See the functional description 0 No homing operation required 1 - 35 See the functional description	
Homing Speed to switch	0x00B6 (182)	0x6099 0x01	U32	UINT32	r/w	0	3000	500	IMM/ BEG	Speed during search for switch	
Homing Speed to zero	0x00B8 (184)	0x6099 0x02	U32	UINT32	r/w	0	3000	500	IMM/ BEG	Speed during search for zero	

Homing Status	0x02BE (702)	-	U16	-	r	-	-	-	-	Status of the actual homing procedure. Read CanOpen device manual for more information.	
Homing Timeout	0x00BC (188)	-	U16	UINT16	r/w	-	-	60	IMM/BEG	Timeout for homing procedure [s].	
I2t Protection Type	0x0100 (256)	0x2F83	U16	UINT16	r/w	1	0	1	IMM	Temperature protection behaviour.	
I2t Time	0x0092 (146)	0x6410	U16	UINT16	r/w	10	3200	3000	IMM	[ms]	
Industrial Ethernet Application Firmware Version	0x1772 (6002)		U32	-	r	-	-	-	-	[a,b,c,d] Major, Minor, Revision, Build	Only with MODBUS TCP/IP
Industrial Ethernet Stack Firmware Version	0x1770 (6000)		U32	-	r	-	-	-	-	[a,b,c,d] Major, Minor, Revision, Build	Only with MODBUS TCP/IP
Input 1 Function	0x0014 (20)	-	U16	-	r/w	0	10	0	IMM	Function value code associated to this input. See Installation Manual for details.	
Input 1 Polarity	0x0022 (34)	-	U16	-	r/w	0	1	0	IMM	0 – True Logic; 1 – Inverted Logic.	
Input 2 Function	0x0015 (21)	-	U16	-	r/w	0	10	0	IMM	Function value code associated to this input. See Installation Manual for details.	
Input 2 Polarity	0x0023 (35)	-	U16	-	r/w	0	1	0	IMM	0 – True Logic; 1 – Inverted Logic.	
Input 3 Function	0x0016 (22)	-	U16	-	r/w	0	10	0	IMM	Function value code associated to this input. See Installation Manual for details.	
Input 3 Polarity	0x0024 (36)	-	U16	-	r/w	0	1	0	IMM	0 – True Logic; 1 – Inverted Logic.	
Input 4 Function	0x0017 (23)	-	U16	-	r/w	0	10	0	IMM	Function value code associated to this input. See Installation Manual for details.	
Input 4 Polarity	0x0025 (37)	-	U16	-	r/w	0	1	0	IMM	0 – True Logic; 1 – Inverted Logic.	
Inputs Status	0x02C1 (705)	0x60FD	U16	UINT32	r	-	-	-	-	Indicates the state of the digital inputs.	
Load Inertia	0x0105 (261)	-	U16	-	r/w	0	65535	0	IMM	Load inertia in (Kg/cm^2)/100	
Max Current	0x008F (143)	0x6073	U16	UINT32	r/w	-	-	-	IMM	Peak motor current A/100 if MODBUS, in mA for CanOpen	
Max Motor Velocity	0x0097 (151)	0x6080	U32	UINT32	r/w	0	6000	4500	-	-	

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
 42024 Castelnovo Sotto Reggio Emilia - Italia
 Tel. +39 0522 682710 - Fax +39 0522 683552
 info@motorpowerco.it - motorpowerco.com
 Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
 Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
 C.F. e P.IVA IT 01308390358



Negative Torque Limit	0x00FF (255)	-	U16	-	r/w	1	100	100	IMM	Torque Negative limit associate to Negative limit Input function in % of Imax.	
Output 1 Function	0x001E (30)	-	U16	-	r/w	0	6	0	IMM	Output Function code associated to relative Out number. See Installation Manul.	Brake 1 function is active and usable only on Virtual Output 4
Output 1 Polarity	0x002C (44)	-	U16	-	r/w	0	1	0	IMM	0 – True Logic; 1 – Inverted Logic.	
Output 2 Function	0x001F (31)	-	U16	-	r/w	0	6	0	IMM	Output Function code associated to relative Out number. See Installation Manul.	Brake 1 function is active and usable only on Virtual Output 4
Output 2 Polarity	0x002D (45)	-	U16	-	r/w	0	1	0	IMM	0 – True Logic; 1 – Inverted Logic.	
Output Status	0x0298 (664)	0x60FE 0x01	U16	UINT32	r	-	-	-	-	Indicates the state of the digital outputs.	
Overvelocity	0x00A8 (168)	-	U32	UINT32	r/w	0	6000	7000	IMM	Maximum allowed velocity value.	
Position Actual Value	0x02B4 (692)	0x6064	S32	INT32	r	-	-	-	-	Actual position. This value is given to the position controller by the angle encoder.	
Position Demand	0x02B8 (696)	0x6062	S32	INT32	r	-	-	-	-	This position is fed into the position controller by the trajectory generator	
Position Error	0x02B6 (694)	-	S32	-	r	-	-	-	-	Actual Error between the position target/setpoint of the controller and the actual position.	
Position Factor Div	0x00E9 (233)	0x6093 0x02	U32	UINT32	r/w	0	65535	1	IMM		
Position Factor Num	0x00E7 (231)	0x6093 0x01	U32	UINT32	r/w	0	65535	1	IMM		
Position Kp	0x008A (138)	0x60FB 0x01	U16	UINT16	r/w	0	65535	1000	IMM	Position control loop proportional gain.	
Position Radius	0x00A4 (164)	0x6067	U32	UINT32	r/w	0	-	-	IMM	[cnt]	
Position Radius Time	0x00AF (175)	0x6068	U16	UINT16	r/w	0	-	-	IMM	[ms]	
Position Target	0x022B (555)	0x607A	S32	INT32	r/w	-	-	-	BEG	The object target_position determines the destination the servo controller moves to.	
Position Tracking Error	0x02BA (698)	0x60F4	S32	INT32	r	-	-	-	-	Actual Error between the position demand of the controller and the actual speed.	
Positive Torque Limit	0x00FE (254)	-	U16	-	r/w	1	100	100	IMM	Torque Negative limit associate to Negative limit Input function in % of Imax.	

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
 42024 Castelnovo Sotto Reggio Emilia - Italia
 Tel. +39 0522 682710 - Fax +39 0522 683552
 info@motorpowerco.it - motorpowerco.com
 Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
 Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
 C.F. e P.IVA IT 01308390358



Post Homing Action	0x00BD (189)	-	S16	-	r/w	-	-	-	IMM/B EG		
Post Homing Speed	0x00C1 (193)	-	U32	UINT32	r/w	-	-	-	IMM/B EG		
Profile Velocity	0x00A1 (161)	0x6081	U32		r/w	100	6000	3000	IMM	[rpm]	
Quick Stop Option Code	0x0103 (259)	0x605A	U16	UINT16	r/w	0	-	2	IMM	[ms]	
Rated Current	0x008E (142)	0x6075	U16	UINT32	r/w	-	-	-	IMM	Rated motor current in A/100, in mA for CanOpen	
Save to EEPROM	0x0200 (512)	0x1010 0x01	U16		w	0	1	0	IMM	Save servo parameters to EEPROM.	
Serial Number	0x0288 (648)	0x1018 0x01	U32	UINT32	r	-	-	-	-	Serial Number of the device	
Set Default Parameters	0x0203 (515)		U16		w	-	-	-	IMM	Set servo parameters to default values.	
Set Immediately	0x0226 (550)	-	U16	-	w	-	-	-	IMM	Bit5 of ControlWord. Only on Profile Position Mode: If this bit is cleared a current positioning order will be processed before starting a new one. If this bit is set a current positioning order will be interrupted by the new one.	
Status Word	0x029C (668)	0x6041	U16	UINT16	r	-	-	-		DS-402 StatusWord	
Stop Deceleration	0x009E (158)	0x6085	U32	UINT32	r/w	0	65535	3000	IMM/ BEG	[rpm/s]	
Torque Filter	0x00C9 (201)	-	U16	-	r/w	0	65535	600	IMM	Torque filter cutoff freq in Hz	
Use Relative Position	0x0227 (551)	-	U16	-	w	-	-	-	IMM	Bit6 of ControlWord. Only on Profile Position Mode: If this bit is set, the target_position of the current positioning job, will be added to the position_demand_value of the position controller.	
Velocity Actual Value	0x02AA (682)	0x606C	S32	INT32	r	-	-	-	-	Actual velocity value.	
Velocity Demand	0x02AE (686)	-	S32	INT32	r	-	-	-	-	It will be influenced by the ramp generator and the trajectory generator respectively.	
Velocity Error Radius	0x00A6 (166)	0x2100	U32	UINT32	r/w	0	-	-	IMM	Velocity error threshold radius [rpm]	

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
 42024 Castelnovo Sotto Reggio Emilia - Italia
 Tel. +39 0522 682710 - Fax +39 0522 683552
 info@motorpowerco.it - motorpowerco.com
 Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
 Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
 C.F. e P.IVA IT 01308390358



Velocity Error Radius Time	0x00B1 (177)	0x2101	U16	UINT16	r/w	0	-	-	IMM	[ms]	
Velocity Factor Div	0x00EE (238)	0x6096 0x02	U32	UINT32	r/w	0	65535	60	IMM		
Velocity Factor Num	0x00EC (236)	0x6096 0x01	U32	-	r/w	0	65535	4096	IMM		
Velocity Filter	0x00C8 (200)	-	U16	-	r/w			300	IMM	Velocity feedback filter cutoff freq in Hz	
Velocity Ki	0x0089 (137)	0x60F9 0x02	U16	UINT16	r/w	0	65535	500	IMM	Velocity control loop integral gain.	
Velocity Kp	0x0088 (136)	0x60F9 0x01	U16	UINT16	r/w	0	65535	500	IMM	Velocity control loop proportional gain.	
Velocity Radius	0x00AA (170)	0x606D	U32	UINT32	r/w	0	-	-	IMM	If the difference between target and actual velocity is smaller than the velocity radius [rpm], for a longer time than velocity radius time [ms], then statusword bit 10 will be set.	
Velocity Radius Time	0x00B2 (178)	0x606E	U16	UINT16	r/w	0	-	-	IMM		
Velocity Target	0x0229 (553)	0x60FF	S32	INT32	r/w	-	-	-	IMM	The object target_velocity is the setpoint for the ramp generator.	
Velocity Threshold	0X00AC (172)	0x606F	U32	UINT32	r/w	0	-	-	IMM/BEG	As soon as the actual velocity exceeds the velocity threshold [rpm],	
Velocity Threshold Time	0X00B0 (176)	0x6070	U16	UINT16	r/w	0	-	-	IMM/BEG	longer than the velocity threshold time [ms], statusword bit 12 is cleared.	
Velocity Tracking Error	0x02B0 (688)	-	S32	-	r	-	-	-	-	Actual Error between the speed demand of the controller and the actual speed.	

Generic Parameters

In this chapter we will describe all the generic parameters and their functionality

Serial Port Baud Rate

With this parameter it will be possible to change the RS-485 port baud rate. The change will be activated at next reboot.

Parameter	Serial Port Baud Rate
Address	5
Base Address	0
Access	R/W
Default Values	2
Range	[0-3]
Activation	Reboot

PARAMETER	BAUD
VALUE	RATE
0	57600
1	115200
2	230400
3	460800
4	921600
5	1843200

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



CanBus Parameters

With the following parameters it will be possible to configure the Can Network functionality.

CO_Node_ID

Parameter	<i>CanBus Address Axis1</i>
Address	8
Base Address	0
Access	R/W
Default Values	1
Range	[1-127]
Activation	REBOOT

CAN Bit Rate

Parameter	<i>CanBus Network Speed</i>
Address	10
Base Address	0
Access	R/W
Default Values	0
Range	[0-3]
Activation	REBOOT

list of possible configuration

Bit Rate	<i>Parameter Value</i>
1MB	0
500kbps	1
250kbps	2
125kbps	3

BUS Nominal Voltage

DC Bus nominal working voltage for the device. In [V].

Parameter	<i>CanBus Network Speed</i>
Address	2
Base Address	0
Access	R/W
Default Values	48
Range	[24-65]
Activation	IMMEDIATELY
CANopen Object ID	0x2201

list of possible configuration

	Bit Rate	<i>Parameter Value</i>
1MB		0
500kbps		1
250kbps		2
125kbps		3

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



PWM Frequency

It's possible to change the PWM frequency.

Parameter	Pwm Frequency
Address	3
Base Address	0
Access	R/W
Default Value	8/16
Range	[4-16]
Activation	REBOOT



NOTE:

Only expert operators have to change this value. This value will change the heating of the system and if increased to much may damage the drive.

If this value will be changed all the gains (Current Loop, Velocity Loop, and Position Loop have to be changed) in order to prevent instability, which may damage the drive and/or the motor.

Input functionality

From parameters 20 to 23 we can find the Input functionality. The Drive have several non committed I/O that the user can program with the functionality he needs.

Parameter	<i>I[n] Input Functionality</i>
Address	<i>20+[n]</i>
Base Address	<i>0</i>
Access	<i>R/W</i>
Default Value	<i>0</i>
Range	<i>[0-100]</i>
Activation	<i>IMMEDIATE</i>

Where [n] = [0-4]

list of possible configuration

Value	<i>Input Functionality</i>
0	<i>Generic Input (No function)</i>
1	<i>Positive Limit Switch</i>
3	<i>Negative Limit Switch</i>
5	<i>Enable</i>
9	<i>Emergency Stop</i>
11	<i>Fault Reset</i>
18	<i>Home Switch</i>
20	<i>Positive JOG</i>
22	<i>Negative JOG</i>
24	<i>Positive Torque Limit</i>
26	<i>Negative Torque Limit</i>
28	<i>Torque Limit</i>
39	<i>Analog Input Polarity</i>
44	<i>Enable and Dir CW</i>
45	<i>Enable and Dir CCW</i>

Input Logic

These parameters defines the logic level of the digital inputs.

	Parameter	I[n] Input Logic
Address		$34+[n]$
Base Address		0
Access		R/W
Default Values		0
Range		[0-1]
Activation		IMMEDIATE

Where [n] = [0-4]

list of possible values

	Value	Input Functionality
0		Negative Logic
1		Positive Logic

Output Functionality

From parameters 30 to 31 we can find the Output functionality. The Drive have several non committed I/O that the user can program with the functionality he needs.

	Parameter	O[n] Output Functionality
Address		$30+[n]$
Base Address		0
Access		R/W
Default Values		0
Range		[0-100]
Activation		IMMEDIATELY

Where [n] = [0-1]

list of possible configuration

Value	<i>Output Functionality</i>
0	<i>General Purpose</i>
1	<i>Brake Axis1 (Use Virtual Output4 Only)</i>
3	<i>Drive OK</i>
5	<i>In Position</i>
7	<i>Homed</i>
9	<i>Velocity feedback</i>

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
 42024 Castelnovo Sotto Reggio Emilia - Italia
 Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
 Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
 Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
 C.F. e P.IVA IT 01308390358



Output Logic

These parameters defines the logic level of the digital inputs.

Parameter	I[n] Input Logic
Address	44+[n]
Access	R/W
Default Values	0
Range	[0-1]
Activation	IMMEDIATELY

Where [n] = [0-1]

list of possible values

Value	Output Functionality
0	<i>Negative Logic</i>
1	<i>Positive Logic</i>

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
 42024 Castelnovo Sotto Reggio Emilia - Italia
 Tel. +39 0522 682710 - Fax +39 0522 683552
 info@motorpowerco.it - motorpowerco.com
 Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
 Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
 C.F. e P.IVA IT 01308390358



Scope Variables

The internal scope configuration can be saved into the serial Flash of the drive for this reason in the Generic Parameter we can find an array of value that define the Scope variables configuration

Parameter	S[n] Scope Configuration
Address	<i>120+[n]</i>
Access	<i>R/W</i>
Default Values	<i>0</i>
Range	<i>[0-65535]</i>
Activation	<i>IMMEDIATE</i>

Where [n] = [0-7]

The scope configuration is a structure that define which Scope channel will be used and the value saved in this track.

bit	Value
[15-13]	<i>Channel</i>
[12-10]	<i>Reserved</i>
[9-0]	<i>[9-0]</i>

The list of value is available on appendix D of this manual.

Axis Parameters

In this chapter we will describe all the parameters necessary to configure the Drive and the Motor

Motor Data

Here below are listed all the necessary motor information.

Motor Poles

Parameter	Motor Poles
Address	141
Access	R/W
Default Values	8
Range	[2-100]
Activation	REBOOT

Refer to Motor Power Company Catalogues to find the Pole Pairs, to enter the right value you must use the following rule:

- Motor Poles = 2 * Motor Poles Pair



NOTE: Only expert operators have to change this value. Changing the motor poles will radically modify drive commutations and behaviour

Rated Current/Nominal current

The nominal current defines the maximum allowed continuous motor phase current, in amperes Arms. This parameter is used to protect the motor from over-current, and the load from excessive torques. The motor current (torque) command is normally limited to its peak limit, as defined by I_{max} Peak Current.

The nominal current cannot be higher than the nominal current of the Drive.

This value is expressed in Arms/100

Parameter	In Nominal Current
Address	142
Access	R/W
Default Values	1700
Range	[0 to 70000]
Activation	IMMEDIATELY
CANopen Object ID	0x6075

Max Current/I_{max} Peak Current

This parameter is used to protect the motor (or the drive) from over-current, and to protect the load from excessive torque. It's possible to use peak current for a time of I_{2T} Time, after that time we will get an Overload Error.

Parameter	In Nominal Current
Address	143
Access	R/W
Default Values	5000
Range	[1-7000]
Activation	IMMEDIATE
CANopen Object ID	0x6073

This value is internally from the drive to its maximum limits.

This value is expressed in Arms/100

I2T Time

This parameter define for how much time is possible to use the Peak current.
This value will affect the Motor Usage Output Variable.

Parameter	<i>I2T time</i>
Address	146
Access	R/W
Default Values	2500 ms
Range	[1-3500]
Activation	IMMEDIATE
CANopen Object ID	0x6410

This value is expressed in ms

I2T Protection Type

This parameter define the type of protection used for motor overload protection.

Parameter	<i>I2T time</i>
Address	256
Access	R/W
Default Values	1
Range	[0-1]
Activation	IMMEDIATE
CANopen Object ID	0x2F83

Value	<i>I2T Protection Type</i>
0	<i>Motor Rated Current Error Occurs</i>
1	<i>Current Limitation on In once I2T exceeds.</i>

Max Motor Velocity

Represent the maximum velocity of the motor represented in User Units. All the internal calculation of the drive use this value as a reference. In order to optimize your system please set this parameter close to your application requirement.

Parameter	Max Motor Velocity
Address	151 (32bit)
Access	R/W
Default Values	3000 [User Units]
Range	[0 - 4.294.967.296]
Activation	IMMEDIATE
CANopen Object ID	0x6080

Motor Kt (Torque Constant)

Torque constant of the motor used in control algorithm for feedforward.

Parameter	Kt
Address	144
Access	R/W
Default Values	100 [1/100 Nm/Arms]
Range	[0 - 65535]
Activation	IMMEDIATE

Motor Inertia

Motor inertial to be used for the control algorithm in $\frac{Kg}{cm^2}$ /100.

Parameter	Kt
Address	260
Access	R/W
Default Values	0
Range	[0 - 65535]
Activation	IMMEDIATE

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Load Inertia

Load inertial to be used for the control algorithm in $\frac{Kg}{cm^2}/100$.

Parameter	Kt
Address	261
Access	R/W
Default Values	0
Range	[0 - 65535]
Activation	IMMEDIATE

Feedback Data

Here are listed all the parameters related to the feedback used to drive the motor.

Encoder Lines Per Revolution (LPR)

This parameter represent the number of lines of the Encoder mounted on the motor, the final resolution after interpolation will be:

- Pulses per revolution = LPR * 4

Parameter	Encoder PPR
Address	149 (32bit)
Access	R/W
Default Values	1024
Range	[0 - 4.294.967.296]
Activation	REBOOT
CANopen Object ID	0x605A



When you change this parameter, it's important that you Save to Flash and Reboot the device, before running the motor.

NOTE: Only expert operators have to change this value. Changing the PPR will radically modify drive commutations and behaviour

Position Feedback Polarity

This parameter allow to switch the motor direction.

Parameter	Position Feedback Polarity
Address	230
Access	R/W
Default Values	0
Range	[0]
Activation	IMMEDIATE

Position Feedback Phase

This parameter set an offset on the commutation phase angle.

Parameter	Position Feedback Phase
Address	229
Access	R/W
Default Values	90
Range	[0-359]
Activation	IMMEDIATE



NOTE: Only expert operators have to change this value.

If this parameter is not set correctly may damage the motor.

Control Mode/ Modes of operation

The drive can operate in different mode. Its configuration is a parameter because we need that the servo will start in the preferred mode at next boot up.

Parameter	Mode of Operation
Address	128
Access	R/W
Default Values	3
Range	[-5 8]
Activation	IMMEDIATE
CANopen Object ID	0x6060

Actually the following modes of operation are supported:

Value	Mode of operation
-5	<i>Stepper Mode</i>
-4	<i>Current Tuning Mode</i>
-3	<i>Velocity Tuning Mode</i>
-1	<i>Position Tuning Mode</i>
1	<i>Profile Position Mode</i>
3	<i>Profile Velocity Mode</i>
4	<i>Current Mode</i>
6	<i>Homing Mode</i>
7	<i>Interpolated Position Mode (Only DUET AD CO)</i>
8	<i>Cyclic Sync Position Mode (Only DUET AD EtherCAT)</i>

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Current Gains

Current Kp

Proportional Gain of current Loop

Parameter	KP Current
Address	134
Access	R/W
Default Values	30
Range	[0-65535]
Activation	IMMEDIATE
CANopen Object ID	0x60F6 0x01

Current Ki

Integral Gain for current loop

Parameter	KI Current
Address	135
Access	R/W
Default Values	10
Range	[0-65535]
Activation	IMMEDIATE
CANopen Object ID	0x60F6 0x02

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Velocity Gains

Velocity Kp

Proportional Gain of velocity Loop

Parameter	KP velocity
Address	136
Access	R/W
Default Values	70
Range	[0-65535]
Activation	IMMEDIATE
CANopen Object ID	0x60F9 0x01

Velocity Ki

Integral Gain for velocity loop

Parameter	KI velocity
Address	137
Access	R/W
Default Values	1
Range	[0-65535]
Activation	IMMEDIATE
CANopen Object ID	0x60F9 0x02

Position Gains

Position Kp

Proportional Gain of position Loop

Parameter	KP Position
Address	138
Access	R/W
Default Values	100
Range	[0-65535]
Activation	IMMEDIATE
CANopen Object ID	0x60FB 0x01

Other controller parameters

Current Filter

This parameter allow to introduce a low pass filter in the current feedback. The parameter specify the cut-off frequency. If the parameter in 0 the filter is disabled.

Parameter	Torque filter
Address	210
Access	R/W
Default Values	700 [Hz]
Range	[0-10.000]
Activation	IMMEDIATE

Torque Filter

This parameter allow to introduce a low pass filter in the current control loop. The parameter specify the cut-off frequency. If the parameter in 0 the filter is disabled.

Parameter	Torque filter
Address	201
Access	R/W
Default Values	700 [Hz]
Range	[0-10.000]
Activation	IMMEDIATE

Velocity Filter

This parameter allow to introduce a low pass filter in the velocity control loop. The parameter specify the cut-off frequency. If the parameter in 0 the filter is disabled.

Parameter	Velocity filter
Address	200
Access	R/W
Default Values	0 [Hz]

Range	[0-10.000]
Activation	IMMEDIATE

Velocity Feed Forward

This parameter defines how much of the position reference derivative is fed as a reference to the speed controller.

Parameter	Velocity feed forward
Address	139
Access	R/W
Default Values	1000
Range	[0 1000]
Activation	IMMEDIATE

Acceleration Feed Forward

This parameter defines how much of the velocity reference derivative is fed as a reference to the current controller.

Parameter	Acceleration feed forward
Address	140
Access	R/W
Default Values	1000
Range	[0 1000]
Activation	IMMEDIATE

Conversion Factors

Acceleration factor num

The factor n is calculated from the factor for numerator divided by the factor for denominator
 This factor converts acceleration in internal drive units (increments/seconds²)

$$\text{Acceleratuin Units} = \frac{\text{Encoder Increment}}{\text{s}^2} * \frac{\text{Acceleratio Factor Num}}{\text{Acceleratio Factor Div}}$$

Parameter	Acceleration factor Num
Address	240-241
Access	R/W
Default Values	4096
Range	U32
Activation	IMMEDIATE
CANopen Object ID	0x6097 0x01

Acceleration factor Div

The factor n is calculated from the factor for numerator divided by the factor for denominator
 This factor converts acceleration in internal drive units (increments/seconds²)

$$\text{Acceleratuin Units} = \frac{\text{Encoder Increment}}{\text{s}^2} * \frac{\text{Acceleratio Factor Num}}{\text{Acceleratio Factor Div}}$$

Parameter	Acceleration factor Div
Address	242-243
Access	R/W
Default Values	60
Range	U32
Activation	IMMEDIATE
CANopen Object ID	0x6097 0x02

Velocity factor Num

The factor n is calculated from the factor for numerator divided by the factor for denominator
 This factor converts velocity in internal drive units (increments/seconds)

$$\text{Vel Units} = \frac{\text{Encoder Increment}}{s} * \frac{\text{Vel Factor Num}}{\text{Vel Factor Div}}$$

Parameter	Vel factor Num
Address	236-237
Access	R/W
Default Values	4096
Range	U32
Activation	IMMEDIATE
CANopen Object ID	0x6096 0x01

Velocity factor Div

The factor n is calculated from the factor for numerator divided by the factor for denominator
 This factor converts velocity in internal drive units (increments/seconds)

$$\text{Vel Units} = \frac{\text{Encoder Increment}}{s} * \frac{\text{Vel Factor Num}}{\text{Vel Factor Div}}$$

Parameter	Vel factor Div
Address	238-239
Access	R/W
Default Values	60
Range	U32
Activation	IMMEDIATE
CANopen Object ID	0x6096 0x02

Position factor Num,

The factor n is calculated from the factor for numerator divided by the factor for denominator
 This factor converts Position in internal drive units.

$$\text{Pos Units} = \text{Enc Increments} * \frac{\text{Pos Factor Num}}{\text{Pos Factor Div}}$$

Parameter	Pos factor Div
Address	231-232
Access	R/W
Default Values	1
Range	U32
Activation	IMMEDIATE
CANopen Object ID	0x6093 0x01

Position factor Div,

The factor n is calculated from the factor for numerator divided by the factor for denominator
 This factor converts Position in internal drive units.

$$\text{Pos Units} = \text{Enc Increments} * \frac{\text{Pos Factor Num}}{\text{Pos Factor Div}}$$

Parameter	Pos factor Div
Address	233-234
Access	R/W
Default Values	1
Range	U32
Activation	IMMEDIATE
CANopen Object ID	0x6093 0x02

Analog Input Functionality

It's possible to use the Analog Input as automatic command generator in Current mode and in Velocity Mode.

Enable Analog Input

Parameter	<i>Enable Analog Input</i>
Address	129
Access	R/W
Default Values	0
Range	[0-1]
Activation	<i>IMMEDIATE</i>

Attention!!!! the activation is immediate and if the Servo is on and the Analog input different then zero, the motor will move.

The Gains of the analog input command are calculated as following in the 2 different configuration modes:

Current mode:

$$1V = \frac{I_{max} * 1000}{10} [A]$$

Where I_{max} is the Parameter that define the Peak current of the motor.

Velocity Mode

$$1V = \frac{\text{Max MotorVelocity} * 1000}{10} [\text{User Units}]$$

Where Max Motor Velocity is the parameter that define the Maximum mechanical velocity of the motor.

Analog Safe Zero

It's possible to define a dead-band window for the analog input, in order to allow steady condition when the command is next to 0.

Parameter	Analog Safe Zero
Address	131
Access	R/W
Default Values	0 [mV]

Range	[0-10000]
Activation	IMMEDIATE

Analog Offset

If the analog command is not well balanced is possible to define an offset to set the zero value in the correct position.

Parameter	Analog Offset
Address	132
Access	R/W
Default Values	0 [mV]
Range	[-10000 10000]
Activation	IMMEDIATE

It's possible to use the Utility present in the Motor Power Company Drive User Interface to easily calculate the analog offset coming from the controller.

Analog Filter

If the analog command source is not stable or noisy, it's possible to use this parameter to apply a Low Pass filter on the Analog Command Value.

A value of 0 means that the filter is disabled.

Parameter	Analog Filter
Address	133
Access	R/W
Default Values	0 [Hz]
Range	[0 10.000]
Activation	IMMEDIATE

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Analog Input Polarity

This parameter allows to reverse the sign of the analog input value (Ex. Change the speed direction). If this parameter is 1 the sign of the analog value will be changed.

Parameter	<i>Analog Input Polarity</i>
Address	130
Access	R/W
Default Values	0
Range	[0 1]
Activation	IMMEDIATE

Brake Parameters

These parameters defines the timing of the brake system in the motor when at least one of the digital outputs has been configured with the Brake Functionality.

For safety reasons, a brake-active output releases the brake so that the brake is activated when the drive is not powered on.

For this reason the brake output should always defined as active low.

When the brake is released at motor start, the drive allows the brake time to disengage before motion begins. During this time, the drive keeps the motor in its starting position. When the motor is turned off, the drive first commands the brake to engage. Then, for a time, it keeps the motor in place while the brake actually engages.

DUET AD supports brake resistor.

Brake TurnOn Delay

It is the time in ms for Brake disengaging, before starting any movement.

Parameter	<i>Brake TurnOn Delay</i>
Address	198
Access	R/W
Default Values	50 [ms]
Range	[0 5000]
Activation	IMMEDIATE

Brake TurnOff Delay

It is the time in ms for the Brake to be engaged before the motor shut down.

Parameter	<i>Brake TurnOff Delay</i>
Address	199
Base Address	Axis1=128 , Axis2=320
Access	R/W
Default Values	50
Range	[0 5000]
Activation	IMMEDIATE

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000.00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Safety Parameters

Over Velocity

To avoid not proper operation it's possible to define a safe speed range. The Over Speed parameter define this window.

Parameter	<i>Over velocity</i>
Address	168-169
Access	R/W
Default Values	7000
Range	[0 10000]
Activation	IMMEDIATE

Homing Parameters

In this chapter are described all the parameters related with the homing functionality embedded into the drives.

Homing Method

This parameter describe set the type of homing function will be used in the next execution.

For a complete description of homing functionality refer to the drive CANOpen/EtherCAT Manuals.

Parameter	<i>Homing method</i>
Address	179
Access	R/W
Default Values	0
Range	[-128 128]
Activation	IMMEDIATE
CANopen Object ID	0x6098

List of allowed values

With Index	Without Index	Homing Method Description
-2	-18	<i>Positive Hard Homing</i>
-1	-17	<i>Negative Hard Homing</i>
1	17	<i>Negative Limit Switch</i>
2	18	<i>Positive Limit Switch</i>
3	19	<i>Positive Home Switch (Low)</i>
6	22	<i>Positive Home Switch (High)</i>
7	23	<i>Positive Home Switch (Low) + PLS</i>
8	24	<i>Positive Home Switch (High) + PLS</i>
9	25	<i>Home Switch (Low) + Positive Initial Move</i>
10	26	<i>Home Switch (High) + Positive Initial Move</i>
11	27	<i>Negative Home Switch (Low) + NLS</i>

12	28	<i>Negative Home Switch (High) + NLS</i>
13	29	<i>Home Switch (Low) + Negative Initial Move</i>
14	30	<i>Home Switch (High) + Negative Initial Move</i>
33		<i>Homing to Index + Negative Move</i>
34		<i>Homing to Index + Positive Move</i>
	35	<i>Homing on current position</i>

Home Offset

This parameter define the value that will be stored in the position counter when the homing condition is reached.

Parameter	<i>Home Offset</i>
Address	190
Access	R/W
Default Values	0
Range	[-2147483647 2147483648]
Activation	IMMEDIATE
CANopen Object ID	0x607C

Homing Speed to Switch

This parameter set the speed that the homing function use to reach the Home switch in rpm.

Parameter	<i>Homing Speed to Switch</i>
Address	182-183
Access	R/W
Default Values	500 [rpm]
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x6099 0x01

Homing speed to zero

This parameter set the speed that the homing function use to reach the Index in rpm.

Parameter	<i>Homing Speed to Index</i>
Address	184-185
Access	R/W
Default Values	500 [rpm]
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x6099 0x02

Homing Acceleration

This parameter define the homing acceleration and deceleration value in rpm/s.

Parameter	<i>Homing Acceleration</i>
Address	186-187
Access	R/W
Default Values	0 [rpm/s]
Range	[0 2147483648]
Activation	IMMEDIATE
CANopen Object ID	0x609A

Post homing action

This parameter define what happen after the homing condition is reached.

Parameter	<i>Post homing action</i>
Address	189
Access	R/W
Default Values	0
Range	[0 10]

Activation

IMMEDIATE

List of allowed values

Value	Description
0	<i>Do Nothing</i>
1	<i>Move to Post Homing Offset</i>

Post homing Offset

This parameter define the position where move the motor if the Post homing action "Move to Post Homing Offset" is activated.

Parameter	Home Offset
Address	190-191
Access	R/W
Default Values	0
Range	[-2147483647 2147483648]
Activation	IMMEDIATE

Post homing speed

This parameter define the speed in rpm of the post homing action .

Parameter	Post homing Speed
Address	192-193
Access	R/W
Default Values	0 [rpm]
Range	[0 10000]
Activation	IMMEDIATE

For Acceleration ad Deceleration of the port homing action is used the Homing Acceleration value.

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Homing Timeout

This parameter define the homing timeout in [s]. If the homing function will not be reached during this time an error will rise.

Parameter	<i>Homing timeout</i>
Address	188
Access	R/W
Default Values	0 [s]
Range	[0 65535]
Activation	IMMEDIATE

Homing I2t Threshold Value

This parameter define the % of I2t value that rise and homing reached action

Parameter	<i>Homing I2t Threshold Value</i>
Address	196
Access	R/W
Default Values	0 [%]
Range	[1 100]
Activation	IMMEDIATE

Homing Current Threshold Timeout

This parameter define the time [ms] where the Homing current threshold value condition have to be active before rising a homing reached action.

Parameter	<i>Homing Current Threshold Timeout</i>
Address	197
Access	R/W
Default Values	0 [ms]
Range	[0 65535]
Activation	IMMEDIATE

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Profile Parameters

In this paragraph describe all the parameters useful for configuring the internal speed and position Interpolator.

Profile Mode

This parameter is used in Velocity mode. If the value is 1 it enable the speed profiler to use acceleration, deceleration and smoothing limits.

Parameter	<i>Profile Mode</i>
Address	153
Access	R/W
Default Values	1
Range	[0 1]
Activation	<i>IMMEDIATE</i>

Interp Max Vel-Profile Max Velocity

This parameter set the maximum velocity [rpm] of the position profile generator.

Parameter	<i>Interp Max Vel</i>
Address	161-162
Access	R/W
Default Values	3000
Range	[0 4294967295]
Activation	<i>IMMEDIATE</i>
CANopen Object ID	0x6081

Acceleration

This parameter set the maximum acceleration [User Units] used by velocity and position profiler.

Parameter	<i>Acceleration</i>
Address	154-155
Access	R/W
Default Values	1000

Range	[0 4294967295]
Activation	IMMEDIATE
CANopen Object ID	0x6083

Deceleration

This parameter set the maximum deceleration [User Units] used by velocity and position profiler.

Parameter	Deceleration
Address	156-157
Access	R/W
Default Values	1000
Range	[0 4294967295]
Activation	IMMEDIATE
CANopen Object ID	0x6084

Stop Deceleration

This parameter set the deceleration [User Units] used by velocity and position profiler under special conditions.

Parameter	Deceleration
Address	158-159
Access	R/W
Default Values	1000
Range	[0 4294967295]
Activation	IMMEDIATE
CANopen Object ID	0x6085

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Velocity Radius

This parameter configures the target velocity window. If the velocity is between this window the status word bit will reflect this situation.

Parameter	<i>Velocity radius</i>
Address	170-171
Access	R/W
Default Values	100 [rpm]
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x606D

Velocity Radius Time

This parameter configures the time [ms] after that the velocity radius will activate the status word bit.

Parameter	<i>Velocity radius time</i>
Address	178
Access	R/W
Default Values	50 [ms]
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x606D

Velocity Threshold

This parameter sets the minimum velocity [User Units] value after that the status word will report that the axis is moving.

Parameter	<i>Velocity threshold</i>
Address	172-173
Access	R/W
Default Values	10 [rpm]
Range	[0 10000]
Activation	IMMEDIATE

Velocity Threshold Time

This parameter set the time [ms] value after that the status word will report that the axis is moving.

Parameter	<i>Velocity threshold time</i>
Address	176
Access	R/W
Default Values	50
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x6070

Velocity Error Radius

This parameter set the velocity error window. If the velocity will leave the window a warning bit will be set in the status word.

Parameter	<i>Velocity error radius</i>
Address	166-167
Access	R/W
Default Values	100 [rpm]
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x2100

Velocity Error Radius Time

This parameter set the time in [ms] after that the velocity radius error will occur

Parameter	<i>Velocity error radius Time</i>
Address	177
Access	R/W
Default Values	100 [rpm]
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x2101

Position Radius

This parameter define the Target Reached window defined in counts.

Parameter	<i>Position radius</i>
Address	164-165
Access	R/W
Default Values	100 [counts]
Range	[]
Activation	IMMEDIATE
CANopen Object ID	0x6067

Position Radius Time

This parameter define the time [ms] after that the position reached flag will be set in the status word.

Parameter	<i>Position radius time</i>
Address	175
Access	R/W
Default Values	10 [ms]
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x6068

Following Error Window

This parameter define a range of tolerated position values symmetrical to the Position Demand Value. If the Position Actual Value is out of the Following error window for Following Error timeout.

Parameter	<i>Following Error Window</i>
Address	162-163
Access	R/W
Default Values	500 [Counts]
Range	[0 2 ³¹]
Activation	IMMEDIATE
CANopen Object ID	0x6065

Following Error Timeout

This parameter set the timeout in [ms] for the Following Error Window

Parameter	<i>Following Error Timeout</i>
Address	174
Access	R/W
Default Values	0 [ms]
Range	[0 10000]
Activation	IMMEDIATE
CANopen Object ID	0x6066

Polarity

This parameter allow to change the polarity of position and speed.

Parameter	<i>Polarity</i>
Address	231
Access	R/W
Default Values	0
Range	[0 255]
Activation	IMMEDIATE

The following table show the list of possible values:

Bit	<i>Description</i>
0	<i>reserved</i>
1	<i>reserved</i>
2	<i>reserved</i>
3	<i>reserved</i>
4	<i>reserved</i>
5	<i>reserved</i>
6	<i>Velocity Polarity</i>

Software Position Limits

Positive Software Limit High

Parameter	<i>Positive software Limit High</i>
Address	208-209
Access	R/W
Default Values	2147483647
Range	[-2147483648;2147483647]
Activation	Immediate

Positive Software Limit Low

Parameter	<i>Positive software Limit High</i>
Address	206-207
Access	R/W
Default Values	-2147483648
Range	[-2147483648;2147483647]
Activation	Immediate

Position Modulo

Position Modulo High Value

Parameter	<i>Position Modulo High Value</i>
Address	204-205
Access	R/W
Default Values	2147483648
Range	[-2147483648;2147483647]
Activation	<i>IMMEDIATE</i>

Position Modulo Low Value

Parameter	<i>Position Modulo Low Value</i>
Address	202-203
Access	R/W
Default Values	-2147483648
Range	[-2147483648;2147483647]
Activation	<i>IMMEDIATE</i>

Other Axis Parameters

Status Word Masking

For compatibility reasons it's possible to use this mask to hide the Manufacturer specific bit of the Status word. The mask affect all status word, please change only the 2 most significative bits if needed.

Parameter	<i>Status Word Masking</i>
Address	255
Access	R/W
Default Values	65535
Range	[0, 65535]
Activation	REBOOT

Boot NMT Status

With this parameter is possible to select the Boot NMT status.

Parameter	<i>Boot NMT Status</i>
Address	252
Access	R/W
Default Values	0
Range	[0, 0x04]
Activation	REBOOT

List of possible values:

Value	<i>Description</i>
0x00	<i>Pre-Operational</i>
0x04	<i>Operational</i>

Quick Stop Option Code

This parameter establishes the axis behaviour during halt/quickstop operation on controlword.

Parameter	<i>Quick Stop Option Code</i>
Address	259
Access	R/W
Default Values	2
Range	[0, 2, 6]
Activation	Immediate
CANopen Object ID	0x605A

	Value	Description
0		<i>Disable drive</i>
2		<i>Slow down on quick stop ramp and transit into Switch On Disabled</i>
6		<i>Slow down on quick stop ramp and stay in Quick Stop Active</i>

Static PDO Mapping

The following parameters allow the user to define a static PDO mapping for RPDO and TPDO 1,2. For a detailed description of these parameter refer to specific device CANOpen/EtherCAT Manual.

Parameter	<i>Static PDO Mapping</i>
Address	264-315
Base Address	Axis1=128 , Axis2=320
Access	R/W
Default Values	-
Range	[0x0, 0xFFFFFFFF]
Activation	REBOOT

Address	<i>Description</i>
264-265	<i>CanOpen @ 1400,01</i> COB ID RPDO1
268	<i>CanOpen @ 1400,02</i> Transmission Type
270	<i>CanOpen @ 1600,00</i> Number Of Entries
272-273	<i>CanOpen @ 1600,01</i> RPDO1 Mapping 0
274-275	<i>CanOpen @ 1600,02</i> RPDO1 Mapping 1
276-277	<i>CanOpen @ 1600,03</i> RPDO1 Mapping 2
278-279	<i>CanOpen @ 1600,04</i> RPDO1 Mapping 3
288-289	<i>CanOpen @ 1800,01</i> COB ID TPDO1
292	<i>CanOpen @ 1800,02</i> Transmission Type
294	<i>CanOpen @ 1800,03</i> Inhibit Time
295	<i>CanOpen @ 1800,05</i> Event Timer
298	<i>CanOpen @ 1A00,0</i> Number Of Entries
300-301	<i>CanOpen @ 1A00,01</i> TPDO1 Mapping 0
302-303	<i>CanOpen @ 1A00,02</i> TPDO1 Mapping 1
304-305	<i>CanOpen @ 1A00,03</i> TPDO1 Mapping 2
306-307	<i>CanOpen @ 1A00,04</i> TPDO1 Mapping 3

266-267	<i>CanOpen @ 1401,01</i>	<i>COB ID RPDO2</i>
269	<i>CanOpen @ 1401,02</i>	<i>Transmission Type</i>
271	<i>CanOpen @ 1601,00</i>	<i>Number Of Entries</i>
280-281	<i>CanOpen @ 1601,01</i>	<i>RPDO2 Mapping 0</i>
282-283	<i>CanOpen @ 1601,02</i>	<i>RPDO2 Mapping 1</i>
284-285	<i>CanOpen @ 1601,03</i>	<i>RPDO2 Mapping 2</i>
286-287	<i>CanOpen @ 1601,04</i>	<i>RPDO2 Mapping 3</i>
290-291	<i>CanOpen @ 1801,01</i>	<i>COB ID TPDO2</i>
293	<i>CanOpen @ 1801,02</i>	<i>Transmission Type</i>
296	<i>CanOpen @ 1801,03</i>	<i>Inhibit Time</i>
297	<i>CanOpen @ 1801,05</i>	<i>Event Timer</i>
299	<i>CanOpen @ 1A01,0</i>	<i>Number Of Entries</i>
308-309	<i>CanOpen @ 1A01,01</i>	<i>TPDO2 Mapping 0</i>
310-311	<i>CanOpen @ 1A01,02</i>	<i>TPDO2 Mapping 1</i>
312-313	<i>CanOpen @ 1A01,03</i>	<i>TPDO2 Mapping 2</i>
314-315	<i>CanOpen @ 1A01,04</i>	<i>TPDO2 Mapping 3</i>

Note: To disable a Static PDO mapping the Msb (Most significant bit) must be set.

Example:

Parameter 136:

0x80000181	PDO DISABLED
0x00000181	PDO ENABLED

Torque Limits

Positive Torque Limit

Parameter	<i>Positive Torque Limit</i>
Address	254
Access	R/W
Default Values	100
Range	[0 100]%
Activation	Immediate

Negative Torque Limit

Parameter	<i>Negative Torque Limit</i>
Address	255
Access	R/W
Default Values	100
Range	[0 100]%
Activation	Immediate

JOG Parameters

JOG Positive

This is the speed of positive JOG in user units

Parameter	<i>JOG Positive Axis</i>
Address	244-245
Access	R/W
Default Values	0
Range	[-2147483648;2147483647]
Activation	Immediate

JOG Negative Axis

This is the speed of negative JOG in user units

Parameter	<i>JOG Negative</i>
Address	246-247
Access	R/W
Default Values	0
Range	[-2147483648;2147483647]
Activation	Immediate

Generic Inputs

With the generic inputs is possible to send general command useful for the drive. All the commands will be activated only on the rising edge transition.




FIGURE 1

Save To Flash

With this command is possible to save the actual configuration present in the RAM into the E2PROM (non volatile memory) so it will be available at next boot.

This command will save all the Parameters (Generic, Axis1 and Axis2)



The communication with the drive will be lost for some second when this command is executed.
During the execution of this command both the servo must be switched off.

<i>Parameter</i>	<i>Save to flash</i>
Address	512
Access	R/W
Default Values	0
Range	[0,1]
Activation	Immediate
CANopen Object ID	0x1010 0x01

Set Default Parameters

This command will copy the default parameter configuration into the RAM. A save to Flash have to be done after this operation.

Input	<i>Set default parameters</i>
Address	515
Access	R/W
Default Values	0
Range	[0,1]
Activation	IMMEDIATE



It is important to reboot the device after this operation.

Reset Drive

This command will perform a software Reset of the Drive. If an upper board is present please always remove the 24 V Backup Voltage to perform a safe Drive Reset.

Input	<i>Reset Drive</i>
Address	516
Access	R/W
Default Values	0
Range	[0,1]
Activation	IMMEDIATE



It is important to Reset the Drive only if the Servo are disabled.

Start Bootloader

This parameter will force the drive to switch to Bootloader mode, and allow a new firmware to be loaded on the device.

<i>Input Start Bootloader</i>	
<i>Address</i>	517
<i>Access</i>	R/W
<i>Default Values</i>	0
<i>Range</i>	[0,1]

Axis Inputs

With Axis input is possible to send command to each axis of the device and set the set point for all the mode of operation.

Control Word

The internal state machine of each single axis is commanded from one single command that is the Control Word. The control word act as a CANOpen/EtherCAT Control Word, for more information on it's bits please refer to the device CANOpen/EtherCAT Manual.

	<i>Input</i>	<i>Control Word</i>
Address	540	
Access	R/W	
Default Values	0	
Range	[0,65535]	
Activation	IMMEDIATE	
CANopen Object ID	0x6040	

For faster and easier use of the system, we took some important bit of the control word and we put into different inputs. Changing these inputs will immediately change the status of the Control Word.

Enable

This input allow the user to turn of the servo.

	<i>Input</i>	<i>Enable</i>
Address	546	
Access	R/W	
Default Values	0	
Range	[0,1]	
Activation	RISING-EDGE	

Note: All the parameter and the Control Filter must be correctly set before the motor can move correctly.

Begin

This input allow the user to commit one set point depending on the actual mode of operation.

	<i>Input</i>	<i>Begin</i>
Address	547	
Access	R/W	
Default Values	0	
Range	[0,1]	
Activation		<i>RISING-EDGE</i>

Fault Reset

This input allow to reset all the fault present on the system. If all the error are reset the changes will be visible both on the error register and the Status Word.

	<i>Input</i>	<i>Fault Reset</i>
Address	548	
Access	R/W	
Default Values	0	
Range	[0,1]	
Activation		<i>RISING-EDGE</i>

Halt

This input allow the user to stop the actual movement both in Position and Velocity mode. The axis will be stopped (0 Velocity) with the Stop Deceleration.

	<i>Input</i>	<i>Halt</i>
Address	549	
Access	R/W	
Default Values	0	
Range	[0,1]	
Activation		<i>RISING-EDGE</i>

Set immediately

This input reflect exactly the Control Word bit and allow the user to define if the following command activated with the Begin bit will be executed immediately or it will wait the execution of a previous command.

If this bit is set to 1 all the commands will be executed immediately.

	<i>Input</i>	<i>Set immediately</i>
Address	550	
Access	R/W	
Default Values	0	
Range	[0,1]	
Activation		IMMEDIATE

Use Relative Position

This input is necessary to define if the Position set point of the next position command is absolute or relative.

If this bit is set to 1 the next position command will be relative.

	<i>Input</i>	<i>Set immediately</i>
Address	551	
Access	R/W	
Default Values	0	
Range	[0,1]	
Activation		IMMEDIATE

Targets

Current Target

This input define the Current Target in [mA] of the Current Loop. The new set point will be activated with the Begin command.

	<i>Input</i>	<i>Current target</i>
Address		552
Access		R/W
Default Values		0
Range		[0 - 15000]
Activation		IMMEDIATE
CANopen Object ID		0x6071

If the operation mode is Stepper Mode (-5) this will be the mandatory current command.

Speed Target

This input define the speed target in [rpm]. The new set point will be activated with the Begin command. The speed target will be affected by Profile mode parameter.

	<i>Input</i>	<i>Speed Target</i>
Address		553-554
Access		R/W
Default Values		0 [rpm]
Range		INT32
Activation		IMMEDIATE
CANopen Object ID		0x60FF

If the operation mode is Stepper Mode (-5) this will be the speed command . Please take care that all the calculation are done with the motor PPR and the conversion factor even if no feedback is connected.

Position Target

This input define the position target in [counts]. The new set point will be activated with the Begin command. The speed target will be affected by “[Use relative position](#)” bit of the Control Word.

<i>Input</i>	<i>Position target</i>
<i>Address</i>	554-555
<i>Access</i>	R/W
<i>Default Values</i>	0 [count]
<i>Range</i>	INT32
<i>Activation</i>	IMMEDIATE
<i>CANopen Object ID</i>	0x607A

If the operation mode is Stepper Mode (-5) this will electrical angle where the motor has to move, and the range is between 0 and 36000.

Generic Outputs

These variable show the status of the servo drive, and the most important variables. These values are read only and are updated real time by the drive.

Firmware Version

This output value contain the firmware version of the device.

	Output	<i>Firmware version</i>
Address		640
Access		R
Unit		[-]
Range		[0 - 65535]
Type		U16
CANopen Object ID		0x100A

How to read Firmware Version: Take the 5 digit number of this Ouput and split as follows:

aa.bb.c

	Value	Description
aa		Version
bb		Revision
c		Minor

Bootloader Firmware Version

This output value contain the bootloader firmware version of the device.

	Output	<i>Firmware version</i>
Address		664
Access		R
Unit		[-]
Range		[0 - 65535]
Type		U16

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



How to read Bootloader Firmware Version: Take the 5 digit number of this Ouput and split as follows:

aa.bb.c

	Value	Description
<i>aa</i>		<i>Version</i>
<i>bb</i>		<i>Revision</i>
<i>c</i>		<i>Minor</i>

Flash Status

This output show if the status bits of the internal flash.

	Output	Flash Status
Address		667
Access		R
Unit		[-]
Range		[0 65535]
Type		UNSIGNED

List of possible Values:

	Bit	Description
0-10		<i>Current parameter being saved</i>
11		<i>Reserved</i>
12		<i>Reserved</i>
13		<i>Default parameters Loaded</i>
14		<i>Parameters Stored Correctly</i>
15		<i>Parameters Loaded Correctly</i>

DC Bus Voltage

This Value show the DC Bus Voltage expressed in [V].

	Output	DC Bus
Address	653	
Access	R	
Unit	[V]	
Range	[0 120]	
Type	Int	
CANopen Object ID	0x6079	

Drive Temperature

This Value show the drive board temperature in [C°/100].

	Output	DC Bus
Address	653	
Access	R	
Unit	[C°/100]	
Range	[0 120]	
Type	Int	
CANopen Object ID	0x2220	

Input bits

This output show the status of the real input bit. Each bit of this word represent the status of each input pin.

	<i>Output</i>	<i>Input bits</i>
Address	663	
Access	R	
Unit		
Range	[0 - 65535]	
Type	bit	
CANopen Object ID	0x60FD	

Output status

This value show the status of the Digital Outputs.

Each bit corresponds to an output.

	<i>Output</i>	<i>Digital Input</i>
Address	664	
Access	R	
Unit		
Range	[0 - 65535]	
Type	bit	
CANopen Object ID	0x60FE 0x01	

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Can Bus Outputs

The following output values show the status of the Can Variables and the Can Register of the DSP.

Vendor ID

The vendor ID is a specific code given by Cia (Can in Automation <http://www.cancia.org/>).

This value is provided for CANOpen compatibility reasons.

	<i>Output</i>	<i>Vendor ID</i>
Address		641-642
Access		R
Unit		-
Range		[0 - 2 ³²]
Type		Long (32 bit)
CANopen Object ID		0x1018 0x01

Product Code

The Product Code is a specific identification given by Motor Power Company for this Device. This value is provided for CANOpen/EtherCAT compatibility reasons.

	<i>Output</i>	<i>Product Code</i>
Address		643-644
Access		R
Unit		-
Range		[0 - 2 ³²]
Type		Long (32 bit)
CANopen Object ID		0x1018 0x02

Revision Number

The Revision Number is a specific code given by Motor Power Company for this Device. This value is provided for CANOpen/EtherCAT compatibility reasons.

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000.000€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



	Output	Revision Number
Address	645-646	
Access	R	
Unit	-	
Range	[0 - 2 ³²]	
Type	Long (32 bit)	
CANopen Object ID	0x1018 0x03	

Serial Number

The Serial Number is a unique code given by Motor Power Company for this Device. This value is provided for CANOpen/EtherCAT compatibility reasons.

	Output	Serial Number
Address	648-649	
Access	R	
Unit	-	
Range	[0 - 2 ³²]	
Type	Long (32 bit)	
CANopen Object ID	0x1018 0x04	

CAN Status Register

Specific CAN Status register.

	Output	Can Status Register
Address	658	
Base Address	640	
Access	R	
Unit	-	
Range	[0 - 65536]	
Type	Int (16 bit)	

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



CAN Error Register

Specific CAN Status register.

	Output	<i>Can Status Register</i>
Address	659	
Access	R	
Unit	-	
Range	[0 - 2 ³²]	
Type	<i>uint (16 bit)</i>	

Axis Outputs

Status Word

This output report the status of the internal state machine of drive. Refer to CANOpen/EtherCAT Manual for more information.

	Output	Status word
Address	668	
Access	R	
Unit	-	
Range	[0 - 65535]	
Type	uint (16 bit)	
CANopen Object ID	0x6041	

Fault Register

This output report if the Axis has one fault or is correctly running. Each bit of the Fault register represent a fault condition. It's possible to have one ore more fault condition activated.

	Output	Fault Register
Address	669	
Access	R	
Unit	-	
Range	[0 - 65535]	
Type	uint (16 bit)	
CANopen Object ID	0x60F3	

The following error are allowed on the drive system:

Bit	Error
0	<i>OVER_VOLTAGE</i>
1	<i>UNDER_VOLTAGE</i>
2	<i>PEAK_MOTOR_CURRENT</i>
3	<i>RATED_MOTOR_CURRENT</i>
4	<i>SHORT_CIRCUIT</i>
8	<i>POSITION_TRACKING_ERROR</i>
9	<i>VELOCITY_TRACKING_ERROR</i>
10	<i>OVERVELOCITY</i>
12	<i>DRIVE_OVERTEMPERATURE</i>
13	<i>FIELDBUS_CYCLE_TIME</i>

Control Mode Display

This output show the actual mode of operation configured.

	Output	<i>Control mode display</i>
Address		670
Access		R
Unit		-
Range		[0 - 65535]
Type		uint (16 bit)
CANopen Object ID		0x6061

For a list of possible value check [Modes of Operation](#) parameter.

Analog Input

This output show the value that the ADC read from the Axis Analog Input in [mV].

	Output	Analog Input
Address	671	
Access	R	
Unit	[mv]	
Range	[0 - 65535]	
Type	uint (16 bit)	
CANopen Object ID	0x2205 0x01	

Current Output

The following outputs are all the important value for the current controller.

Iq Target

This value is the IQ Current set point in [A/100].

	<i>Output</i>	<i>Iq target</i>
Address	676	
Access	R	
Unit	[A/100]	
Range	[0 - 65535]	
Type	int (16 bit)	
CANopen Object ID	0x6071	

Actual Iq

This value is the IQ Current value [A/100].

	<i>Output</i>	<i>Actual Iq</i>
Address	674	
Access	R	
Unit	[A/100]	
Range	[-32767 32768]	
Type	int (16 bit)	
CANopen Object ID	0x6078	

Iq Error

This value is the difference between IqTarget and Actual Iq value [A/100]. This value will feed the Current Profiler to generate a IqDemand.

	<i>Output</i>	<i>Iq error</i>
--	---------------	-----------------

Address	675
Access	R
Unit	[A/100]
Range	[-32767 32768]
Type	int (16 bit)

Actually the Current Interpolator is not active so IqTarget will feed immediately the Iq Demand.

Iq Demand

This value is the Actual Iq Demand. This is the real actual current demand.

	Output	<i>Iq demand</i>
Address	676	
Access	R	
Unit	[A/100]	
Range	[-32767 32768]	
Type	int (16 bit)	
CANopen Object ID	0x6074	

Iq Tracking Error

This value is the difference between IqDemand and Actual Iq value [A/100], ence the real error that is present on the current controller.

	Output	<i>Iq tracking error</i>
Address	676	
Access	R	
Unit	[A/100]	
Range	[-32767 32768]	
Type	int (16 bit)	

Velocity Outputs

The following outputs represent all the important value for the speed controller.

Velocity Target

This value is the Speed set-point that feed the speed profiler [rpm].

	<i>Output</i>	<i>Velocity target</i>
Address	680-681	
Access	R	
Unit	[rpm]	
Range	[-32767 32768]	
Type	int (16 bit)	
CANopen Object ID	0x60FF	

Actual Velocity

This value represent the actual speed of the motor [rpm].

	<i>Output</i>	<i>Actual velocity</i>
Address	682-683	
Access	R	
Unit	[rpm]	
Range	[-32767 32768]	
Type	int (16 bit)	
CANopen Object ID	0x606C	

Velocity Error

This value represent the difference between Velocity Target and Actual velocity [rpm].

	<i>Output</i>	<i>Velocity error</i>
Address	684-685	
Access	R	
Unit	[rpm]	
Range	[-32767 32768]	
Type	int (16 bit)	

Velocity Demand

This value represent the actual velocity demand coming from the speed profiler.

	<i>Output</i>	<i>Velocity demand</i>
Address	686-687	
Access	R	
Unit	[rpm]	
Range	[-32767 32768]	
Type	int (16 bit)	

Velocity Tracking Error

This value represent the difference between Velocity Demand and Actual Velocity value [rpm], hence the real error that is present on the speed controller.

	<i>Output</i>	<i>Velocity tracking error</i>
Address	688-689	
Access	R	
Unit	[rpm]	
Range	[-32767 32768]	
Type	int (16 bit)	

Position Outputs

The following outputs represent all the important value for the position controller.

Position Target

This value is the position set-point [Counts].

Output	<i>Position target</i>
Address	690-691
Access	R
Unit	[counts]
Range	[-2147483648;2147483647]
Type	long (32 bit)
CANopen Object ID	0x607A

Actual Position

This value is the position actual of the motor [Counts]

Output	<i>Actual position</i>
Address	692-693
Access	R
Unit	[counts]
Range	[-2147483648;2147483647]
Type	long (32 bit)
CANopen Object ID	0x6064

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Position Error

This value is the difference between Position Target and Actual Position [Counts]. This error will feed the Position Profiler.

	<i>Output</i>	<i>Position error</i>
Address	694-695	
Access	R	
Unit	[counts]	
Range	[-2147483648;2147483647]	
Type	long (32 bit)	

Position Demand

This value is the output of the Position Profiler, ence the Actual Position Demand [Counts]

	<i>Output</i>	<i>Position demand</i>
Address	696-697	
Access	R	
Unit	[counts]	
Range	[-2147483648;2147483647]	
Type	long (32 bit)	

Position Tracking Error

This value is the difference between Position Demand and Actual Position [Counts]. This error of the Position Loop.

	Output	<i>Position tracking error</i>
Address	698-699	
Access	R	
Unit	[counts]	
Range	[-2147483648;2147483647]	
Type	long (32 bit)	
CANopen Object ID	0x60F4	

In Position

This value is a flag that report that the position of the motor is within the limit, so the movement is completed.

	Output	<i>In position</i>
Address	700	
Access	R	
Unit	[-]	
Range	[0 1]	
Type	bool (1 bit)	

Other Output Parameters

Homing Status

	<i>Output</i>	<i>Homing Status</i>
Address		702
Access		R
Unit		[-]
Range		[0 10]
Type		<i>Unsigned Int</i>

This parameter show the status of the homing process. The status can have the following values:

	<i>Bit</i>	<i>Error</i>
0		<i>Idle</i>
1		<i>Moving to Switch</i>
2		<i>Moving from Switch</i>
3		<i>Moving From Limit Switch</i>
4		<i>Moving to Zero</i>
5		<i>Halted</i>
6		<i>Timeout</i>
7		<i>Error</i>
8		<i>Attained – Axis Still</i>
9		<i>Moving</i>
10		<i>Post Homing Action</i>
		<i>Completed</i>

Motor Usage

This value shows the percentage use of the motor. If the value reaches 100%, the motor will be stopped with I2T error.

	<i>Output</i>	<i>Motor Usage</i>
Address	704	
Access	R	
Unit	[%]	
Range	[0 100]	
Type	Int (16 bit)	

Axis Enabled

This value is 1 when the servo is enabled. This parameter can be used in connection with Enable (Input) to create a safe protocol.

	<i>Output</i>	<i>Axis Enabled</i>
Address	703	
Access	R	
Unit	[bit]	
Range	[0 1]	
Type	Bool	

Input State

Indicates the state of digital inputs. Each bit corresponds to a digital input (if present).

	<i>Output</i>	<i>Input State</i>
Address	704	
Access	R	
Unit	[bit]	
Range	[0 1]	
Type	Bool	
CANopen Object ID	0x60FD	

NMT State

This value show the actual status of the CANOpen/EtherCAT network on the axis.

	Output	NMT state
Address	706	
Access	R	
Unit	[-]	
Range	[0 20]	
Type	Int (16 bit)	

User Program Functionality

In this Chapter are listed all the relevant user program Input output and parameter

User Program Active-Enable User Program

This parameter allow the start of the User Function

Parameter	<i>User Program active</i>
Address	14
Base Address	0
Access	R/W
Default Values	0
Range	[0 - 1]
Activation	IMMEDIATE
CANopen Object ID	0x2300 0x01

User Program Type

This parameter allow to pass one parameter to the user User Function.

Parameter	<i>User Program Type</i>
Address	15
Base Address	0
Access	R/W
Default Values	0
Range	[0 - 65535]
Activation	IMMEDIATE
CANopen Object ID	0x2300 0x02

Ethernet Fieldbus Parameters

Industrial Ethernet Stack Firmware Version

This output value contain the Ethernet Fieldbus Stack firmware version of the device.

Only readable with MODBUS TCP/IP

	Output	<i>Firmware version</i>
Address		6000-6001
Access		R
Unit		[-]
Range		-
Type		<i>String</i>

How to read Firmware Version: Take the bytes of this Output and split as follows in orders:

a.b.c.d

	Value	<i>Description</i>
a		<i>Major</i>
b		<i>Minor</i>
c		<i>Revision</i>
d		<i>Build</i>

Industrial Ethernet Application Firmware Version

This output value contain the Ethernet Fieldbus Application firmware version of the device.

Only readable with MODBUS TCP/IP

	Output	<i>Firmware version</i>
Address		6002-6003
Access		R
Unit		[-]
Range		-

Motor Power Company s.r.l.

Via Leonardo Da Vinci, 4
42024 Castelnovo Sotto Reggio Emilia - Italia
Tel. +39 0522 682710 - Fax +39 0522 683552
info@motorpowerco.it - motorpowerco.com
Cap. Soc. 250.000,00€ i.v. - R.E.A. di RE 175521
Iscr.Reg.Impr. di RE n.01308390358 - N. Mecc. RE 010210
C.F. e P.IVA IT 01308390358



Type	<i>String</i>
-------------	---------------

How to read Firmware Version: Take the bytes of this Output and split as follows in orders:

a.b.c.d

	Value	Description
a		<i>Major</i>
b		<i>Minor</i>
c		<i>Revision</i>
d		<i>Build</i>

