



## **EtherCAT and CANopen manual**

***Important!***  
***Read thoroughly before use!***  
***Retain for future reference!***

**> Contact**

Motor Power Company S.r.l.  
Via Leonardo Da Vinci, 4  
42024 Castelnovo Sotto - Reggio Emilia  
Italy

Tel +39 0522 682710  
Fax +39 0522 683552  
Email: [info@motorpowerco.it](mailto:info@motorpowerco.it)  
<https://www.motorpowerco.com>

Manufacturer:  
Metronix Meßgeräte und Elektronik GmbH,  
Kocherstraße 3, 38120 Braunschweig, Germany

**> Revision Information**

Manual title	EtherCAT and CANopen manual
Version	1.0
Year	2023

# Table of Contents

<b>1 About this manual</b> .....	<b>10</b>
1.1 Structure of the warning notes .....	10
1.2 Notation in this manual .....	11
<b>2 Quick-start guide</b> .....	<b>12</b>
2.1 CANopen .....	12
2.1.1 Basics .....	12
2.1.2 Wiring and pin assignment .....	13
2.1.3 Wiring instructions .....	14
2.1.4 Status LEDs .....	15
2.1.5 Activate CANopen .....	16
2.1.6 Integration of the servo drive in a master project .....	18
2.2 EtherCAT .....	24
2.2.1 Basics .....	24
2.2.2 Wiring and pin assignment .....	25
2.2.3 Wiring instructions .....	26
2.2.4 Status LEDs (BL 4000-C) .....	27
2.2.5 Activate EtherCAT .....	27
2.2.6 Integration of the servo drive in a master project .....	28
2.2.7 EoE (Ethernet over EtherCAT®) .....	32
2.2.7.1 Activating EoE in the master .....	33
2.2.7.2 Configure Bridge .....	34
<b>3 Parameterisation</b> .....	<b>36</b>
3.1 Loading and saving parameter sets .....	38
3.1.1 Overview .....	38
3.1.2 Description of objects .....	39
3.1.2.1 Object 1011h: restore_default_parameters .....	39
3.1.2.2 Object 1010h: store_parameters .....	40
3.2 Compatibility settings .....	41
3.2.1 Overview .....	41
3.2.2 Description of objects .....	41
3.2.2.1 Object 6510h_F0h: compatibility_control .....	41
3.3 Factor Group .....	43
3.3.1 Overview .....	43
3.3.2 Parameterisation of the Factor Group .....	44
3.3.3 Description of objects .....	45
3.3.3.1 Object 6093h: position_factor .....	45
3.3.3.2 Object 6094h: velocity_encoder_factor .....	45
3.3.3.3 Object 6097h: acceleration_factor .....	46
3.3.3.4 Object 607Eh: polarity .....	46
3.4 Power stage parameters .....	47
3.4.1 Overview .....	47
3.4.2 Description of objects .....	47
3.4.2.1 Object 6510h_10h: enable_logic .....	47

3.4.2.2	Object 6510h_30h: pwm_frequency	48
3.4.2.3	Object 6510h_3Ah: enable_enhanced_modulation	49
3.4.2.4	Object 6510h_31h: power_stage_temperature	49
3.4.2.5	Object 6510h_32h: max_power_stage_temperature	50
3.4.2.6	Object 6510h_33h: nominal_dc_link_circuit_voltage	50
3.4.2.7	Object 6510h_34h: actual_dc_link_circuit_voltage	51
3.4.2.8	Object 6510h_35h: max_dc_link_circuit_voltage	51
3.4.2.9	Object 6510h_36h: min_dc_link_circuit_voltage	52
3.4.2.10	Object 6510h_37h: enable_dc_link_undervoltage_error	52
3.4.2.11	Object 6510h_40h: nominal_current	53
3.4.2.12	Object 6510h_41h: peak_current	53
3.5	Current controller and motor adaption	54
3.5.1	Overview	54
3.5.2	Description of objects	54
3.5.2.1	Object 6075h: motorRatedCurrent	54
3.5.2.2	Object 6073h: max_current	55
3.5.2.3	Object 604Dh: pole_number	55
3.5.2.4	Object 6410h_11h: encoder_offset_angle	55
3.5.2.5	Object 6410h_10h: phase_order	56
3.5.2.6	Object 6410h_03h: iit_time_motor	57
3.5.2.7	Object 6410h_04h: iit_ratio_motor	57
3.5.2.8	Object 6510h_3Dh: iit_ratio_servo	57
3.5.2.9	Object 6510h_38h: iit_error_enable	58
3.5.2.10	Object 6510h_2Eh: motor_temperature	58
3.5.2.11	Object 6410h_14h: motor_temperature_sensor_polarity	59
3.5.2.12	Object 6510h_2Fh: max_motor_temperature	59
3.5.2.13	Object 60F6h: torque_control_parameters	60
3.5.2.14	Object 203Ah: torque_feed_forward	60
3.6	Velocity controller	61
3.6.1	Overview	61
3.6.2	Description of objects	61
3.6.2.1	Object 60F9h: velocity_control_parameters	61
3.6.2.2	Object 2073h: velocity_display_filter_time	62
3.7	Position Controller	63
3.7.1	Overview	63
3.7.2	Description of objects	64
3.7.2.1	Object 60FBh: position_control_parameter_set	64
3.7.2.2	Object 6062h: position_demand_value	66
3.7.2.3	Object 202Dh: position_demand_sync_value	66
3.7.2.4	Object 6064h: position_actual_value	66
3.7.2.5	Object 6066h: following_error_time_out	66
3.7.2.6	Object 6065h: following_error_window	67
3.7.2.7	Object 60F4h: following_error_actual_value	67
3.7.2.8	Object 60FAh: control_effort	67
3.7.2.9	Object 6410h_0Fh: rotor_position	68

3.7.2.10	Object 6067h: position_window .....	68
3.7.2.11	Object 6068h: position_window_time .....	68
3.7.2.12	Object 6510h_22h: position_error_switch_off_limit .....	69
3.7.2.13	Object 2030h: set_position_absolute .....	69
3.7.2.14	Object 607Dh: software_position_limit .....	70
3.7.2.15	Object 607Bh: position_range_limit .....	70
3.7.2.16	Object 6510h_20h: position_range_limit_enable .....	71
3.8	Setpoint limitation .....	72
3.8.1	Object 2415h: current_limitation .....	72
3.8.2	Object 2416h: speed_limitation .....	73
3.9	Encoder adaptation .....	74
3.9.1	Overview .....	74
3.9.2	Description of objects .....	74
3.9.2.1	Object 2024h: encoder_x2a_data_field .....	74
3.9.2.2	Object 2026h: encoder_x2b_data_field .....	75
3.9.2.3	Object 2025h: encoder_x10_data_field .....	75
3.9.2.4	Object 202Ch: max_comm_enc_pos_enc_difference .....	76
3.10	Master frequency output .....	77
3.10.1	Overview .....	77
3.10.2	Description of objects .....	77
3.10.2.1	Object 201Ah: encoder_emulation_data .....	77
3.10.2.2	Object 2028h: encoder_emulation_resolution .....	77
3.11	Setpoint / actual value selection .....	78
3.11.1	Overview .....	78
3.11.2	Description of objects .....	78
3.11.2.1	Object 201Fh: commutation_encoder_select .....	78
3.11.2.2	Object 2021h: position_encoder_selection .....	79
3.11.2.3	Object 2022h: synchronisation_encoder_selection .....	79
3.11.2.4	Object 202Fh: synchronisation_selector_data .....	80
3.11.2.5	Object 2023h: synchronisation_filter_time .....	80
3.12	Analogue inputs .....	81
3.12.1	Overview .....	81
3.12.2	Description of objects .....	81
3.12.2.1	Object 2400h: analog_input_voltage .....	81
3.12.2.2	Object 2401h: analog_input_offset .....	82
3.13	Digital inputs and outputs .....	83
3.13.1	Overview .....	83
3.13.2	Description of objects .....	83
3.13.2.1	Object 60FDh: digital_inputs .....	83
3.13.2.2	Object 60FEh: digital_outputs .....	83
3.13.2.3	Object 2420h: digital_output_state_mapping .....	84
3.14	Limit switch / Reference switch .....	86
3.14.1	Overview .....	86
3.14.2	Description of objects .....	86
3.14.2.1	Object 6510h_11h: limit_switch_polarity .....	86

3.14.2.2	Object 6510h_12h: limit_switch_selector .....	87
3.14.2.3	Object 6510h_15h: limit_switch_deceleration .....	87
3.14.2.4	Object 6510h_14h: homing_switch_polarity .....	88
3.14.2.5	Object 6510h_13h: homing_switch_selector .....	88
3.15	Position capturing (Sampling) .....	89
3.15.1	Overview .....	89
3.15.2	Description of objects .....	89
3.15.2.1	Object 204Ah: sample_data .....	89
3.16	Brake control .....	92
3.16.1	Overview .....	92
3.16.2	Description of objects .....	92
3.16.2.1	Object 6510h_18h: brake_delay_time .....	92
3.17	Device information .....	93
3.17.1	Description of objects .....	93
3.17.1.1	Object 1000h: device_type .....	93
3.17.1.2	Object 1008h: manufacturer_device_name .....	93
3.17.1.3	Object 1009h: manufacturer_hardware_version .....	93
3.17.1.4	Object 100Ah: manufacturer_software_version .....	94
3.17.1.5	Object 1018h: identity_object .....	94
3.17.1.6	Object 6510h_A0h: drive_serial_number .....	95
3.17.1.7	Object 6510h_A1h: drive_type .....	96
3.17.1.8	Object 6510h_A9h: firmware_main_version .....	96
3.17.1.9	Object 6510h_AAh: firmware_custom_version .....	96
3.17.1.10	Object 6510h_ADh: km_release .....	97
3.17.1.11	Object 6510h_ACh: firmware_type .....	97
3.17.1.12	Object 6510h_B0h: cycletime_current_controller .....	97
3.17.1.13	Object 6510h_B1h: cycletime_velocity_controller .....	98
3.17.1.14	Object 6510h_B2h: cycletime_position_controller .....	98
3.17.1.15	Object 6510h_B3h: cycletime_trajectory_generator .....	98
3.17.1.16	Object 6510h_C0h: commissioning_state .....	99
3.17.1.17	Object 20FDh: user_device_name .....	99
3.18	Error management .....	100
3.18.1	Overview .....	100
3.18.2	Description of objects .....	100
3.18.2.1	Object 2100h: error_management .....	100
3.18.2.2	Object 200Fh: last_warning_code .....	101
<b>4</b>	<b>Device Control .....</b>	<b>102</b>
4.1	Overview .....	102
4.2	State Machine .....	103
4.2.1	State diagram: States .....	105
4.2.2	State diagram: State transitions .....	105
4.3	controlword .....	108
4.4	Reading the servo drive status .....	111
4.5	Statuswords .....	112
4.5.1	Object 6041h: statusword .....	112

4.5.2	Object 2000h: manufacturer_statuswords	115
4.5.3	Object 2005h: manufacturer_status_masks	118
4.5.4	Object 200Ah: manufacturer_status_invert	118
4.5.5	Object 2001h: manufacturer_warnings	118
4.5.6	Object 2006h: manufacturer_warning_masks	119
4.6	Description of further objects	120
4.6.1	Object 605Bh: shutdown_option_code	120
4.6.2	Object 605Ch: disable_operation_option_code	120
4.6.3	Object 605Ah: quick_stop_option_code	120
4.6.4	Object 605Eh: fault_reaction_option_code	121
<b>5</b>	<b>Operating modes</b>	<b>122</b>
5.1	Setting the operating mode	122
5.1.1	Overview	122
5.1.2	Description of objects	122
5.1.2.1	Object 6060h: modes_of_operation	122
5.1.2.2	Object 6061h: modes_of_operation_display	123
5.2	Homing Mode	124
5.2.1	Overview	124
5.2.2	Description of objects	125
5.2.2.1	Important objects in other sections	125
5.2.2.2	Object 607Ch: home_offset	125
5.2.2.3	Object 6098h: homing_method	125
5.2.2.4	Object 6099h: homing_speeds	126
5.2.2.5	Object 609Ah: homing_acceleration	127
5.2.2.6	Object 2045h: homing_timeout	127
5.2.3	Homing sequences	128
5.2.3.1	Methods -17 and -18: Stop	128
5.2.3.2	Methods -1 and -2: stop with index pulse evaluation	128
5.2.3.3	Methods 17 and 18: positive and negative limit switch	129
5.2.3.4	Methods 1 and 2: positive and negative limit switch with index pulse evaluation	129
5.2.3.5	Methods 23 and 27: reference switch	130
5.2.3.6	Methods 7 and 11: reference switch and index pulse evaluation	131
5.2.3.7	Methods -23 and -27: homing run (positive/negative) to the reference switch	132
5.2.3.8	Methods 32 and 33: homing to the index pulse	132
5.2.3.9	Method 34: homing to the current position	132
5.2.4	Homing control	133
5.3	Profile Position Mode	134
5.3.1	Overview	134
5.3.2	Functional description	134
5.3.3	Description of objects	136
5.3.3.1	Important objects in other sections	136
5.3.3.2	Object 607Ah: target_position	136
5.3.3.3	Object 6081h: profile_velocity	136
5.3.3.4	Object 6082h: end_velocity	137
5.3.3.5	Object 6083h: profile_acceleration	137

5.3.3.6	Object 6084h: profile_deceleration .....	137
5.3.3.7	Object 6085h: quick_stop_deceleration .....	137
5.3.3.8	Object 6086h: motion_profile_type .....	138
5.4	Interpolated Position Mode .....	139
5.4.1	Overview .....	139
5.4.2	Functional description .....	139
5.4.3	Description of objects .....	142
5.4.3.1	Important objects in other sections .....	142
5.4.3.2	Object 60C0h: interpolation_submode_select .....	142
5.4.3.3	Object 60C1h: interpolation_data_record .....	143
5.4.3.4	Object 60C2h: interpolation_time_period .....	143
5.4.3.5	Object 60C3h: interpolation_sync_definition .....	144
5.4.3.6	Object 60C4h: interpolation_data_configuration .....	145
5.4.3.7	Object 1006h: communication_cycle_period .....	146
5.5	Cyclic Synchronous Position Mode .....	147
5.5.1	Overview .....	147
5.5.2	Description of objects .....	147
5.5.2.1	Important objects in other sections .....	147
5.6	Profile Velocity Mode .....	148
5.6.1	Overview .....	148
5.6.2	Description of objects .....	149
5.6.2.1	Important objects in other sections .....	149
5.6.2.2	Object 6069h: velocity_sensor_actual_value .....	150
5.6.2.3	Object 606Ah: sensor_selection_code .....	150
5.6.2.4	Object 606Bh: velocity_demand_value .....	150
5.6.2.5	Object 202Eh: velocity_demand_sync_value .....	150
5.6.2.6	Object 606Ch: velocity_actual_value .....	151
5.6.2.7	Object 2074h: velocity_actual_value_filtered .....	151
5.6.2.8	Object 606Dh: velocity_window .....	152
5.6.2.9	Object 606Eh: velocity_window_time .....	152
5.6.2.10	Object 606Fh: velocity_threshold .....	152
5.6.2.11	Object 6070h: velocity_threshold_time .....	153
5.6.2.12	Object 6080h: max_motor_speed .....	153
5.6.2.13	Object 60FFh: target_velocity .....	153
5.6.2.14	Speed ramps .....	154
5.7	Profile Torque Mode .....	156
5.7.1	Overview .....	156
5.7.2	Description of objects .....	157
5.7.2.1	Important objects from other sections .....	157
5.7.2.2	Object 6071h: target_torque .....	157
5.7.2.3	Object 6072h: max_torque .....	157
5.7.2.4	Object 6074h: torque_demand_value .....	157
5.7.2.5	Object 6076h: motorRated_torque .....	158
5.7.2.6	Object 6077h: torque_actual_value .....	158
5.7.2.7	Object 6078h: current_actual_value .....	158



---

5.7.2.8 Object 6079h: dc_link_circuit_voltage .....	158
5.7.2.9 Object 6087h: torque_slope .....	159
5.7.2.10 Object 6088h: torque_profile_type .....	159
<b>6 Detailed description of the CANopen protocol .....</b>	<b>160</b>
6.1 Introduction .....	160
6.2 Access via SDO .....	161
6.2.1 SDO sequences for reading and writing .....	162
6.2.2 SDO error response (abort codes) .....	163
6.2.3 Simulation of SDO accesses .....	164
6.3 Access via PDO .....	165
6.3.1 Description of objects .....	166
6.3.2 Objects for PDO configuration .....	168
6.3.3 Activation of PDOs .....	173
6.4 EMERGENCY message .....	174
6.4.1 Overview .....	174
6.4.2 Structure of the EMERGENCY message .....	175
6.4.3 Description of objects .....	175
6.5 SYNC message .....	176
6.6 Network Management (NMT service) .....	177
6.7 Bootup .....	180
6.7.1 Overview .....	180
6.7.2 Structure of the Bootup message .....	180
6.8 Heartbeat (Error Control Protocol) .....	180
6.8.1 Overview .....	180
6.8.2 Structure of the Heartbeat message .....	181
6.8.3 Description of objects .....	181
6.9 Nodeguarding (Error Control Protocol) .....	182
6.9.1 Overview .....	182
6.9.2 Structure of the Nodeguarding messages .....	182
6.9.3 Description of objects .....	183
6.9.3.1 Object 100Ch: guard_time .....	183
6.9.3.2 Object 100Dh: life_time_factor .....	183
6.10 Table of identifiers .....	184
<b>7 Appendix .....</b>	<b>185</b>
7.1 CANopen .....	185
7.2 Characteristics of the CAN interface .....	185
7.3 Error codes of the EMERGENCY message .....	186

# 1 About this manual

This manual describes how the servo drives of the BL 4000-C or BL 4000-M / BL 4000-D device series can be integrated into a CANopen or Ethercat network. The physical connection, activation of the fieldbus protocol, integration into the network and the parameters for adaptation to the respective application are described. It is intended for persons who are already familiar with the respective servo drive series and have read and understood the corresponding product manual.

The product manual contains instructions for the proper and professional transport, storage, assembly, installation, project planning and correct and safe operation of the servo drive.

**The product manual contains safety instructions which must be strictly observed.**

The product manuals are available for download on our homepage (<https://www.motorpowerco.com>).

## 1.1 Structure of the warning notes

Warning notes have the following structure:

- Signal word
- Type of hazard
- Measures to prevent the hazard

### > Signal words

#### **⚠ DANGER**

Indicates an imminent hazard.

If the situation is not avoided, extremely serious and possibly fatal injuries will result.

#### **⚠ WARNING**

Indicates a potentially hazardous situation.

If the situation is not avoided, extremely serious and possibly fatal injuries may result.

#### **⚠ CAUTION**


Indicates a potentially hazardous situation.

If the situation is not avoided, slight or minor injuries may result.

#### **NOTICE**

Warns against damage to property.

### > Warning signs as per ISO 7010

Warning sign	Explanation
	Warning against fatal electric voltage.

## 1.2 Notation in this manual

### > Structure of notes

The notes in this manual have the following structure:

- Signal word "NOTE"
- Introductory phrase
- Explanations and special tips

### > Operating elements, menus

Operating elements, menus and menu paths are written in red.

**Example:** Double-clicking the desired device or clicking the button **Establish connection** will establish an online connection.

### > CAN Objects, bit constants

Terms from the CANopen standards such as parameter names (CAN objects) are written in dark red. Bit constants are highlighted by a different font.

**Example:** If this bit is set, bit 4 of the **statusword** (`vo1tage_enabled`) is output according to DSP 402 v2.0.

### > States, commands

Servo drive states (see section 4 *Device Control* on page 102) are set in a different font and are capitalised. Commands are highlighted with a white box.

**Example:**

NOT_READY_TO_SWITCH_ON	The servo drive carries out a self-test.					
4	Enable Operation	1	1	1	1	Motor control according to the current operating mode

## 2 Quick-start guide

This chapter describes how to connect the servo drives to a commercially available CANopen or Ethercat controller and put them into operation in order to obtain a quick setup for starting application development. Depending on which fieldbus interface is used, the respective other chapter can be skipped.

Section 3 *Parameterisation* on page 36 then describes all available parameters, which can usually be used equally under CANopen and EtherCAT, in order to adapt the servo drive to the respective application. This chapter is intended for users who already have an industrial controller.

### 2.1 CANopen

CANopen is a standard maintained by the association "CAN in Automation", which defines the use of CAN in automation technology independently of manufacturers. The CANopen interface in the BL 4000 is designed according to CiA 301 (transmission layer) and CiA 402 (drive controller profile).

#### 2.1.1 Basics

The CANopen fieldbus protocol defines how data is exchanged via the CAN fieldbus in industrial automation.

In general, there are two types of messages (communication objects) that are exchanged between the master (e.g. CoDeSys controller) and the slave.

- **SDO (Service Data Objects)**

This type of message is used for acyclic communication between master and slave, e.g. during the initialization phase of the application or in a very simple application where no cyclic data exchange is required.

- **PDO (Process Data Objects)**

This type of message is exchanged cyclically/automatically between master and slave to transfer process data. Process data is all the data required by the master or slave to execute the application. In our example, this process data contains e.g. position setpoint/actual values, control and status words and other important information to be able to use the servo drive as a SoftMotion axis.

There are further message types, such as **Emergency Messages**, **Heartbeat Messages** or **Node Guarding Messages**, which are also exchanged between master and slave, but only in case of a special event or in special applications. For example, an **Emergency Message** is sent from the slave to the master when a serious error has occurred in the servo drive. A detailed description of these message types can be found in section 6 *Detailed description of the CANopen protocol* on page 160.

## 2.1.2 Wiring and pin assignment

The CAN interface is integrated in the BL 4000-C servo drives and therefore always available. For servo drives of the BL 4000-M / BL 4000-D series, the CAN interface is only available with the CAN field bus variant. More detailed information on this can be found in the *Product Description* section of the Product manual BL 4000-D and BL 4000-M.

### **INFORMATION** CAN bus wiring

When wiring the servo drive via the CAN bus, it is essential that you observe the following information and notes in order to obtain a stable, trouble-free system.

If the cabling is not correct, faults can occur on the CAN bus during operation, which can cause the servo drive to switch off with a fault for safety reasons.

### **INFORMATION** 120Ω terminating resistor

No terminating resistor is integrated in the BL 4000-C, BL 4000-D and BL 4000-M servo drives.

### > BL 4000-C

The CAN bus connection is designed as a 9-pin DSUB connector (servo drive side) according to the standard.




Figure 1: CAN connector

Pin	Name	Description
1		Not used
6	CAN-GND	CAN-GND (directly coupled to GND in the BL 4000-C servo drive)
2	CAN-L	CAN low signal line
7	CAN-H	CAN high signal line
3	CAN-GND	See pin no. 6
8		Not used
4		Not used
9		Not used
5	Shield	Connection for cable shield

### ➤ BL 4000-D and BL 4000-M (Fieldbus variant CAN)

On these devices, the CAN bus connection is designed as an M8 connector according to IEC 61076-114 (4-pin, socket, D-coded). Note that although the fieldbus variant PROFINET/EtherCAT uses the identical connectors, it is not electrically compatible. The fieldbus variants must not be mixed up and must never be used simultaneously in the same network!




Figure 2: Pin assignment of the fieldbus connector

Pin assignment **CANopen**:

Pin	Name	Description	Colour
1	CAN-H	Differential Signal High	Yellow
2	CAN-GND	Reference potential	Orange
3	CAN-L	Differential Signal High	White
4	CAN-GND	Reference potential	Blue

For wiring, we recommend using the following pre-assembled cables or comparable products from other manufacturers:

Assembled network cable Phoenix Contact:

M8 plug to M8 plug: NBC-M8MSD/ 1,0-93C/M8MSD - 1423707

M8 plug to RJ45: NBC-M8MSD/ 1,0-93C/R4AC - 1423711

M8 plug to free cable end: NBC-M8MSD/ 1,0-93C - 1423703

## 2.1.3 Wiring instructions

For trouble-free operation of the CAN bus communication, the following instructions must be observed

- Ideally, the individual nodes of the networks are always connected in a linear manner so that the CAN cable is looped through from servo drive to servo drive.
- A terminating resistor of 120 Ω, 5%, must be present on both ends of the CAN bus cable
- We advise against the use of intermediate plugs for cabling the CAN bus. However, if this is necessary, use metal connector housings for connecting the cable shield.

In order to keep interferences as low as possible ensure that

- the motor cables are not installed parallel to signal lines
- the motor cables comply with the specification
- the motor cables are properly shielded and earthed (grounded)

The cable used should be constructed as follows

- Shielded cables with exactly two twisted pairs must be used for cabling
- Use one twisted pair to connect CAN-H and CAN-L.
- The cores of the other pair are used jointly for CAN-GND.
- The shield of the cable is led to the CAN shield connections for all nodes




Figure 3: CAN bus cabling example

### › Technical data CAN cable

The cable names that are stated refer to cables made by Lapp. However, it is also possible to use comparable cables from other manufacturers, for example Lütze or Helukabel.

**Technical data of the CAN bus cable:** 2 pairs of 2 twisted cores,  $d \geq 0.22 \text{ mm}^2$ , shielded, loop resistance  $< 0.2 \text{ } \Omega/\text{m}$ , characteristic impedance 100-120  $\Omega$

LAPP KABEL UNITRONIC BUS CAN; 2 x 2 x 0.22; 7.6 mm, with CU shielding

**For highly flexible applications:**

LAPP KABEL UNITRONIC BUS CAN FD P; 2 x 2 x 0.25; 8.4 mm, with CU shielding

## 2.1.4 Status LEDs

### › BL 4000-C

For easy indication of the CAN bus status, the servo drive is equipped with two fieldbus status LEDs:

The LEDs indicate the following states:

Name	Colour	Description
RUN/SF/MS	Green	This LED indicates ongoing communication between the master and the servo drive. It is triggered when a message is received from the master. If this LED is continuously OFF, there is no communication with the servo drive.
ERR/BF/NS	Red	This LED indicates the fieldbus error related to the CAN fieldbus. The LED flashes if a CAN-related fieldbus error is present and has not yet been acknowledged.


In normal operation the RUN LED is on, because communication with the servo drive is taking place and the ERR LED is off.

If the ERR LED is flashing, one of the following CAN fieldbus errors has occurred:

Group 12: CAN communication		
12-1	CAN: communication error, bus OFF	Check the wiring: compliance with the cable specification, cable break, maximum cable length exceeded, correct terminating resistors, cable shield earthed, all signals connected?
12-2	CAN: communication error (sending)	
12-3	CAN: communication error (receiving)	
12-4	CAN: Node Guarding	Failure of the PLC or the cycle time of the remote frames of the servo drive and PLC do not match.
12-5	CAN: RPDO too short	The number of bytes of a received RPDO is smaller than the number that is parameterised in the servo drive.
12-9	CAN: protocol error	Please contact the Technical Support team.

## 2.1.5 Activate CANopen

The CANopen fieldbus communication must be activated once via the CANopen window of the MPC ServoCommander ([Parameter / Fieldbus / CANopen / Operation parameters](#)). Depending on the devices series, not all options may be available, so that the appearance of the window may be different.



A total of 3 different parameters must be set:

Parameter	Description
Bit rate	This parameter determines the bit rate in kBit/s used on the CAN bus. It must match the bit rate in the master. Note that the maximum permissible cable length decreases at high bit rates.



Parameter	Description
Node number	For clear identification in the network, each participant must be assigned a node number that may only occur once in the network. The device is addressed via this node number. As an additional option it is possible to make the node number of the servo drive dependent on the external connection. The input combination of the digital inputs DIN0...DIN3 is added once to the basic node number after the reset.
Options	<b>Add node number to COB-IDs of the PDOs:</b> By setting this option, the COB-IDs of the PDOs do not have to be adapted manually to the node number (see section 6.3.2 <i>Objects for PDO configuration</i> on page 168).

Finally, the CANopen protocol can be activated. The above mentioned parameters can only be changed if the protocol is deactivated.

#### **INFORMATION** Parametrisation of the CANopen functionality

Please note that the parametrisation of the CANopen functionality is only retained after a reset if the parameter set of the servo drive has been saved.

#### **INFORMATION** Identical node numbers

It is not permitted to operate several servo drives on the CANopen fieldbus with the same node number. Therefore, make sure that each servo drive on the CANopen fieldbus has a unique node number before you activate communication.


## 2.1.6 Integration of the servo drive in a master project

As an example, this chapter shows how to integrate the servo drive into a CoDeSys V3.5 project and operate them as SoftMotion drives.

As a prerequisite, you must download the CANopen EDS file (Electronic Data Sheet) for the corresponding servo drive from our website (<https://www.motorpowerco.com>). This file contains a complete description of the drive characteristics and the object dictionary and is used by CoDeSys (or another CANopen master) for the automatic configuration of the servo drive. The following example shows the installation of a **BL 4104-C**.

### ➤ Create a new project

Start CoDeSys, connect to your CANopen master and create an empty project.




### ➤ Install the EDS file in the CoDeSys device directory

- Open the CoDeSys device directory.  
Path: **Tools / Device Repository**
- Click the **Install** button
- Select the downloaded EDS file from your location.
- Confirm by clicking the **Open** button

Now the CoDeSys software knows the servo drive and it can be used.


## ➤ Add CANopen Master

Next, a CANopen master must be added. Therefore right click on the Master device and select **Add Device**. The CAN Master must be configured to the same bit rate as the one selected for the servo drive via the MPC ServoCommander.



To be able to connect the servo drive to the CAN master, an additional CANopen SoftMotion Manager must be added to the CAN master.


To do this, right click on the CAN master again and select **Add Device**.



## › Set cycle period


The SoftMotion Manager runs with a specific cycle time. As cyclic PDO data exchange is used in our application, the master synchronises the servo drive to this cycle time. To do this, the cycle time of the master (**Cycle Period**) must match the cycle time configured in the servo drive.

In the MPC ServoCommander you will find the dialog for configuring the cycle time in the menu **Parameters\Controller parameters\Cycle times**. For more information on setting the cycle times, refer to the section *Control circuit cycle times* in the product manual BL 4000.



## › Adding devices to the project


Finally, the generation of synchronisation telegrams must be activated in the SoftMotion Manager (**Enable Sync Producing**). Log on to the master by clicking on the **Online Config Mode** button. Search for servo drives on the CANopen field bus by right-clicking on the CANopen SoftMotion Manager and selecting **Scan devices**.



All servo drives connected to the fieldbus are detected and can be added to the project by clicking the **Copy to project** button. Afterwards the selected servo drives are displayed as devices connected to SoftMotion Manager.

## ➤ Set PDO configuration

After the servo drive has been found, the cyclic data to be exchanged between servo drive and master must be specified. This is called PDO configuration and can be found on the tab with the corresponding servo drive name (in this case **BL 4104-C**).



The standard PDO mapping only uses the PDOs **1400<sub>h</sub>** (TPDO0-Master►Slave) and **1800<sub>h</sub>** (RPDO0-Master◀Slave).

These PDOs contain the following parameters for operating the servo drive as a SoftMotion axis:


### TPDO 0

Name	ID	Description	See
controlword	6040 <sub>h</sub>	Control word for activating / deactivating the servo drive	page 102
modes_of_operation	6060 <sub>h</sub>	Configuration of the operating mode of the drive	page 122
homing_method	6098 <sub>h</sub>	Configuring the homing method to be used	page 124
target_position	607A <sub>h</sub>	Position setpoints	page 147

### RPDO 0


Name	ID	Description	See
statusword	6041 <sub>h</sub>	Current status of the drive	page 102
modes_of_operation_display	6061 <sub>h</sub>	Current operation mode of the drive	page 122
error_register	1001 <sub>h</sub>	Current error code of the drive	page 174
position_actual_value	6064 <sub>h</sub>	Actual position value	page 66

Both PDOs must be set to "Cyclic transmission at 1 Sync". This is done by selecting the corresponding PDO and clicking the **Edit** button.




Once the PDO configuration is complete, a SoftMotion axis can be added to the servo drive.

To do this, select the servo drive in SoftMotion Manager. A context menu opens by right-clicking on the list entry (BL\_4104\_C). Click on the menu item **Add SoftMotion CiA402 Axis**.




## ➤ Adjust conversion factors

To ensure that the units of the cyclically exchanged values (e.g. for position and speed) match between master and servo drive, the scaling in the servo drive must be adapted to the scaling in the master. Therefore the following scaling should be set in the MPC ServoCommander under **Parameters/Field bus/CANopen/Display units**:



With this scaling a maximum of  $\pm 32768$  revolutions with 16 bit resolution can be displayed on the bus. If this is not sufficient, the scaling of the setpoints transmitted on the bus can be adapted. This is described in section 3.3 *Factor Group* on page 43.

If the scaling is configured correctly, the actual position values should now be displayed in the **Commissioning** window of the CoDeSys SoftMotion axis:



The axis can now be moved from the **Commissioning** tab for testing. In addition, the axis is now ready for implementation in the PLC project. A detailed description of all

parameters of the servo drive and the implemented operating modes can be found in section 3 *Parameterisation* on page 36.

## 2.2 EtherCAT

EtherCAT is a real-time Ethernet developed by Beckhoff Automation. The *CAN application protocol over EtherCAT (CoE)* has been defined to enable an easy changeover from CAN to EtherCAT. This allows the CiA 402 drive controller profile to be used via EtherCAT.

### 2.2.1 Basics

CoE is based on the CANopen field bus protocol and therefore uses the same object dictionary and the same message types:

- **SDO (Service Data Objects)** This type of message is used for acyclic communication between master and slave, e.g. during the initialization phase of the application or in a very simple application where no cyclic data exchange is required.
- **PDO (Process Data Objects)**  
This type of message is exchanged cyclically/automatically between master and slave to exchange process data. Process data is all the data required by the master or slave to execute the application. In our example, this process data contains e.g. position setpoint/actual values, control and status words and other important information to be able to use the servo drive as a SoftMotion axis.

The message type **Emergency Message** is also available. This message is sent from the slave to the master if a serious error has occurred in the servo drive.

Other message types, such as **Sync** messages, are not supported by EtherCAT CoE, because there are other mechanisms to synchronise several slaves on the fieldbus to a common clock. The most important one is **Distributed Clocks (DC)**, which are fully supported by the BL 4000 devices series.

Synchronisation is important for motion applications in which several drives execute interpolated movements.




## 2.2.2 Wiring and pin assignment

In the BL 4000-C servo drives the EtherCAT interface is already integrated in the servo drives. For servo drives of the BL 4000-M / BL 4000-D series, the EtherCAT interface is only available with the PROFINET/EtherCAT field bus variant. For more detailed information, see the *Product Description* section of the Product manual BL 4000-D and BL 4000-M.

### > BL 4000-C

According to the EtherCAT specification, two RJ45 connectors are available as RTE0 and RTE1 [X21]. One for uplink (connection from the previous drive) and one as downlink (connection to the next servo drive in the line).



The two connections RTE0 and RTE1 are RJ45 sockets, Cat. 6

Pin	Designation	Description
1	RX-	Receiver signal -
2	RX+	Receiver signal +
3	TX-	Transmitter signal -
4	-	-
5	-	-
6	TX+	Transmitter signal +
7	-	-
8	-	-

### > BL 4000-D and BL 4000-M (Fieldbus variant PROFINET/EtherCAT)

On these devices, the EtherCAT connection is designed as an M8 connector according to IEC 61076-114 (4-pin, socket, D-coded). Note that although the fieldbus variant CAN uses the identical connectors, it is not electrically compatible. The fieldbus variants must not be mixed up and must never be used simultaneously in the same network!




Figure 4: Pin assignment of the fieldbus connector

Pin assignment **EtherCAT/PROFINET**:

Pin	Name	Description	Colour
1	TD+	Transmission signal +	Yellow
2	RD+	Reception signal +	White
3	TD-	Transmission signal -	Orange
4	RD-	Reception signal -	Blue

We recommend using the following pre-assembled cables or comparable products from other manufacturers.

Assembled network cable Phoenix Contact:


M8 plug to M8 plug: NBC-M8MSD/ 1,0-93C/M8MSD - 1423707

M8 plug to RJ45: NBC-M8MSD/ 1,0-93C/R4AC - 1423711

M8 plug to free cable end: NBC-M8MSD/ 1,0-93C - 1423703

## 2.2.3 Wiring instructions

For cabling, shielded twisted pair Ethernet cables that comply with STP, Cat.5 are used for the EtherCAT bus. All nodes of a network are connected in a linear manner.



## 2.2.4 Status LEDs (BL 4000-C)

For easy indication of the EtherCAT bus status, the servo drive series BL 4000-C is equipped with two fieldbus status LEDs. The behaviour of the LEDs is predefined by the EtherCAT User Group (ETG).

The green RUN LED indicates the current EtherCAT® CoE state:


Flashing code	Status of the State Machine
LED is off	No communication yet.
LED flashes	<b>Pre-Operational (PreOp)</b> The master sets up the slave for cyclic communication. Only asynchronous communication via SDOs is active.
LED flashes once	<b>Safe Operation (SafeOp)</b> Cyclic communication via PDOs is running. The slave ignores the setpoint data, but sends actual values to the master.
LED is on	<b>Operational (OP)</b> The slave accepts setpoints from the master and follows them.

The red ERR-LED indicates possible fieldbus errors:

Flashing code	Status of the State machine
LED is off	No error
LED flashes twice	<b>Cyclic process data watchdog error</b> The fieldbus communication is interrupted. The slave has not received setpoints from the master.

## 2.2.5 Activate EtherCAT

The EtherCAT fieldbus communication must be activated once via the EtherCAT window of the MPC ServoCommander ([Parameters / Field bus / EtherCAT / Operating parameters](#)).



### **INFORMATION** Servo drive blocks communication to succeeding slaves

Note that a servo drive with a deactivated Ethercat interface blocks communication to all following slaves on the fieldbus. Therefore a deactivated servo drive should be removed from the network.

## 2.2.6 Integration of the servo drive in a master project


As an example, the servo drive BL 4104-C is to be inserted as a SoftMotion axis in a PLC project based on CoDeSys V3.5 and Beckhoff TwinCAT. The integration of other servo drives is done in the same way.

### › Integration into the CoDeSys V3.5 project

As a prerequisite you must download the EtherCAT ESI file for the corresponding servo drive from our website (<https://www.motorpowerco.com>). This file contains a complete description of the drive features and the object dictionary and is used by CoDeSys (or any other EtherCAT master) to automatically configure the servo drive.

In contrast to the CANopen EDS file, this file contains not only the object dictionary, but also the complete configuration of the servo drive, including the selection of cyclically exchanged setpoints and actual values via PDOs, the configuration of the fieldbus cycle time and all necessary initialization commands to be sent to the servo drive when the fieldbus is started up.


- After downloading the ESI XML file, connect the servo drive to the CoDeSys master via an Ethernet cable.
- Start CoDeSys, connect to your EtherCAT master and create an empty project.



### › Install the ESI XML file in the CoDeSys device directory


- Call up the CoDeSys device directory. **Path: Tools / Device Repository**
- Click the Install button.
- Select the downloaded EDS file from your location.
- Confirm by clicking the **Open** button.

Now the CoDeSys software knows the servo drive BL 4000-C and it can be used.



## > Add EtherCAT Master


Next an EtherCAT Master must be added. To do this, right click on the Master device and select **Add Device**.



## › Set cycle time


The EtherCAT master exchanges PDOs with the servo drive at a certain cycle time. For this purpose, the servo drive is synchronised by the master to this cycle time. The **Cycle Time** of the servo drive must therefore correspond to the cycle time configured in the EtherCAT master, and Distributed Clock (DC) must be activated in the master.

In the MPC ServoCommander you will find the dialog for configuring the cycle time in the menu **Parameters\Controller parameters\Cycle times**. For more information on setting the cycle times, refer to the section *Control circuit cycle times* in the product manual BL 4000.



## › Adding devices to the project

Finally, the generation of synchronisation telegrams must be activated in the SoftMotion Manager (**Enable Sync Producing**). Log on to the master by clicking on the **Online Config Mode** button. Search for servo drives on the CANopen field bus by right-clicking on the EtherCAT SoftMotion Manager and selecting **Scan devices**.




All servo drives connected to the fieldbus are detected and can be added to the project by clicking the **Copy to project** button. Afterwards the selected servo drives are displayed as devices connected to SoftMotion Manager.

## › Set PDO configuration


In contrast to CANopen, the complete PDO configuration of the cyclic data is done automatically via the ESI XML file, so that a SoftMotion axis can now be added directly to the servo drive.

Right click on the **BL 4104-C** to add a DSP402-compatible SoftMotion axis:




## › Adjust conversion factors

To ensure that the units of the cyclically exchanged values (e.g. for position and speed) match between master and servo drive, the scaling in the servo drive must be adapted to the scaling in the master. Therefore the following scaling should be set in the MPC ServoCommander under **Parameters/Field bus/CANopen/Display units**:



With this scaling a maximum of  $\pm 32768$  revolutions with 16 bit resolution can be displayed on the bus. If this is not sufficient, the scaling of the setpoints transmitted on the bus can be adapted. This is described in section 3.3 *Factor Group* on page 43.

If the scaling is configured correctly, the actual position values should now be displayed in the **Commissioning** window of the CoDeSys SoftMotion axis:




The axis can now be moved from the **Commissioning** tab for testing. In addition, the axis is now ready for implementation in the PLC project. A detailed description of all parameters of the servo drive and the implemented operating modes can be found from section 3 *Parameterisation* on page 36.

## 2.2.7 EoE (Ethernet over EtherCAT®)

Servo drives of the BL 4000 series support the EoE profile (Ethernet over EtherCAT®). In this case, normal Ethernet packets are also routed by the Ethernet master via the EtherCAT® network. This enables the MPC Servo Commander to establish Ethernet communication with the servo drives in the EtherCAT® network without additional cabling of the LAN interfaces.

EoE does not have to be activated separately in the servo drive, but only configured in the EtherCAT® master.

There are two different connection options for the EoE profile. In the first case, the laptop/PC running the MPC Servo Commander is connected directly to the controller, in the second case both are operated on a common LAN.







### 2.2.7.1 Activating EoE in the master

The activation of the EoE function is explained below using the example of a Beckhoff controller. The example assumes that an EtherCAT® network already exists and that cyclic communication with the drives is possible.

Select **Device 1 (EtherCAT®)** in the TwinCAT System Manager and click on **Advanced Settings** in the **EtherCAT** tab




Select the entry **EoE Support** and activate **Virtual Ethernet Switch** and **Connect to TCP/IP Stack**. In the **Windows IP Routing** section, the **IP Enable Router** field must be selected. This enables the forwarding of standard Ethernet packets in the controller.




Finally, EoE support must be activated in the servo drive for each servo drive.

Select the corresponding drive, in this example **Drive 5 (BL 4104)** and click on **Advanced Settings** in the **EtherCAT** tab.



Click **Mailbox / EoE**, enable **Virtual Ethernet Port** and select **IP Port**. At this point you have the choice whether you want to assign a fixed IP address to the device or whether it should be obtained dynamically via DHCP. This requires that a corresponding DHCP server is located in the network.




Finally, the new configuration must be loaded and activated on the controller. The servo drive is now displayed in the device search of the MPC ServoCommander as if the servo drive is connected directly via the Ethernet parameterisation interface (X18). If this is not the case, a "bridge" must also be activated within the Beckhoff controller. This is described in the following chapter.

### 2.2.7.2 Configure Bridge


To make this setting, you must log in directly to the operating system of the Beckhoff controller.

Select **Network and Internet** in the Control Panel. Select the appropriate Ethernet connections (in our case TwinCAT Intel PCI Ethernet Adapter and Beckhoff Virtual Ethernet Adapter).

Press the right mouse button and select **Bridge Connections**.



Afterwards a **Network Bridge** is displayed.



# 3 Parameterisation

Before the servo drive can perform the desired task (torque control, speed control, positioning), numerous parameters of the servo drive must be adapted to the motor used and the specific application. This can be done either via the MPC ServoCommander or via CANopen.

The order in which the parameters are set can be based on the order of the following chapters. If the servo drive is already fully parameterised, you can continue directly with section 4 *Device Control* on page 102 or section 5 *Operating modes* on page 122.

**INFORMATION** **Seven-segment display of the servocontroller shows an "A"**

Servo drives with a seven-segment display show an "A" (Attention) if the servo drive has not yet been parameterised. If the servo drive is to be parameterised completely via CANopen, you must write to object `6510h_C0h` to suppress this display. (See section 3.17.1.16 *Object 6510<sub>h</sub>\_C0<sub>h</sub>: commissioning\_state* on page 99).

In addition to the parameters described here in detail, the object directory of the servo drive contains further parameters that must be implemented according to CANopen. They usually do not contain any information that can be used meaningfully with our servo drives. If required, the specification of such objects can be found in the corresponding standards (see section 7.1 *CANopen* on page 185).

### > Description of the parameters

All parameters of the drive are described in a uniform way. If the parameter is a simple data type (VAR), it is described as follows:

Index	Index (hexadecimal)			
Name	Name of the parameter			
Info	Unit	rw	PDO	Data type
Value	Value range	Default value		

If the parameter is a structured data type (ARRAY/RECORD), it is described as follows:

Index	Index (hexadecimal)		
Name	Name of the parameter group		
Type	Object code		Max
Sub-Index	Subindex (hexadecimal)		
Name	Name of the parameter		
Info	Unit	rw	<del>PDO</del> Data type
Value	Value range	Default value	

The individual fields have the following meaning:

Field	Meaning
Index (hexadecimal)	The main index of the described parameter.
Subindex (hexadecimal)	The subindex of the described parameter. If this is not specified, the subindex is zero.
Name of the parameter group	Plain text name of the parameter group.
Name of the parameter	Plain text name of the parameter.
Object code	Specifies whether the data type is simple or structured: <ul style="list-style-type: none"> <li>• VAR: Simple data type</li> <li>• ARRAY: Group of parameters that all have the same data type.</li> <li>• RECORD: Group of parameters that have different data types.</li> </ul>
Max	Maximum subindex of the group.
Data type	Data type of the parameter or the ARRAY: A list of the supported data types can be found in section 6.2 <i>Access via SDO</i> on page 161.
Unit	Physical unit of the parameter.
Access	Specifies whether the parameter may be read (ro), written (wr) or read and written (rw).
PDO <del>PDO</del>	Specifies whether the parameter may be mapped into a PDO.
Value range	The range of permissible values for this parameter.
Default value	Value that is effective on factory setting or after successful writing to 3.1.2.1 <i>Object 1011h: restore_default_parameters</i> .

## 3.1 Loading and saving parameter sets

### 3.1.1 Overview

The servo drive has three parameter sets:

#### Current parameter set

This parameter set is located in the servo drive's volatile memory (RAM) and contains the parameters that are currently in use. It can be read and written as required with the parameterization program MPC ServoCommander or via the CAN bus. When the servo drive is switched on, the **Application parameter set** is copied to the **Current parameter set**.


#### Application parameter set

The **Current parameter set** can be saved in the non-volatile flash memory (EEPROM) so that it is available again after the next power-up. The saving process is triggered with a write access to the CANopen object `1010h01h` (`save_all_parameters`).

#### Default parameter set

This is the unchangeable parameter set of the servo drive specified by the manufacturer as standard. The **Default parameter set** can be copied to the **Current parameter set** by a write operation to the CANopen object `1011h01h` (`restore_all_default_parameters`). This copying process is only possible when the power stage is switched off.

The following diagram illustrates the relationships between the individual parameter sets.



Two different concepts for parameter set management are conceivable:

**Concept 1:** The parameter set is created with the MPC ServoCommander and also transferred completely to the individual servo drives with the MPC ServoCommander. Using this method, only the objects that are exclusively accessible via CANopen must be set via the CAN bus. The disadvantage here is that the parameterization software is required for each commissioning of a new machine or in the event of a repair (servo drive replacement).

**Concept 2:** This variant is based on the fact that most application-specific parameter sets differ from the default parameter set only in a few parameters. This makes it possible to rebuild the **Current parameter set** each time the system is switched on via the CAN bus. For this purpose, the master controller first loads the **Default parameter set** by calling the CANopen object `1011h01h` (`restore_all_default_parameters`). Then only the deviating objects are transferred, which is very fast due to the small number of objects. An advantage is that this procedure also works with unparameterised servo

drives, so that commissioning new systems or replacing individual servo drives is unproblematic and the parameterization software MPC ServoCommander is not required for this purpose.

**▲ CAUTION Risk of injury due to incorrectly parameterised servo drive**

An incorrectly parameterised servo drive can cause uncontrolled rotary movements and thus personal injury or damage to property.

Before switching on the power stage for the very first time, make sure that the servo drive contains the desired parameters.

### 3.1.2 Description of objects

#### 3.1.2.1 Object 1011<sub>h</sub>: restore\_default\_parameters

Index	1011 <sub>h</sub>		
Name	restore_parameters		
Type	ARRAY		01 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	restore_all_default_parameters		
Info	--	rw	<del>PBO</del> UINT32
Value	64616F6C <sub>h</sub> („load“), 1 (read access)	--	

The object 1011<sub>h</sub>\_01<sub>h</sub> (restore\_all\_default\_parameters) allows the **Current parameter set** to be set to a defined state. To do this, the **Default parameter set** is copied into the **Current parameter set**. The copying process is triggered when "load" is written in hexadecimal form to this object.

This command is only executed when the output stage is deactivated. Otherwise the SDO error 08 00 00 22h is issued. If the wrong identifier is sent, error 08 00 00 20h is issued. If the object is accessed in read mode, a 1 is returned to indicate that resetting to default values is supported.

### 3.1.2.2 Object 1010<sub>h</sub>: store\_parameters

Index	1010 <sub>h</sub>		
Name	store_parameters		
Type	ARRAY		01 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	save_all_parameters		
Info	--	rw	<del>PBO</del> UINT32
Value	65766173 <sub>h</sub> („save“), 1 (read access)	--	

If the **Default parameter set** is also to be saved as the **Application parameter set**, 1010<sub>h</sub>\_01<sub>h</sub> (save\_all\_parameters must be called in addition.

If the object is written via an SDO, the default behavior is that the SDO is answered immediately. The response therefore does not reflect the end of the saving process. However, the behavior can be changed using object 6510<sub>h</sub>\_F0<sub>h</sub> (compatibility\_control).



## 3.2 Compatibility settings

### 3.2.1 Overview

The object `compatibility_control` has been introduced in order to remain compatible with earlier device series on the one hand, and to be able to carry out changes and corrections compared to the DSP402 and DS301 on the other. In the default parameter set, this object returns 0, that is, compatibility with earlier versions. For new applications, we recommend that you set the defined bits to ensure the highest possible level of compliance with the standards mentioned.

### 3.2.2 Description of objects

#### 3.2.2.1 Object 6510<sub>h</sub>F0<sub>h</sub>: `compatibility_control`

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	F0 <sub>h</sub>		
Name	compatibility_control		
Info	--	rw	<del>PBC</del> UINT16
Value	0...7FFh, see Table		--

Bit	Name	Value	Description
Bit 0	homing_method_scheme*	0001 <sub>h</sub>	The bit has the same meaning as bit 2 and is present for compatibility reasons. If bit 2 is set, this bit is also set and vice versa.
Bit 1	reserved	0002 <sub>h</sub>	The bit is reserved. It must not be set.
Bit 2	homing_method_scheme	0004 <sub>h</sub>	If this bit is set, the homing methods 32... 35 are numbered according to DSP402, otherwise the numbering is compatible with earlier implementations (see also section 5.2.3 <i>Homing sequences</i> on page 128). If this bit is set, bit 0 is also set and vice versa.
Bit 3	reserved	0008 <sub>h</sub>	The bit is reserved. It must not be set.
Bit 4	response_after_save	0010 <sub>h</sub>	If this bit is set, the response to <code>save_all_parameters</code> is not sent until saving is complete. This can take several seconds, which may cause a timeout in the PLC. If the bit is cleared, the response is sent immediately, but it must be taken into account that the saving process is not yet complete.
Bit 5	reserved	0020 <sub>h</sub>	The bit is reserved. It must not be set.

Bit	Name	Value	Description
Bit 6	homing_to_zero	0040 <sub>h</sub>	<p>When using CANopen, the homing run consists of only 2 phases (search run and crawl run). The drive does NOT move to the determined zero position (which may be shifted to the found reference position, e.g. by the homing_offset).</p> <p>If this bit is set, the option selected in the MPC ServoCommander under <b>Go to zero position after homing</b> is used. In addition, the value given under <b>max. homing distance permitted</b> is used for the maximum search distance of the reference run.</p> <p>See section 5.2 <i>Homing Mode</i> on page 124.</p>
Bit 7	device_control	0080 <sub>h</sub>	<p>If this bit is set, bit 4 of the <b>statusword</b> (voltage_enabled) is output according to DSP 402 v2.0. In addition, the FAULT_REACTION_ACTIVE state can be distinguished from the FAULT state. See section 4 <i>Device Control</i> on page 102.</p>
Bit 8	reserved	0100 <sub>h</sub>	The bit is reserved. It must not be set.
Bit 9	uzk_preload_ready	0200 <sub>h</sub>	<p>If this bit is set, a set bit 4 (voltage_enabled) in the <b>statusword</b> indicates that the DC link is fully loaded. If this bit is cleared, bit 4 indicates that the output stage is switched on. See section 4 <i>Device Control</i> on page 102.</p>
Bit 10	home_offset_sign	0400 <sub>h</sub>	<p>If this bit is set, the <b>home_offset</b>(607C<sub>h</sub>) is subtracted from the reference position instead of added, so that the drive is at the <b>home_offset</b> position (instead of <b>-home_offset</b>) after the reference run.</p>


## 3.3 Factor Group

### 3.3.1 Overview

Usually, the values transmitted via the CAN bus are converted by the controller in such a way that they match the application used. If this is not the case, the scaling of the values transmitted on the bus can be adjusted directly using the **Factor Group**.

This may also be necessary if the resolution of the values transmitted on the bus is not sufficient, e.g. because the standard settings only allow a differentiation of  $\pm 32768$  revolutions.

The servo drive converts the read or written values into its internal units with the help of the **Factor Group**. For each physical quantity (position, velocity and acceleration) a conversion factor is available to adapt the user units to the own application. The units set by the **Factor Group** are generally referred to as `position_unit`, `speed_unit` or `acceleration_unit`. The following figure illustrates the function of the **Factor Group**:



All parameters in the servo drive are always stored in internal units and are only converted by means of the **Factor Group** when writing or reading.

**For this reason, the **Factor Group** should be set before the very first parameterisation and should not be changed afterwards.**

By default, the Factor Group is set to the following units:

Quantity	Designation	Unit	Description
Length	position_unit	Increments	65536 increments per revolution
Speed	speed_unit	min <sup>-1</sup>	Revolution per minute
Acceleration	acceleration_unit	(min <sup>-1</sup> )/s	Speed increase in revolutions per minute per second

### 3.3.2 Parameterisation of the Factor Group

The Factor Group can be conveniently set via the MPC ServoCommander:

Parameters/Field bus/CANopen/Display units or  
Parameters/Feld bus/Ethercat/Display units




Figure 5: "CANopen Factor Group" window

Under **Settings/Physical Units** the desired unit for the position values (**Position**), **Speed** and **Acceleration** can be selected separately. In addition, the desired number of decimal places (**Decimals**) and a gear (**Gearbox**) can be included.

If a length unit is selected as the position unit, the **Feed constant** can also be specified.

The results of the setting selected in this way are displayed under **Calculated Factor Group** and can be transferred to the servo drive by clicking the **Apply Factor Group** button.

### 3.3.3 Description of objects

#### 3.3.3.1 Object 6093<sub>h</sub>: position\_factor

The object **position\_factor** is used to convert all length units of the application from **position\_unit** to the internal unit **increments** (65536 increments correspond to 1 revolution). It consists of numerator and denominator. The **position\_factor** must not be greater than  $2^{24}$ .

Index	6093 <sub>h</sub>			
Name	position_factor			
Type	ARRAY			02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	numerator			
Info	--	rw	PDO	UINT32
Value	--	1		
Sub-Index	02 <sub>h</sub>			
Name	divisor			
Info	--	rw	PDO	UINT32
Value	--	1		

#### 3.3.3.2 Object 6094<sub>h</sub>: velocity\_encoder\_factor

The object **velocity\_encoder\_factor** is used to convert all velocity values of the application from **speed\_unit** to the internal unit **revolutions per 4096 minutes**. It consists of numerator and denominator.

Index	6094 <sub>h</sub>			
Name	velocity_encoder_factor			
Type	ARRAY			02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	numerator			
Info	--	rw	PDO	UINT32
Value	--	1000 <sub>h</sub>		
Sub-Index	02 <sub>h</sub>			
Name	divisor			
Info	--	rw	PDO	UINT32
Value	--	1		

### 3.3.3.3 Object 6097<sub>h</sub>: acceleration\_factor

The object **acceleration\_factor** is used to convert all acceleration values of the application from **acceleration\_unit** to the internal unit **revolutions per minute per 256 seconds**. It consists of numerator and denominator.

Index	6097 <sub>h</sub>			
Name	acceleration_factor			
Type	ARRAY			02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	numerator			
Info	--	rw	PDO	UINT32
Value	--	100 <sub>h</sub>		
Sub-Index	02 <sub>h</sub>			
Name	divisor			
Info	--	rw	PDO	UINT32
Value	--	1		

### 3.3.3.4 Object 607E<sub>h</sub>: polarity

The sign of the position and velocity values of the servo drive can be set with the **polarity** object. This can be used to invert the direction of rotation of the motor with identical setpoints.

In most applications it is useful to set the **position\_polarity\_flag** and the **velocity\_polarity\_flag** to the same value.

Setting the **position\_polarity\_flag** or the **velocity\_polarity\_flag** only affects parameters during reading and writing. Parameters already present in the servo drive are not changed.

Index	607E <sub>h</sub>			
Name	polarity			
Info	--	rw	PDO	UINT8
Value	0, 40 <sub>h</sub> , 80 <sub>h</sub> , C0 <sub>h</sub>			--

Bit	Value	Name	Description
6	40 <sub>h</sub>	velocity_polarity_flag	0: multiply by 1 (default) 1: multiply by -1 (invers)
7	80 <sub>h</sub>	position_polarity_flag	0: multiply by 1 (default) 1: multiply by -1 (invers)

## 3.4 Power stage parameters

### 3.4.1 Overview

The DC link is supplied with mains voltage via a pre-charging circuit. This limits the current and controls the charging process. The precharge control is bypassed when the DC link is fully charged. This state is a condition for enabling the servo drive. The rectified mains voltage is smoothed with the capacitors of the DC link. The motor is supplied from the DC link via the IGBTs.

The output stage contains a number of monitoring functions, some of which can be parameterised:

- Controller enable logic (software- and hardware enable)
- Overvoltage / undervoltage monitoring of the DC link
- Overcurrent monitoring
- Power section monitoring

### 3.4.2 Description of objects

#### 3.4.2.1 Object 6510<sub>h\_10\_h</sub>: enable\_logic

To enable the power stage of the servo drive, the digital input **Controller enable** must be set: The **Controller enable** is processed by the microcontroller of the servo drive. Depending on the operating mode, the servo drive reacts differently after this signal is disabled:

#### ➤ Positioning mode and speed-controlled operation

After resetting the signal, the motor is braked with a defined braking ramp. The output stage is only switched off when the motor speed is below 10 min<sup>-1</sup> and the holding brake, if present, has been applied.

#### ➤ Torque-controlled operation

The output stage is switched off immediately after the signal is reset. At the same time a possibly existing holding brake is applied. The motor coasts down unbraked or is only stopped by a possibly existing holding brake.

**⚠ DANGER** ⚠ **Danger to life due to electric shock!**

Removing the **Controller enable** does not guarantee that the motor is voltage-free.

When operating the servo drive via CAN or EtherCAT, the digital input **Controller enable** can be connected to 24V and the enable controlled via the bus. To do this, object **6510<sub>h</sub>\_10<sub>h</sub>** (**enable\_logic**) must be set to 2 (for CAN) or 8 (for EtherCAT). For safety reasons, this is done automatically when the fieldbus is activated (even after a reset of the servo drive).

Index	<b>6510<sub>h</sub></b>		
Name	<b>drive_data</b>		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	<b>10<sub>h</sub></b>		
Name	<b>enable_logic</b>		
Info	--	rw	<del>PBC</del> UINT16
Value	0...18 <sub>h</sub>	--	

Value	Description
0	Digital Input DIN5
1 <sub>h</sub>	DIN5 + Parameterisation interface
2 <sub>h</sub>	DIN5 + CAN
3 <sub>h</sub>	DIN5 + PROFIBUS/PROFINET
8 <sub>h</sub>	DIN5 + EtherCAT
11 <sub>h</sub>	Parameterisation interface only
12 <sub>h</sub>	CAN bus only
13 <sub>h</sub>	PROFIBUS/PROFINET only
18 <sub>h</sub>	EtherCAT only

### 3.4.2.2 Object 6510<sub>h</sub>\_30<sub>h</sub>: pwm\_frequency

The switching losses of the output stage are proportional to the switching frequency of the power transistors. Some servo drives can draw a little more power by halving the normal PWM frequency. However, this increases the current ripple caused by the output stage. Switching is only possible when the output stage is switched off.

Index	<b>6510<sub>h</sub></b>		
Name	<b>drive_data</b>		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	<b>30<sub>h</sub></b>		
Name	<b>pwm_frequency</b>		
Info	--	rw	<del>PBC</del> UINT16
Value	0, 1	0	

Value	Description
0	Standard power stage frequency
1	Half power stage frequency



### 3.4.2.3 Object 6510<sub>h</sub>\_3A<sub>h</sub>: enable\_enhanced\_modulation

With the object `enable_enhanced_modulation` the enhanced sine modulation can be activated. It allows for a better utilization of the DC bus voltage and thus about 14% higher speeds. The disadvantage is that the control behavior and the smooth running of the motor is slightly worse at very low speeds. The parameter may only be changed with the power stage switched off and only becomes effective after a reset. To do this, the parameter set must first be saved (`save_all_parameters`).

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	3A <sub>h</sub>		
Name	enable_enhanced_modulation		
Info	--	rw	PDO UINT16
Value	0, 1	0	

Value	Description
0	Enhanced sine modulation OFF
1	Enhanced sine modulation ON

### 3.4.2.4 Object 6510<sub>h</sub>\_31<sub>h</sub>: power\_stage\_temperature

The temperature of the power stage can be read out via the object `power_stage_temperature`. If the temperature specified in object 6510<sub>h</sub>\_32<sub>h</sub> (`max_power_stage_temperature`) is exceeded, the power stage switches off and an error message is issued.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	31 <sub>h</sub>		
Name	power_stage_temperature		
Info	°C	ro	PDO INT16
Value	--	--	

### 3.4.2.5 Object 6510<sub>h</sub>\_32<sub>h</sub>: max\_power\_stage\_temperature

The temperature of the power stage can be read out via the object 6510<sub>h</sub>\_31<sub>h</sub> (`power_stage_temperature`). If the temperature specified in object `max_power_stage_temperature` is exceeded, the power stage switches off and an error message is issued.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	32 <sub>h</sub>		
Name	max_power_stage_temperature		
Info	°C	ro	<del>PBC</del> INT16
Value	--	--	

Device type	Value
BL 4102-C	85°C
BL 4104-C	85°C
BL 4304-C	90°C
BL 4308-C	85°C
BL 4312-C	75°C

### 3.4.2.6 Object 6510<sub>h</sub>\_33<sub>h</sub>: nominal\_dc\_link\_circuit\_voltage

Via the object `nominal_dc_link_circuit_voltage` the device nominal voltage can be read out in millivolts.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	33 <sub>h</sub>		
Name	nominal_dc_link_circuit_voltage		
Info	mV	ro	<del>PBC</del> UINT32
Value	--	--	

Device type	Value
BL 4102-C	325000
BL 4104-C	325000
BL 4304-C	560000
BL 4308-C	560000
BL 4312-C	560000

### 3.4.2.7 Object 6510<sub>h</sub>34<sub>h</sub>: actual\_dc\_link\_circuit\_voltage

The object **actual\_dc\_link\_circuit\_voltage** can be used to read the current voltage of the DC link in millivolts.

Index	6510 <sub>h</sub>			
Name	drive_data			
Type	RECORD	F0 <sub>h</sub>		
Sub-Index	34 <sub>h</sub>			
Name	actual_dc_link_circuit_voltage			
Info	mV	ro	PDO	UINT32
Value	--	--		

### 3.4.2.8 Object 6510<sub>h</sub>35<sub>h</sub>: max\_dc\_link\_circuit\_voltage

The object **max\_dc\_link\_circuit\_voltage** specifies the DC link voltage at which the output stage is immediately switched off for safety reasons and an error message is sent.

Index	6510 <sub>h</sub>			
Name	drive_data			
Type	RECORD	F0 <sub>h</sub>		
Sub-Index	35 <sub>h</sub>			
Name	max_dc_link_circuit_voltage			
Info	mV	ro	<del>PDO</del>	UINT32
Value	--	--		

Device type	Value
BL 4102-C	439979
BL 4104-C	439979
BL 4304-C	799976
BL 4308-C	799976
BL 4312-C	799976

### 3.4.2.9 Object 6510<sub>h</sub>36<sub>h</sub>: min\_dc\_link\_circuit\_voltage

The servo drive has an undervoltage monitor. This can be activated via object 6510<sub>h</sub>37<sub>h</sub> (enable\_dc\_link\_undervoltage\_error). Object 6510<sub>h</sub>36<sub>h</sub> (min\_dc\_link\_circuit\_voltage) specifies the minimum DC link voltage. Below this voltage, error E 02-0 is raised.

Index	6410 <sub>h</sub>		
Name	motor_data		
Type	RECORD		14 <sub>h</sub>
Sub-Index	36 <sub>h</sub>		
Name	min_dc_link_circuit_voltage		
Info	mV	rw	<del>PBC</del> UINT32
Value	0...1000000	--	

### 3.4.2.10 Object 6510<sub>h</sub>37<sub>h</sub>: enable\_dc\_link\_undervoltage\_error

The undervoltage monitoring can be activated with the object enable\_dc\_link\_undervoltage\_error. The undervoltage monitoring can be activated with the object enable\_dc\_link\_undervoltage\_error. Object 6510<sub>h</sub>36<sub>h</sub> (min\_dc\_link\_circuit\_voltage) defines the DC link voltage below which an error is raised.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	37 <sub>h</sub>		
Name	enable_dc_link_undervoltage_error		
Info	--	rw	<del>PBC</del> UINT16
Value	0, 1	0	

Value	Description
0	Undervoltage error OFF (reaction <b>Warning</b> )
1	Undervoltage error ON (reaction <b>Disable servo drive</b> )

If this object is written, the error reaction of error 02-0 is modified. If 0 is written, the error reaction **Warning** is set. If 1 is written, the error reaction **Disable servo drive** is set. If the object is read, the reaction **Disable servo drive** or higher is reported as 1, all other error reactions as 0. See also section 3.18 *Error management* on page 100.

### 3.4.2.11 Object 6510<sub>h</sub>\_40<sub>h</sub>: nominal\_current

The **nominal\_current** object can be used to read the nominal device current. This is the upper limit value which can be written into the object 6075<sub>h</sub> (**motor\_rated\_current**). Due to a power derating, different values may be read depending on the servo drive cycle time and the power stage clock frequency.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	40 <sub>h</sub>		
Name	nominal_current		
Info	mA	ro	DDC UINT32
Value	--	see Table	

Device type	Value
BL 4102-C	2000
BL 4104-C	4000
BL 4304-C	4000
BL 4308-C	8000
BL 4312-C	12000

### 3.4.2.12 Object 6510<sub>h</sub>\_41<sub>h</sub>: peak\_current

The **peak\_current** object can be used to read the maximum device current. This is the upper limit value which can be written into the object 6073<sub>h</sub> (**max\_current**). Due to a power derating, different values may be read depending on the servo drive cycle time and the power stage clock frequency.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	41 <sub>h</sub>		
Name	peak_current		
Info	mA	ro	DDC UINT32
Value	--	see Table	

Device type	Value
BL 4102-C	6400
BL 4104-C	12800
BL 4304-C	12000
BL 4308-C	24000
BL 4312-C	30000

## 3.5 Current controller and motor adaption

**NOTICE** Damage to property due to incorrect settings

Incorrect settings of the current controller parameters and the current limits can destroy the motor and possibly also the servo drive within a very short time.

### 3.5.1 Overview

**CAUTION** Danger of injury due to dangerous movements

If the phase order of the motor or angle encoder cable is twisted, positive feedback may occur, which means that the speed in the motor cannot be controlled. The motor can rotate uncontrolled.

The parameter set of the servo drive must be adapted for the connected motor and the cable set used. The following parameters are affected:

- Rated current (depending on the motor)
- Overload capacity (depending on the motor)
- Number of poles (depending on the motor)
- Current controller (depending on the motor)
- Direction of rotation (depending on the motor and the phase sequence in the motor and angle encoder cable)
- Offset angle (depending on motor and phase sequence in motor and angle encoder cable)

These data must be determined with the program MPC ServoCommander when a motor type is used for the first time. For a number of motors you can also obtain ready-made parameter sets from your dealer. Please note that the direction of rotation and offset angle also depend on the cable set used. The parameter sets therefore only work with identical wiring.

### 3.5.2 Description of objects

#### 3.5.2.1 Object 6075<sub>h</sub>: motor<sub>rated</sub>\_current

This value can be taken from the motor nameplate and is entered as an effective value (RMS) in the unit milliamperere. No current can be entered which is above the servo drive rated current (6510<sub>h</sub>\_40<sub>h</sub>, nominal<sub>current</sub>).

Index	6075 <sub>h</sub>			
Name	motor <sub>rated</sub> _current			
Info	mA	rw	PDO	UINT32
Value	0...nominal <sub>current</sub>	--		

**INFORMATION** Objects not independent

If object 6075<sub>h</sub> (`motorRatedCurrent`) is written with a new value, object 6073<sub>h</sub> (`maxCurrent`) must also be reparameterised in any case.

### 3.5.2.2 Object 6073<sub>h</sub>: `maxCurrent`

Servo motors may normally be overloaded for a certain period of time. This object is used to set the maximum permissible motor current. It refers to the rated motor current (Object 6075<sub>h</sub>, `motorRatedCurrent`) and is set in thousandths. The value range is limited upwards by the maximum servo drive current (Object 6510<sub>h\_41</sub>, `peakCurrent`). Many motors can be overloaded by a factor of 2 for a short time. In this case, the value 2000 must be written into this object. Object 6073<sub>h</sub> (`maxCurrent`) may only be written to after Object 6075<sub>h</sub> (`motorRatedCurrent`) has previously been written with a valid value.

Index	6073 <sub>h</sub>			
Name	maxCurrent			
Info	‰ (1000 = motorRatedCurrent)	rw	PDO	UINT16
Value	--	--	--	--

### 3.5.2.3 Object 604D<sub>h</sub>: `poleNumber`

The number of poles of the motor can be taken from the motor data sheet or the parameterization program MPC ServoCommander. The number of poles is always even. Often the number of pole pairs is given instead of the number of poles. In this case, the number of poles is twice the number of pole pairs. This object is not changed by `restoreDefaultParameters`, but it can be reset by selecting **File / Parameter set / Load default servo parameter set**.

Index	604D <sub>h</sub>			
Name	poleNumber			
Info	--	rw	PDO	UINT8
Value	2...254	--	--	--

### 3.5.2.4 Object 6410<sub>h\_11</sub>: `encoderOffsetAngle`

The servo motors used have permanent magnets on the rotor. These generate a magnetic field whose orientation to the stator depends on the rotor position. For electronic commutation, the servo drive must always adjust the electromagnetic field of the stator at the correct angle to this permanent magnetic field. To do this, it continuously determines the rotor position with an angle encoder (resolver etc.).

The orientation of the angle encoder to the permanent magnetic field must be entered in the object `encoderOffsetAngle`. This angle can be determined with the parameterisation program MPC ServoCommander (**Parameters / Device parameters / Encoder / Settings**).

The angle determined with the MPC ServoCommander is in the range of ±180°. It must be converted as follows:

$$\text{encoderOffsetAngle} = \text{Offset of encoder} \times 32767 / 180^\circ$$

This object is not changed by `restore_default_parameters`, but it can be reset by selecting **File / Parameter set / Load default servo parameter set**.

Index	6410 <sub>h</sub>			
Name	motor_data			
Type	RECORD			14 <sub>h</sub>
Sub-Index	11 <sub>h</sub>			
Name	encoder_offset_angle			
Info	180° / 32767	rw	PDO	INT16
Value	--	--		

### 3.5.2.5 Object 6410<sub>h</sub>\_10<sub>h</sub>: phase\_order

The `phase_order` object considers twists between motor cable and angle encoder cable. It can be taken from the parameterisation program MPC ServoCommander. This object is not changed by `restore_default_parameters`, but it can be reset by selecting **File / Parameter set / Load default servo parameter set**

Index	6410 <sub>h</sub>			
Name	motor_data			
Type	RECORD			14 <sub>h</sub>
Sub-Index	10 <sub>h</sub>			
Name	phase_order			
Info	--	rw	<del>PDO</del>	UINT16
Value	0, 1	0		

Value	Description
0	Right
1	Left



### 3.5.2.6 Object 6410<sub>h</sub>\_03<sub>h</sub>: iit\_time\_motor

Servo motors may normally be overloaded for a certain period of time. This object is used to specify how long the connected motor may be operated with the current specified in object 6073<sub>h</sub> (*max\_current*). After the I<sup>2</sup>t time has expired, the current is automatically limited to the value specified in object 6075<sub>h</sub> (*motor\_rated\_current*) to protect the motor. The default setting is two seconds and is applicable for most motors.

Index	6410 <sub>h</sub>		
Name	motor_data		
Type	RECORD	14 <sub>h</sub>	
Sub-Index	03 <sub>h</sub>		
Name	iit_time_motor		
Info	ms	rw	<del>PDO</del> UINT16
Value	0...10000	--	

### 3.5.2.7 Object 6410<sub>h</sub>\_04<sub>h</sub>: iit\_ratio\_motor

The object *iit\_ratio\_motor* can be used to read the current I<sup>2</sup>t limitation of the motor in per mille.

Index	6410 <sub>h</sub>		
Name	motor_data		
Type	RECORD	14 <sub>h</sub>	
Sub-Index	04 <sub>h</sub>		
Name	iit_ratio_motor		
Info	‰	ro	<del>PDO</del> UINT16
Value	--	--	

### 3.5.2.8 Object 6510<sub>h</sub>\_3D<sub>h</sub>: iit\_ratio\_servo

The object *iit\_ratio\_servo* can be used to read the current I<sup>2</sup>t limitation of the power stage in per mille.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	3D <sub>h</sub>		
Name	iit_ratio_servo		
Info	‰	ro	PDO UINT16
Value	--	--	

### 3.5.2.9 Object 6510<sub>h</sub>\_38<sub>h</sub>: iit\_error\_enable

The object `iit_error_enable` defines how the servo drive behaves when the I<sup>2</sup>t limitation occurs. Either this is only indicated in the `statusword`, or error E 31-0 is raised.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	38 <sub>h</sub>		
Name	iit_error_enable		
Info	--	rw	<del>PDO</del> UINT16
Value	0, 1	0	

Value	Description
0	I <sup>2</sup> t error OFF (Reaction <b>Warning</b> )
1	I <sup>2</sup> t error ON (Reaction <b>Disable Servo Drive</b> )

If this object is written, the error reaction of error 31-0 is modified. If 0 is written, the error reaction **Warning** is set. If 1 is written, the error reaction **Disable servo drive** is set. If the object is read, the reaction **Disable servo drive** or higher is reported as 1, all other error reactions as 0. See section 3.18 *Error management* on page 100.

### 3.5.2.10 Object 6510<sub>h</sub>\_2E<sub>h</sub>: motor\_temperature

This object can be used to read out the current motor temperature if an analog temperature sensor is connected. Otherwise, the value of the object is undefined.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	2E <sub>h</sub>		
Name	motor_temperature		
Info	°C	ro	PDO INT16
Value	--	--	

### 3.5.2.11 Object 6410<sub>h</sub>\_14<sub>h</sub>: motor\_temperature\_sensor\_polarity

This object can be used to define whether a normally closed contact or a normally open contact is used as a digital motor temperature sensor.

Index	6410 <sub>h</sub>		
Name	motor_data		
Type	RECORD	14 <sub>h</sub>	
Sub-Index	14 <sub>h</sub>		
Name	motor_temperature_sensor_polarity		
Info	--	rw	PDO INT16
Value	0, 1	0	

Value	Description
0	Normally closed contact
1	Normally open contact

### 3.5.2.12 Object 6510<sub>h</sub>\_2F<sub>h</sub>: max\_motor\_temperature

If the motor temperature defined in this object is exceeded, the reaction as set in the error management (error E 03-0, motor overtemperature analog) is executed. If a reaction is parameterised which leads to the drive being switched off, an emergency message is sent. For parameterisation of the error management, see section 3.18 *Error management* on page 100.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	2F <sub>h</sub>		
Name	max_motor_temperature		
Info	°C	rw	<del>PDO</del> INT16
Value	20...300	--	

### 3.5.2.13 Object 60F6<sub>h</sub>: torque\_control\_parameters

The data of the current controller must be taken from the parameterisation program MPC ServoCommander. The following conversions must be observed:

The gain of the current controller must be multiplied by 256. For a gain of 1.5 in the "Current controller" menu of the parameterisation program MPC ServoCommander, the value  $384 = 180_{10}$  must be written into the `torque_control_gain` object.

The time constant of the current controller is specified in milliseconds in the parameterisation program MPC ServoCommander. In order to be able to transfer this time constant into the `torque_control_time` object, it must first be converted into microseconds. For a specified time of 0.6 milliseconds, the value 600 must be entered into the `torque_control_time` object accordingly. The lower limit must not be smaller than the current cycle time of the current controller (see section 3.17.1.12 *Object 6510h\_B0h: cycletime\_current\_controller* on page 97).

Index	60F6 <sub>h</sub>		
Name	torque_control_parameters		
Type	RECORD		02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	torque_control_gain		
Info	256 = „1“	rw	<del>PBO</del> UINT16
Value	0...(32*256)	--	
Sub-Index	02 <sub>h</sub>		
Name	torque_control_time		
Info	µs	rw	<del>PBO</del> UINT16
Value	104...64401	--	

### 3.5.2.14 Object 203A<sub>h</sub>: torque\_feed\_forward

Specifies the current feedforward factor. This is parameterised in  $10^{-7}$  A per set acceleration. This allows an acceleration profile set via CANopen to be run and the current during acceleration to be recorded. The quotient of current and acceleration can then be written directly to this object.

Index	203A <sub>h</sub>		
Name	torque_feed_forward		
Info	A / (rev/min/s)	rw	<del>PBO</del> UINT32
Value	0...208	--	

## 3.6 Velocity controller

### 3.6.1 Overview

#### **NOTICE** Damage to property due to incorrect settings

Incorrect settings of the controller parameters can lead to strong vibrations and possibly destroy parts of the machine.

The parameter set of the servo drive must be adapted for the application. Especially the gain is highly dependent on any masses coupled to the motor. The data must be optimally determined during commissioning of the system using the MPC ServoCommander parameterisation program.

### 3.6.2 Description of objects

#### 3.6.2.1 Object 60F9<sub>h</sub>: velocity\_control\_parameters

The data of the speed controller can be taken from the parameterisation program MPC ServoCommander. The following conversions must be observed:

The gain of the speed controller must be multiplied by 256. For a gain of 1.5 in the "Speed controller" menu of the parameterisation program, the value 384 = 180<sub>h</sub> must be written into the velocity\_control\_gain object.

The time constant of the speed controller is given in milliseconds in the parameterisation program. In order to be able to transfer this time constant into the object **velocity\_control\_time**, it must first be converted into microseconds. For a given time of 2.0 milliseconds, the value 2000 must be entered into the object **velocity\_control\_time** accordingly. The same applies to the object **velocity\_control\_filter\_time**, with which the actual speed value filter is parameterised.

Index	60F9 <sub>h</sub>		
Name	velocity_control_parameter_set		
Type	RECORD		04 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	velocity_control_gain		
Info	256 = „1“	rw	<del>PBC</del> UINT16
Value	20...(64*256)	--	
Sub-Index	02 <sub>h</sub>		
Name	velocity_control_time		
Info	µs	rw	<del>PBC</del> UINT16
Value	1...32000	--	

Sub-Index	04 <sub>h</sub>		
Name	velocity_control_filter_time		
Info	µs	rw	<del>PBO</del> UINT16
Value	1...32000	--	

### 3.6.2.2 Object 2073<sub>h</sub>: velocity\_display\_filter\_time

The **velocity\_display\_filter\_time** object can be used to set the filter time of the speed actual value filter, which filters the actual value for display.

Index	2073 <sub>h</sub>		
Name	velocity_display_filter_time		
Info	µs	rw	<del>PBO</del> UINT32
Value	1000...50000	--	

**INFORMATION** Object is also used for overspeed-protection

Note that the object **velocity\_actual\_value\_filtered** is used for the overspeed-protection. If the filter time is very long, a overspeed error is only detected after a respective delay.

## 3.7 Position Controller

### 3.7.1 Overview

This chapter describes all parameters required for the position controller. The position setpoint (`position_demand_value`) from the trajectory generator is applied to the input of the position controller. In addition, the actual position value (`position_actual_value`) is supplied by the angle encoder (resolver, incremental encoder etc.). The behavior of the position controller can be influenced by parameters. To keep the position control loop stable, a limitation of the output variable (`control_effort`) is possible. The output variable is fed into the speed controller as a speed setpoint value. All input and output variables of the position controller are converted by the Factor Group from the application-specific units into the respective internal units of the servo drive.

#### › Following error

The `following_error_actual_value` is the deviation of the actual position value (`position_actual_value`) from the position setpoint (`position_demand_value`). If this following error is larger than specified in the `following_error_window` for a certain period of time, bit 13 `following_error` is set in the `statusword` object. The permissible time period can be specified via the object `following_error_time_out`.




Figure 6: Following error – function overview

Figure 6 "Following error". It is monitored whether the difference between target position (`position_demand_value`) and actual position (`position_actual_value`) leaves the symmetrical `following_error_window`. If the position difference does not return to the window within a certain period of time (`following_error_time_out`), bit 13 in the `statusword` is set.

### › Position reached (Target reached)

This function offers the possibility to define a position window around the **target position**. If the actual position of the drive is within this range for a certain time - the **position\_window\_time** - the associated bit 10 (**target\_reached**) is set in the **statusword**.




Figure 7: Position reached - function overview

Figure 7. It is monitored whether the actual position (**position\_actual\_value**) is within the symmetrical target position window (**target\_position+position\_window, target\_position-position\_window**). If the actual position remains in the target window longer than the waiting time (**target\_window\_time**) and the positioning is completed, bit 10 in the **statusword** is set.

## 3.7.2 Description of objects

### 3.7.2.1 Object 60FB<sub>n</sub>: position\_control\_parameter\_set

The parameter set of the servo drive must be adapted for the application. The data of the position controller must be optimally determined with the aid of the program MPC ServoCommander when the machine is commissioned.

**NOTICE** Damage to property due to incorrect settings

Incorrect settings of the controller parameters can lead to strong vibrations and possibly destroy parts of the machine.

The position controller compares the setpoint position with the actual position and forms a correction speed (object 60FA<sub>n</sub>: **control\_effort**) from the difference - taking into account the gain and possibly the integrator - which is fed to the speed controller. The position controller is relatively slow compared to the current and speed controller. Therefore, the servo drive works internally with feedforward controls, so that the correction work for the position controller is minimised and the servo drive is quickly in the steady state. A proportional element is normally sufficient as position controller.



The position controller data can be taken from the parameterization program MPC ServoCommander. The following conversions must be observed: The gain of the position controller must be multiplied by 256. For a gain of 1.5 in the **Position Controller** window of the parameterization program, the value 384 must be written into the object **position\_control\_gain**.

Normally the position controller does not need an integrator. In this case, the value zero must be entered in the object **position\_control\_time**. Otherwise, the time constant of the position controller must be converted into microseconds. For a time of 4.0 milliseconds, the value 4000 must be entered in the object **position\_control\_time** accordingly. Since the position controller converts even the smallest position deviations into significant correction speeds, in the event of a brief malfunction (e.g. brief clamping of the system), this would result in very violent control reactions with very high correction speeds. This can be avoided if the output of the position controller is limited sensibly (e.g. 500 min<sup>-1</sup>) via the object **position\_control\_v\_max**.

The object **position\_error\_tolerance\_window** can be used to define the size of a position deviation up to which the position controller does not act (dead band). This can be used for stabilization purposes, for example, if there is backlash in the system.

Index	<b>60FB<sub>h</sub></b>			
Name	<b>position_control_parameter_set</b>			
Type	RECORD			05 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>			
Name	<b>position_control_gain</b>			
Info	256 = „1“	rw	<del>PBC</del>	UINT16
Value	0...(64*256)	--		
Sub-Index	<b>02<sub>h</sub></b>			
Name	<b>position_control_time</b>			
Info	µs	rw	<del>PBC</del>	UINT16
Value	0	--		
Sub-Index	<b>04<sub>h</sub></b>			
Name	<b>position_control_v_max</b>			
Info	speed_unit	rw	<del>PBC</del>	UINT32
Value	0...131072 min <sup>-1</sup>	--		
Sub-Index	<b>05<sub>h</sub></b>			
Name	<b>position_error_tolerance_window</b>			
Info	position_unit	rw	<del>PBC</del>	UINT32
Value	--	--		

### 3.7.2.2 Object 6062<sub>h</sub>: position\_demand\_value

The current position setpoint can be read out via this object. This is fed into the position controller by the travel curve generator.

Index	<b>6062<sub>h</sub></b>			
Name	<b>position_demand_value</b>			
Info	position_unit	ro	PDO	INT32
Value	--	--		

### 3.7.2.3 Object 202D<sub>h</sub>: position\_demand\_sync\_value

This object can be used to read the position setpoint of the synchronisation encoder. This is defined by object [2022<sub>h</sub> synchronization\\_encoder\\_select](#).

Index	<b>202D<sub>h</sub></b>			
Name	<b>position_demand_sync_value</b>			
Info	position_unit	ro	<del>PDO</del>	INT32
Value	--	--		

### 3.7.2.4 Object 6064<sub>h</sub>: position\_actual\_value

The actual position can be read out via this object. This is fed to the position controller from the angle encoder.

Index	<b>6064<sub>h</sub></b>			
Name	<b>position_actual_value</b>			
Info	position_unit	ro	PDO	INT32
Value	--	--		

### 3.7.2.5 Object 6066<sub>h</sub>: following\_error\_time\_out

If a following error - longer than defined in this object - occurs, the corresponding bit 13 [following\\_error](#) is set in the [statusword](#).

Index	<b>6066<sub>h</sub></b>			
Name	<b>following_error_time_out</b>			
Info	ms	rw	PDO	UINT16
Value	0...27314	--		

### 3.7.2.6 Object 6065<sub>h</sub>: following\_error\_window

The object `following_error_window` defines a symmetrical range around the position setpoint (`position_demand_value`). If the actual position value (`position_actual_value`) is outside the `following_error_window`, then a following error occurs and bit 13 in the `statusword` is set. The reasons below can cause a following error:

- The drive is blocked
- The positioning speed is too high
- The acceleration values are too high
- The object `following_error_window` has a value that is too small
- The position controller is not correctly parameterised

Index	<b>6065<sub>h</sub></b>			
Name	<b>following_error_window</b>			
Info	position_unit	rw	PDO	UINT32
Value	--	--		

### 3.7.2.7 Object 60F4<sub>h</sub>: following\_error\_actual\_value

The current difference between `position_demand_value` (6062<sub>h</sub>) and `position_actual_value` (6064<sub>h</sub>) can be read from this object.

Index	<b>60F4<sub>h</sub></b>			
Name	<b>following_error_actual_value</b>			
Info	position_unit	ro	PDO	INT32
Value	--	--		

### 3.7.2.8 Object 60FA<sub>h</sub>: control\_effort

The output value of the position controller can be read out via this object. This value is fed internally into the speed controller as setpoint value.

Index	<b>60FA<sub>h</sub></b>			
Name	<b>control_effort</b>			
Info	speed_unit	ro	PDO	INT32
Value	--	--		

### 3.7.2.9 Object 6410<sub>h</sub>0F<sub>h</sub>: rotor\_position

The **rotor\_position** can be read out via the object in per mil of one revolution.

Index	6410 <sub>h</sub>			
Name	motor_data			
Type	RECORD	14 <sub>h</sub>		
Sub-Index	0F <sub>h</sub>			
Name	rotor_position			
Info	‰ (1000 = 1 rev)	ro	PDO	UINT16
Value	--	--		

### 3.7.2.10 Object 6067<sub>h</sub>: position\_window

The object **position\_window** defines a symmetrical range around the target position. If the actual position value (**position\_actual\_value**) is within this range for a certain time, the **target position** is considered to be reached.

Index	6067 <sub>h</sub>			
Name	position_window			
Info	position_unit	rw	PDO	UINT32
Value	--	--		

### 3.7.2.11 Object 6068<sub>h</sub>: position\_window\_time

If the actual position of the drive is within the positioning window (**position\_window**) for as long as defined in this object, the corresponding bit 10 **target\_reached** is set in the **statusword**.

Index	6068 <sub>h</sub>			
Name	position_window_time			
Info	ms	rw	PDO	UINT16
Value	--	--		

### 3.7.2.12 Object 6510<sub>h</sub>22<sub>h</sub>: position\_error\_switch\_off\_limit

The maximum permissible deviation between the target and actual position can be entered in the object `position_error_switch_off_limit`. In contrast to the **Following Error** message above, the output stage is switched off immediately if this limit is exceeded and an error is raised. The motor thus coasts down unbraked (unless there is a holding brake).

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	22 <sub>h</sub>		
Name	position_error_switch_off_limit		
Info	position_unit	rw	<del>PBC</del> UINT32
Value	--	--	

Value	Description
0	Switch-off limit following error OFF (Reaction <b>No action</b> )
> 0	Switch-off limit following error ON (Reaction <b>Disable power stage immediately</b> )

If this object is written, the error reaction of error 17-0 is modified. If 0 is written, the error reaction **No action** is set. If a value greater than 0 is written, the error reaction **Disable power stage immediately** is set. If the object is read, the reaction **Disable power stage immediately** is reported as 1, all other error reactions as 0. See also section 3.18 *Error management* on page 100.

### 3.7.2.13 Object 2030<sub>h</sub>: set\_position\_absolute

The object `set_position_absolute` can be used to move the readable actual position without changing the physical position. The drive does not carry out any movement. If an absolute encoder system is connected, the position displacement is stored in the encoder, if the encoder system allows this. In this case, the position offset is therefore retained after a reset. This storage operation runs in the background independently of this object. All parameters belonging to the encoder memory are also stored with their current values.

Index	2030 <sub>h</sub>		
Name	set_position_absolute		
Info	position_unit	wo	<del>PBC</del> INT32
Value	--	--	

### 3.7.2.14 Object 607D<sub>h</sub>: software\_position\_limit

The object array **software\_position\_limit** contains two sub-parameters that limit the maximum positioning range. If the drive leaves this range in **Profile Position Mode**, error 40-0 (Negative SW limit switch reached) or 40-1 (Positive SW limit switch reached) is raised.

Index	<b>607D<sub>h</sub></b>			
Name	<b>software_position_limit</b>			
Type	ARRAY			02 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>			
Name	<b>min_position_limit</b>			
Info	position_unit	rw	PDO	INT32
Value	--	--		
Sub-Index	<b>02<sub>h</sub></b>			
Name	<b>max_position_limit</b>			
Info	position_unit	rw	PDO	INT32
Value	--	--		

### 3.7.2.15 Object 607B<sub>h</sub>: position\_range\_limit

The object array **position\_range\_limit** contains two sub-parameters that limit the numerical range of the position values. If one of these limits is exceeded, the actual position value automatically overflows to the other limit. This enables the parameterisation of so-called rotary axes. The limits that should physically correspond to the same position must be specified, for example 0° and 360°.

To make these limits effective, a rotary axis mode must be selected via **6510<sub>h\_20<sub>h</sub></sub>** (**position\_range\_limit\_enable**).

Index	<b>607B<sub>h</sub></b>			
Name	<b>position_range_limit</b>			
Type	ARRAY			02 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>			
Name	<b>min_position_range_limit</b>			
Info	position_unit	rw	PDO	INT32
Value	--	--		
Sub-Index	<b>02<sub>h</sub></b>			
Name	<b>max_position_range_limit</b>			
Info	position_unit	rw	PDO	INT32
Value	--	--		

### 3.7.2.16 Object 6510<sub>h</sub>20<sub>h</sub>: position\_range\_limit\_enable

Via the object **position\_range\_limit\_enable** the range limits defined by the object 607B<sub>h</sub> can be activated. Different modes are possible:

If the mode "Shortest distance" is selected, positioning is always carried out on the physically shorter distance to the target. The drive itself adjusts the sign of the travel speed for this purpose. In the two modes with fixed direction of rotation, positioning is always carried out only in the direction specified in the mode.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	20 <sub>h</sub>		
Name	position_range_limit_enable		
Info	--	rw	<del>PBO</del> UINT16
Value	0...5	--	

Value	Description
0	Off
1	Shortest distance (for compatibility reasons)
2	Shortest distance
3	Reserved
4	Direction always „positive“
5	Direction always „negative“

## 3.8 Setpoint limitation

### 3.8.1 Object 2415<sub>h</sub>: current\_limitation

The **current\_limitation** object record can be used to limit the maximum current for the motor in the **Profile Position Mode**, **Interpolated Position Mode**, **Cyclic Synchronous Position Mode**, **Homing Mode** and **Profile Velocity Mode**, thus allowing torque-limited speed operation, for example. The **limit\_current\_input\_channel** object is used to specify the source of the limiting torque setpoint. Here you can choose between setting a direct setpoint (fixed value) or using an analogue input. The **limit\_current** object is used to specify either the limiting torque (source = fixed value) or the scaling factor for the analogue inputs (source = AINx), depending on the selected source. In the first case, the current is directly limited to the torque-proportional fixed value in mA, in the second case the current in mA is specified, which should correspond to an applied voltage of 10V.

Index	2415 <sub>h</sub>			
Name	current_limitation			
Type	RECORD	02 <sub>h</sub>		
Sub-Index	01 <sub>h</sub>			
Name	limit_current_input_channel			
Info	--	rw	PDO	INT8
Value	0...4	0		
Sub-Index	02 <sub>h</sub>			
Name	limit_current			
Info	mA	rw	PDO	INT32
Value	--	--		

Value	Description
0	No limit
1	AIN0
2	AIN1
3	AIN2
4	Fixed value / fieldbus (fieldbus selector 2)



### 3.8.2 Object 2416<sub>h</sub>: speed\_limitation

The **speed\_limitation** object group can be used to limit the maximum speed of the motor in **Profile Torque Mode**, thus allowing speed-limited torque operation.

The **limit\_speed\_input\_channel** object is used to specify the setpoint source of the limiting speed. Here you can choose between setting a direct setpoint (fixed value) or using an analogue input. The **limit\_speed** object is used to specify either the limiting speed (source = fixed value) or the scaling factor for the analog inputs (source = AINx), depending on the selected source. In the first case, the speed is directly limited to the fixed value, in the second case the speed is specified, which should correspond to an applied voltage of 10V.

Index	2416 <sub>h</sub>		
Name	speed_limitation		
Type	RECORD		02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	limit_speed_input_channel		
Info	--	rw	<del>PBO</del> INT8
Value	0...4	0	
Sub-Index	02 <sub>h</sub>		
Name	limit_speed		
Info	speed_unit	rw	<del>PBO</del> INT32
Value	--	--	

Value	Description
0	No limit
1	AIN0
2	AIN1
3	AIN2
4	Fixed value / fieldbus (fieldbus selector 2)

## 3.9 Encoder adaptation

### 3.9.1 Overview

This chapter describes the configuration of the angle encoder input X2A, X2B and the master frequency input (BL 4000-C, BL 4000-M / BL 4000-D: X1).

**NOTICE** Damage to property due to incorrect angle encoder settings

Incorrect angle encoder settings can cause the drive to rotate uncontrollably and possibly destroy parts of the machine.

### 3.9.2 Description of objects

#### 3.9.2.1 Object 2024<sub>h</sub>: encoder\_x2a\_data\_field

The object record `encoder_x2a_data_field` contains parameters that are necessary for the operation of the angle encoder at connector X2A.

Since many encoder settings are only effective after a reset, the selection and setting of the encoders should be done via the MPC ServoCommander. The following settings can be read or changed via CANopen:

The object `encoder_x2a_resolution` specifies how many increments are generated by the encoder per revolution or length unit. Since only resolvers can be connected to input X2A, which are always evaluated with 16 bits, 65536 is always returned here. The objects `encoder_x2a_numerator` and `encoder_x2a_divisor` can be used to take into account a possible gear (also with sign) between motor shaft and encoder.

Index	2024 <sub>h</sub>			
Name	encoder_x2a_data_field			
Type	RECORD			03 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	encoder_x2a_resolution			
Info	Increments (4 * line count)	ro	<del>PBO</del>	UINT32
Value	--	--		
Sub-Index	02 <sub>h</sub>			
Name	encoder_x2a_numerator			
Info	--	rw	<del>PBO</del>	INT16
Value	-32768...-1,1...32767	1		
Sub-Index	03 <sub>h</sub>			
Name	encoder_x2a_divisor			
Info	--	rw	<del>PBO</del>	INT16
Value	1...32767	1		

### 3.9.2.2 Object 2026<sub>h</sub>: encoder\_x2b\_data\_field

The object record **encoder\_x2b\_data\_field** contains parameters that are necessary for the operation of the angle encoder at connector X2B.

The object **encoder\_x2b\_resolution** specifies how many increments are generated by the encoder per revolution (for incremental encoders this is four times the number of lines or periods per revolution) or length unit. The object **encoder\_x2b\_counter** returns the currently counted number of increments, i.e. values between 0 and **encoder\_x2b\_resolution-1**.

The objects **encoder\_x2b\_numerator** and **encoder\_x2b\_divisor** can be used to take into account a possible gear (also with sign) between motor shaft and encoder.

Index	2026 <sub>h</sub>		
Name	encoder_x2b_data_field		
Type	RECORD	16 <sub>h</sub>	
Sub-Index	01 <sub>h</sub>		
Name	encoder_x2b_resolution		
Info	Increments (4 * line count)	rw	<del>PDO</del> UINT32
Value	--	--	
Sub-Index	02 <sub>h</sub>		
Name	encoder_x2b_numerator		
Info	--	rw	<del>PDO</del> INT16
Value	-32768...-1,1...32767	1	
Sub-Index	03 <sub>h</sub>		
Name	encoder_x2b_divisor		
Info	--	rw	<del>PDO</del> INT16
Value	1...32767	1	
Sub-Index	04 <sub>h</sub>		
Name	encoder_x2b_counter		
Info	Increments (4 * line count)	ro	PDO UINT32
Value	0 ... (encoder_x2b_resolution – 1)	--	

### 3.9.2.3 Object 2025<sub>h</sub>: encoder\_x10\_data\_field

The object record **encoder\_x10\_data\_field** contains parameters that are necessary for the operation of the master frequency input, which is located on connector X1 in the BL 4000 devices series.

A digital incremental encoder or emulated incremental signals, for example from another servo drive (master frequency output), can be connected to the master frequency input. The signals of the master frequency input can optionally be used as setpoint or actual value.

The object **encoder\_x10\_resolution** specifies how many increments are generated by the encoder per revolution (for incremental encoders this is four times the number of

lines or periods per revolution) or length unit. The object `encoder_x10_counter` returns the currently counted number of increments, i.e. values between 0 and `encoder_x10_resolution-1`.

The objects `encoder_x10_numerator` and `encoder_x10_divisor` can be used to take into account a possible gear (also with sign) between motor shaft and encoder. When using the master frequency input as setpoint, this can be used to realise gear ratios between master and slave.

Index	<b>2025<sub>h</sub></b>			
Name	<b>encoder_x10_data_field</b>			
Type	RECORD			05 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>			
Name	<b>encoder_x10_resolution</b>			
Info	Increments (4 * line count)	rw	<del>PDO</del>	UINT32
Value	encoder dependent	--		
Sub-Index	<b>02<sub>h</sub></b>			
Name	<b>encoder_x10_numerator</b>			
Info	--	rw	<del>PDO</del>	INT16
Value	-32768...-1,1...32767	1		
Sub-Index	<b>03<sub>h</sub></b>			
Name	<b>encoder_x10_divisor</b>			
Info	--	rw	<del>PDO</del>	INT16
Value	1...32767	1		
Sub-Index	<b>04<sub>h</sub></b>			
Name	<b>encoder_x10_counter</b>			
Info	Increments (4 * line count)	ro	PDO	UINT32
Value	0 ... (encoder_x10_resolution – 1)	--		
Sub-Index	<b>05<sub>h</sub></b>			
Name	<b>encoder_x10_position</b>			
Info	--	ro	PDO	INT32
Value	--	--		

### 3.9.2.4 Object 202C<sub>h</sub>: max\_comm\_enc\_pos\_enc\_difference

The object `max_comm_enc_pos_enc_difference` returns the maximum difference between the commutation encoder and the actual position encoder.

Index	<b>202C<sub>h</sub></b>			
Name	<b>max_comm_enc_pos_enc_difference</b>			
Info	position_unit	rw	PDO	INT32
Value	--	--		

## 3.10 Master frequency output

### 3.10.1 Overview

This object group is used to parameterise the master frequency output (BL 4000-C, BL 4000-M / BL 4000-D: X1). Thus, master-slave applications in which the master frequency output (incremental encoder emulation) of the master is connected to the master frequency input of the slave can be parameterised via CANopen.

### 3.10.2 Description of objects

#### 3.10.2.1 Object 201A<sub>h</sub>: encoder\_emulation\_data

The object record `encoder_emulation_data` contains all options for the master frequency output.

Using the object `encoder_emulation_resolution` the output number of increments (= four times the number of lines) can be set as a multiple of 4. In a master-slave application, this must correspond to the `encoder_X10_resolution` of the slave to achieve a ratio of 1:1.

With the object `encoder_emulation_offset` the position of the output zero pulse can be shifted in relation to the zero position of the actual value encoder.

Index	201A <sub>h</sub>		
Name	encoder_emulation_data		
Type	RECORD		02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	encoder_emulation_resolution		
Info	Increments (4 * line count)	rw	<del>PBO</del> INT32
Value	4 * (1...8192)	--	
Sub-Index	02 <sub>h</sub>		
Name	encoder_emulation_offset		
Info	32767 = 180°	rw	<del>PBO</del> INT16
Value	-32768...32767	--	

#### 3.10.2.2 Object 2028<sub>h</sub>: encoder\_emulation\_resolution

The object `encoder_emulation_resolution` only exists for compatibility reasons. It corresponds to object 201A<sub>h</sub>\_01<sub>h</sub>.

## 3.11 Setpoint / actual value selection

### 3.11.1 Overview

The following objects can be used to change the source for the setpoint and the actual value. By default, the servo drive uses the input for the motor encoder X2A or X2B as the actual value for the position controller. When using an external position encoder, e.g. behind a gearbox, the position value fed in via the master frequency input can be used as the actual value for the position controller. Furthermore, it is possible to use the master frequency input as an additional setpoint, which allows synchronous operating modes. For reasons of downward compatibility, the objects for parameterising the master frequency input are always designated "\_X10\_", even if the master frequency input is located on the connector [X1], as is the case with the BL 4000 controller family.

### 3.11.2 Description of objects

#### 3.11.2.1 Object 201F<sub>h</sub>: commutation\_encoder\_select

The object `commutation_encoder_select` specifies the encoder input that is used as commutation encoder. Since this value only becomes effective after a reset, the commutation encoder should always be set via the MPC ServoCommander .

Index	201F <sub>h</sub>		
Name	commutation_encoder_select		
Info	--	rw	<del>DD</del> INT16
Value	0, 2	--	

Value	Description
0	X2A
2	X2B

### 3.11.2.2 Object 2021<sub>h</sub>: position\_encoder\_selection

The object **position\_encoder\_selection** specifies the encoder input that is used to determine the actual position (*actual position encoder*). This value can be changed in order to switch to "position control via an external encoder" (connected to the driven side). It is possible to switch between master frequency input and the encoder input that is selected as *commutation encoder* (X2A or X2B). If one of the encoder inputs X2A / X2B is selected as actual position encoder, the one used as *commutation encoder* must be used. If the respective other encoder is selected, the system automatically switches over to the *commutation encoder*.

Index	2021 <sub>h</sub>		
Name	position_encoder_selection		
Info	--	rw	<del>DD</del> INT16
Value	0...2	--	

Value	Description
0	X2A
1	X2B
2	Master frequency input

#### **INFORMATION** Permissible combinations

The following combinations are **permitted**:

- Commutating encoder X2A, position encoder: master frequency input
- Commutating encoder X2B, position encoder: master frequency input

The following combinations are **not permitted**:

- Commutating encoder X2A, position encoder: X2B
- Commutating encoder X2B, position encoder: X2A

### 3.11.2.3 Object 2022<sub>h</sub>: synchronisation\_encoder\_selection

The object **synchronisation\_encoder\_selection** specifies the encoder input via which the synchronisation setpoint is fed in. Depending on the operating mode, this is equivalent to a position setpoint (**Profile Position Mode**) or a speed setpoint (**Profile Velocity Mode**). Only the master frequency input can be used as synchronisation input. Thus, it is possible to select between "Master frequency input" and "No encoder". Do not select the same input as used for the actual value encoder as the synchronisation setpoint.

Index	2022 <sub>h</sub>		
Name	synchronisation_encoder_selection		
Info	--	rw	<del>DD</del> INT16
Value	-1, 2	--	

Value	Description
-1	No encoder / undefined
2	Master frequency input

### 3.11.2.4 Object 202F<sub>h</sub>: synchronisation\_selector\_data

The object **synchronisation\_main** can be used to activate a synchronous setpoint. Bit 0 must be set so that the synchronous setpoint is calculated at all. Bit 1 enables the synchronous position to be switched on only after starting a position set (flying saw). Bit 8 can be used to specify that the homing run should be executed without switching on the synchronous position in order to be able to reference the master and slave separately.

Index	202F <sub>h</sub>		
Name	synchronisation_selector_data		
Type	RECORD		07 <sub>h</sub>
Sub-Index	07 <sub>h</sub>		
Name	synchronisation_main		
Info	--	rw	<del>PBC</del> UINT16
Value	see Table	--	

Bit	Value	Description
0	0001 <sub>h</sub>	0: Synchronisation inactive 1: Synchronisation active
1	0002 <sub>h</sub>	0: "Flying saw" inactive 1: "Flying saw" active
8	0100 <sub>h</sub>	0: Synchronization during homing 1: No synchronization during homing

### 3.11.2.5 Object 2023<sub>h</sub>: synchronisation\_filter\_time

The object **synchronisation\_filter\_time** is used to define the filter time constant of a PT1 filter with which the synchronisation speed is smoothed. This may be necessary especially with low line numbers, since even small changes of the input value correspond to high speeds. On the other hand, the drive may no longer be able to follow a dynamic input signal fast enough at high filter times.

Index	2023 <sub>h</sub>		
Name	synchronisation_filter_time		
Info	µs	rw	<del>PBC</del> UINT32
Value	10...50000	--	



## 3.12 Analogue inputs

### 3.12.1 Overview

The servo drives have analogue inputs, which may be used to provide setpoints to the servo drive, for example. For all these analogue inputs, the following objects offer the possibility of reading out the current input voltage (**analog\_input\_voltage**) and setting an offset (**analog\_input\_offset**). Depending on the servo drive series (BL 4000-M / BL 4000-D, BL 4000-C), there are different numbers of analogue inputs.

### 3.12.2 Description of objects

#### 3.12.2.1 Object 2400<sub>h</sub>: analog\_input\_voltage

The object group **analog\_input\_voltage** supplies the current input voltage of the respective channel in millivolts including the offset.

Index	<b>2400<sub>h</sub></b>			
Name	<b>analog_input_voltage</b>			
Type	ARRAY			03 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>			
Name	<b>analog_input_voltage_ch_0</b>			
Info	mV	ro	PDO	INT16
Value	--	--		
Sub-Index	<b>02<sub>h</sub></b>			
Name	<b>analog_input_voltage_ch_1</b>			
Info	mV	ro	PDO	INT16
Value	--	--		
Sub-Index	<b>03<sub>h</sub></b>			
Name	<b>analog_input_voltage_ch_2</b>			
Info	mV	ro	PDO	INT16
Value	--	--		

### 3.12.2.2 Object 2401<sub>h</sub>: analog\_input\_offset

Via the object group **analog\_input\_offset** the offset voltage in millivolts can be set or read for the respective inputs. With the help of the offset, a possible applied DC voltage can be compensated. A positive offset compensates a positive input voltage.

Index	<b>2401<sub>h</sub></b>		
Name	<b>analog_input_offset</b>		
Type	ARRAY		03 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>		
Name	<b>analog_input_offset_ch_0</b>		
Info	mV	rw	<del>DDQ</del> INT32
Value	-10000...10000	--	
Sub-Index	<b>02<sub>h</sub></b>		
Name	<b>analog_input_offset_ch_1</b>		
Info	mV	rw	<del>DDQ</del> INT32
Value	-10000...10000	--	
Sub-Index	<b>03<sub>h</sub></b>		
Name	<b>analog_input_offset_ch_2</b>		
Info	mV	rw	<del>DDQ</del> INT32
Value	-10000...10000	--	

## 3.13 Digital inputs and outputs

### 3.13.1 Overview

All digital inputs of the servo drive can be read via the CAN bus and almost all digital outputs can be set as required. Furthermore, status messages can be assigned to the digital outputs of the servo drive. Depending on the devices series, not all digital inputs/outputs described here may be available for every device.

### 3.13.2 Description of objects

#### 3.13.2.1 Object 60FD<sub>h</sub>: digital\_inputs

Via the object 60FD<sub>h</sub> the digital inputs may be read:

Index	60FD <sub>h</sub>			
Name	digital_inputs			
Info	--	ro	PDO	UINT32
Value	see Table	--		

Bit	Value	Digital input
0	00000001 <sub>h</sub>	Negative limit switch
1	00000002 <sub>h</sub>	Positive limit switch
2	00000004 <sub>h</sub>	Reference switch
3	00000008 <sub>h</sub>	Interlock (Controller enable or Powerstage enable or STO missing)
24...27	0F000000 <sub>h</sub>	DIN0...DIN3
28	10000000 <sub>h</sub>	DIN8
29	20000000 <sub>h</sub>	BL 4100-C: DIN4

#### 3.13.2.2 Object 60FE<sub>h</sub>: digital\_outputs

Via object 60FE<sub>h</sub> the digital outputs may be controlled. A set bit in object `digital_outputs_mask` specifies which digital output is to be controlled. Via the `digital_outputs_data` object the selected outputs can then be set as required. Please note that a delay of up to 10 ms can occur when controlling the digital outputs. When the outputs are actually set can be determined by reading back object 60FE<sub>h</sub>.

Index	60FE <sub>h</sub>			
Name	digital_outputs			
Type	ARRAY			02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	digital_outputs_data			
Info	--	rw	PDO	UINT32
Value	--	--		
Sub-Index	02 <sub>h</sub>			
Name	digital_outputs_mask			
Info	--	rw	PDO	UINT32
Value	--	--		

Bit	Value	Digital output
0	00000001 <sub>h</sub>	1 = Applying the brake
25...27	0E000000 <sub>h</sub>	DOUT1...DOUT3

**NOTICE** Damage to property possible

If control of the brake is enabled via `digital_output_mask`, the holding brake is released manually by clearing bit 0 in `digital_output_data`!

This can cause the axis to drop in the case of hanging axes.

### 3.13.2.3 Object 2420<sub>h</sub>: digital\_output\_state\_mapping

The object group `digital_outputs_state_mapping` can be used to issue various status messages of the servo drive via the digital outputs. For the integrated digital outputs of the servo drive, there is a separate sub-index for each output.

If such a status message has been assigned to a digital output and the output is then switched on or off directly via `digital_outputs` (60FE<sub>h</sub>), the `digital_outputs_state_mapping` object is also set to OFF (0) or ON (12).

Index	2420 <sub>h</sub>			
Name	digital_outputs_state_mapping			
Type	RECORD			12 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	dig_out_state_mapp_dout_1			
Info	--	rw	<del>PDO</del>	UINT8
Value	0...16, see Table	--		
Sub-Index	02 <sub>h</sub>			
Name	dig_out_state_mapp_dout_2			
Info	--	rw	<del>PDO</del>	UINT8
Value	0...16, see Table	--		

Sub-Index	03 <sub>h</sub>		
Name	dig_out_state_mapp_dout_3		
Info	--	rw	<del>DD</del> UINT8
Value	0...16, see Table		--

Value	Description	Value	Description
0	Off (Output is low)	9	Undervoltage intermed. circuit
1	Position $X_{set} = X_{dest}$	10	Brake unlocked
2	Position $X_{act} = X_{dest}$	11	Power stage active
3	Reserved	12	On (Output is high)
4	Remaining distance	13	Reserved
5	Homing active	14	Reserved
6	Speed reached	15	Linear motor identified
7	I <sup>2</sup> t monitoring active	16	Homing position valid
8	Following error		

## 3.14 Limit switch / Reference switch

### 3.14.1 Overview

For defining the reference position of the servo drive, either limit switches or homing switches can be used. More information about the possible homing methods can be found in section 5.2 *Homing Mode* on page 124.

### 3.14.2 Description of objects

#### 3.14.2.1 Object 6510<sub>h</sub>11<sub>h</sub>: limit\_switch\_polarity

The polarity of the limit switches can be programmed by the object 6510<sub>h</sub>11<sub>h</sub> (*limit\_switch\_polarity*). A zero must be entered in this object for normally closed contacts, a one must be entered when using normally open contacts.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	11 <sub>h</sub>		
Name	limit_switch_polarity		
Info	--	rw	<del>PBO</del> INT16
Value	0, 1	1	

Value	Description
0	Normally closed contact
1	Normally open contact

### 3.14.2.2 Object 6510<sub>h</sub>\_12<sub>h</sub>: limit\_switch\_selector

Via object 6510<sub>h</sub>\_12<sub>h</sub> (**limit\_switch\_selector**) the assignment of the limit switches (negative, positive) can be swapped without having to make changes to the cabling. To exchange the assignment of the limit switches, enter a one.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	12 <sub>h</sub>		
Name	limit_switch_selector		
Info	--	rw	<del>PBO</del> INT16
Value	0, 1	0	

Value	Description
0	DIN6 = E0 (negative limit switch) DIN7 = E1 (positive limit switch)
1	DIN6 = E1 (positive limit switch) DIN7 = E0 (negative limit switch)

### 3.14.2.3 Object 6510<sub>h</sub>\_15<sub>h</sub>: limit\_switch\_deceleration

The **limit\_switch\_deceleration** object determines the deceleration used for braking when the limit switch is reached during normal operation (limit switch emergency ramp).

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	15 <sub>h</sub>		
Name	limit_switch_deceleration		
Info	acceleration_unit	rw	<del>PBO</del> INT32
Value	0...3000000 min <sup>-1</sup> /s	--	

### 3.14.2.4 Object 6510<sub>h</sub>\_14<sub>h</sub>: homing\_switch\_polarity

The polarity of the reference switch can be configured by object 6510<sub>h</sub>\_14<sub>h</sub> (**homing\_switch\_polarity**). For an opening reference switch, a zero must be entered in this object, for the use of closing contacts a one must be entered.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	14 <sub>h</sub>		
Name	homing_switch_polarity		
Info	--	rw	<del>PBC</del> INT16
Value	0, 1	1	

Value	Description
0	Normally closed contact
1	Normally open contact

### 3.14.2.5 Object 6510<sub>h</sub>\_13<sub>h</sub>: homing\_switch\_selector

Object 6510<sub>h</sub>\_13<sub>h</sub> (**homing\_switch\_selector**) determines whether DIN8 or DIN9 should be used as input for the reference switch.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	13 <sub>h</sub>		
Name	homing_switch_selector		
Info	--	rw	<del>PBC</del> INT16
Value	0, 1	0	

Value	Description
0	DIN9
1	DIN8



## 3.15 Position capturing (Sampling)

### 3.15.1 Overview

The servo drives offer the possibility of capturing the actual position value on the rising or falling edge of a digital input (e.g. a measuring probe). This position value can then be read out, e.g. for calculation within a control system.

All necessary objects are summarised in the record `sample_data`: The object `sample_mode` determines the type of sampling: Should only a single sample event be recorded or should sampling be continuous. Using the object `sample_status`, the controller can query whether a sample event has occurred. This is indicated by a set bit, which can also be displayed in the `statusword` if the object `sample_status_mask` is set accordingly. The object `sample_control` is used to control the release of the sample event and the sampled positions can be read out via the objects `sample_position_rising_edge` and `sample_position_falling_edge`.

Which digital input is used can be defined with the MPC ServoCommander under [Parameters / IOs / Digital Inputs / Sample Input](#).

### 3.15.2 Description of objects

#### 3.15.2.1 Object 204A<sub>h</sub>: sample\_data

Index	204A <sub>h</sub>		
Name	sample_data		
Type	RECORD		06 <sub>h</sub>

The following object can be used to select whether the position is to be determined on each occurrence of a sample event (continuous sampling) or whether sampling is to be disabled after a sample event until sampling is enabled again. Please note that even a bouncing input can trigger both edges.

Sub-Index	01 <sub>h</sub>		
Name	sample_mode		
Info	--	rw	<del>PBO</del> UINT16
Value	0...1	--	

Value	Description
0	Continuous sampling
1	Autolock sampling

The following object indicates a new sample event.

Sub-Index	02 <sub>h</sub>		
Name	sample_status		
Info	--	ro	PDO UINT8
Value	0...3	--	

Bit	Value	Name	Description
0	01 <sub>h</sub>	falling_edge_occurred	= 1: Position sampled (falling edge)
1	02 <sub>h</sub>	rising_edge_occurred	= 1: Position sampled (rising edge)

The following object can be used to specify those bits of the `sample_status` object that should also lead to the setting of bit 15 of the statusword. This means that the information "Sample event occurred" is available in the statusword, which is usually transferred anyway. Only if "Sample event occurred" is displayed there, the controller must read the `sample_status` object to determine which edge has occurred.

Sub-Index	03 <sub>h</sub>		
Name	sample_status_mask		
Info	--	rw	PDO UINT8
Value	0...3	--	

Bit	Value	Name	Description
0	01 <sub>h</sub>	falling_edge_visible	If falling_edge_occurred = 1 Bit 15 is set in the statusword
1	02 <sub>h</sub>	rising_edge_visible	If rising_edge_occurred = 1 Bit 15 is set in the statusword

Setting the respective bit in `sample_control` resets the corresponding status bit in `sample_status` and, in case of "Autolock" sampling, enables sampling again.

Sub-Index	04 <sub>h</sub>		
Name	sample_control		
Info	--	wo	PDO UINT8
Value	0...3	0	

Bit	Value	Name	Description
0	01 <sub>h</sub>	falling_edge_enable	Sampling on falling edge
1	02 <sub>h</sub>	rising_edge_enable	Sampling on rising edge

The following objects contain the sampled positions.

Sub-Index	<b>05<sub>h</sub></b>			
Name	<b>sample_position_rising_edge</b>			
Info	position_unit	ro	PDO	INT32
Value	--	--		
Sub-Index	<b>06<sub>h</sub></b>			
Name	<b>sample_position_falling_edge</b>			
Info	position_unit	ro	PDO	INT32
Value	--	--		

## 3.16 Brake control

### 3.16.1 Overview

The following objects can be used to parameterise how the servo drive controls a holding brake that may be integrated in the motor. The holding brake is always enabled as soon as the servo drive enable is switched on. For holding brakes with high mechanical inertia, a delay time  $t_A$  can be parameterised so that the holding brake is engaged before the power stage is switched off (sagging of vertical axes). Similarly, the control of the motor is delayed ( $t_F$ ) until the holding brake is completely released. Both delays are parameterised simultaneously by the object `brake_delay_time` ( $t_A = t_F$ ).




Figure 8: Function of brake delay (for speed control / positioning)

### 3.16.2 Description of objects

#### 3.16.2.1 Object 6510<sub>h</sub>\_18<sub>h</sub>: brake\_delay\_time

The braking delay time can be parameterised via the object `brake_delay_time`.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	18 <sub>h</sub>		
Name	brake_delay_time		
Info	ms	rw	<del>PBC</del> UINT16
Value	0...32000	--	

## 3.17 Device information

Numerous CAN objects can be used to read a wide variety of information from the device, such as servo drive type, firmware used, etc.

### 3.17.1 Description of objects

#### 3.17.1.1 Object 1000<sub>h</sub>: device\_type

The **device\_type** object indicates in the lower 16 bits that device profile 402 is supported and in the upper 16 bits that it is a servo drive (bit 17).

Index	1000 <sub>h</sub>		
Name	device_type		
Info	--	ro	DDC UINT32
Value	--	00020192 <sub>h</sub>	

#### 3.17.1.2 Object 1008<sub>h</sub>: manufacturer\_device\_name

Via the object **manufacturer\_device\_name** the name of the device series can be read in plain text.

Index	1008 <sub>h</sub>		
Name	manufacturer_device_name		
Info	--	ro	DDC VISSTR
Value	--	--	

#### 3.17.1.3 Object 1009<sub>h</sub>: manufacturer\_hardware\_version

The **manufacturer\_hardware\_version** object can be used to read the hardware revision of the device. This is also displayed in the MPC ServoCommander under **Help / Info Tab Firmware / Hardware**.

Index	1009 <sub>h</sub>		
Name	manufacturer_hardware_version		
Info	MMM.SSS	ro	DDC VISSTR
Value	--	--	

Value	Description
M	main version
S	sub version

### 3.17.1.4 Object 100A<sub>h</sub>: manufacturer\_software\_version

The **manufacturer\_software\_version** object can be used to read the firmware version in plain text. The individual parts of the version number are formatted as ASCII characters without leading zeros and are separated by dots, e.g. "1.0.0.1.2".

Index	100A <sub>h</sub>		
Name	manufacturer_software_version		
Info	M.S.C.K.k	ro	DBC VISSTR
Value	--		

Value	Description
M	Corresponds to MMMM of <i>Object 6510h_A9h: firmware_main_version</i>
S	Corresponds to SSSS of <i>Object 6510h_A9h: firmware_main_version</i>
C	Corresponds to <i>Object 6510h_AAh: firmware_custom_version</i>
K	Corresponds to MMMM of <i>Object 6510h_ADh: km_release</i>
k	Corresponds to SSSS of <i>Object 6510h_ADh: km_release</i>

### 3.17.1.5 Object 1018<sub>h</sub>: identity\_object

The servo drive can be uniquely identified in a CANopen network via the **identity\_object** defined in DS301. For this purpose, the vendor code (**vendor\_id**), a unique product code (**product\_code**), the revision number of the CANopen implementation (**revision\_number**) and the serial number (**serial\_number**) can be read out.

Index	1018 <sub>h</sub>		
Name	identity_object		
Type	RECORD		04 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	vendor_id		
Info	--	ro	DBC UINT32
Value	-- 000000E4 <sub>h</sub>		
Sub-Index	02 <sub>h</sub>		
Name	product_code		
Info	--	ro	DBC UINT32
Value	--		

Value	Description
8202 <sub>h</sub>	BL 4102-C
8203 <sub>h</sub>	BL 4104-C
8208 <sub>h</sub>	BL 4304-C
8209 <sub>h</sub>	BL 4308-C

Value	Description
8212 <sub>h</sub>	BL 4312-C
820A <sub>h</sub>	BL 4104-M ETH
820C <sub>h</sub>	BL 4104-D ETH
820D <sub>h</sub>	BL 4840-M ETH
820F <sub>h</sub>	BL 4840-D ETH
820B <sub>h</sub>	BL 4104-M CAN
8210 <sub>h</sub>	BL 4104-D CAN
820E <sub>h</sub>	BL 4840-M CAN
8211 <sub>h</sub>	BL 4840-D CAN

Sub-Index	03 <sub>h</sub>		
Name	revision_number		
Info	--	ro	<del>PBC</del> UINT32
Value	--	00040002 <sub>h</sub>	
Sub-Index	04 <sub>h</sub>		
Name	serial_number		
Info	--	ro	<del>PBC</del> UINT32
Value	--	--	

### 3.17.1.6 Object 6510<sub>h</sub>\_A0<sub>h</sub>: drive\_serial\_number

The object `drive_serial_number` returns the serial number of the servo drive . This object is used to ensure compatibility with earlier versions.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD	F0 <sub>h</sub>	
Sub-Index	A0 <sub>h</sub>		
Name	drive_serial_number		
Info	--	ro	<del>PBC</del> UINT32
Value	--	--	

### 3.17.1.7 Object 6510<sub>h</sub>A1<sub>h</sub>: drive\_type

The **drive\_type** object can be used to read the product code of the servo drive. This object is used to ensure compatibility with earlier versions.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	A1 <sub>h</sub>		
Name	drive_type		
Info	see 1018 <sub>h</sub> 02 <sub>h</sub> (product code)	ro	DDC UINT32
Value	see 1018 <sub>h</sub> 02 <sub>h</sub> (product code)	--	

### 3.17.1.8 Object 6510<sub>h</sub>A9<sub>h</sub>: firmware\_main\_version

The **firmware\_main\_version** object can be used to read the main version number of the firmware (product step).

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	A9 <sub>h</sub>		
Name	firmware_main_version		
Info	MMMMSSSS <sub>h</sub>	ro	DDC UINT32
Value	--	--	

Value	Description
M	main version
S	sub version

### 3.17.1.9 Object 6510<sub>h</sub>AA<sub>h</sub>: firmware\_custom\_version

The object **firmware\_custom\_version** can be used to read the version number of the customer-specific variant of the firmware.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	AA <sub>h</sub>		
Name	firmware_custom_version		
Info	--	ro	DDC UINT32
Value	--	--	



### 3.17.1.10 Object 6510<sub>h</sub>\_AD<sub>h</sub>: km\_release

The version number of the **km\_release** can be used to differentiate between firmware versions of the same product level.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	AD <sub>h</sub>		
Name	km_release		
Info	MMMMSSSS <sub>h</sub>	ro	DBQ UINT32
Value	--		--

Value	Description
M	main version
S	sub version

### 3.17.1.11 Object 6510<sub>h</sub>\_AC<sub>h</sub>: firmware\_type

The **firmware\_type** object is present for compatibility reasons and has no significance for the BL 4000 series.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	AC <sub>h</sub>		
Name	firmware_type		
Info	000000GX <sub>h</sub>	ro	DBQ UINT32
Value	F2 <sub>h</sub>		--

### 3.17.1.12 Object 6510<sub>h</sub>\_B0<sub>h</sub>: cycletime\_current\_controller

The object **cycletime\_current\_controller** returns the cycle time of the current controller in microseconds.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	B0 <sub>h</sub>		
Name	cycletime_current_controller		
Info	μs	ro	DBQ UINT32
Value	--		--

### 3.17.1.13 Object 6510<sub>h</sub>\_B1<sub>h</sub>: cycletime\_velocity\_controller

The object `cycletime_velocity_controller` returns the cycle time of the speed controller in microseconds.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	B1 <sub>h</sub>		
Name	cycletime_velocity_controller		
Info	µs	ro	<del>PBO</del> UINT32
Value	--	--	

### 3.17.1.14 Object 6510<sub>h</sub>\_B2<sub>h</sub>: cycletime\_position\_controller

The object `cycletime_position_controller` returns the cycle time of the position controller in microseconds.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	B2 <sub>h</sub>		
Name	cycletime_position_controller		
Info	µs	ro	<del>PBO</del> UINT32
Value	--	--	

### 3.17.1.15 Object 6510<sub>h</sub>\_B3<sub>h</sub>: cycletime\_trajectory\_generator

The object `cycletime_trajectory_generator` returns the cycle time of the trajectory generator in microseconds.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	B3 <sub>h</sub>		
Name	cycletime_trajectory_generator		
Info	µs	ro	<del>PBO</del> UINT32
Value	--	--	

3.17.1.16 Object 6510<sub>h</sub>\_C0<sub>h</sub>: commissioning\_state**NOTICE** Unsuitable parameterisation possible

This object does not contain any information about whether the servo drive has been parameterised correctly according to the motor and the application, but only whether the points mentioned were parameterised at least once after delivery.

**INFORMATION** „A“ on the 7-segment display

Note that at least one bit must be set in the `commissioning_state` object to suppress the "A" on the display of your servo drive.

Index	6510 <sub>h</sub>		
Name	drive_data		
Type	RECORD		F0 <sub>h</sub>
Sub-Index	C0 <sub>h</sub>		
Name	commissioning_state		
Info	--	rw	<del>DD</del> UINT32
Value	--	--	

Bit	Description	Bit	Description
0	Nominal current valid	9	Reserved
1	Maximum current valid	10	Physical units valid
2	Number of poles of motor valid	11	Speed controller valid
3	Offset angle / direction of rotation valid	12	Position controller valid
4	Reserved	13	Monitoring parameter valid
5	Offset angle / direction of rotation Hall sensor valid	14	Reserved
6	Reserved	15	Limit switch polarity valid
7	Absolute position encoder system valid	16...31	Reserved
8	Current controller parameters valid		

3.17.1.17 Object 20FD<sub>h</sub>: user\_device\_name

The `user_device_name` object can be used to read and write the user-definable name of the drive (e.g. "X-axis").

Index	20FD <sub>h</sub>		
Name	user_device_name		
Info	--	rw	<del>DD</del> VISSTR
Value	--	--	

## 3.18 Error management

### 3.18.1 Overview

The servo drives offer the possibility to change the error reaction of individual events, such as the occurrence of a following error. As a result, the servo drive reacts differently when a particular event occurs: Depending on the setting, the servo drive will decelerate, the power stage will be switched off immediately or only a warning will be shown on the display.

A fixed minimum reaction is provided for each event, which must not be fallen below. This means that "critical" errors such as "06-0 short-circuit of the power stage" cannot be reparameterised, as in this case an immediate switch-off is necessary to protect the servo drive from being destroyed.

If a lower error response than permitted for the respective error is entered, the value is limited to the lowest permitted error response. A list of all error numbers can be found in the "Product Manual smartServo BL 4000".

### 3.18.2 Description of objects

#### 3.18.2.1 Object 2100<sub>h</sub>: error\_management

Index	2100 <sub>h</sub>		
Name	error_management		
Type	RECORD		02 <sub>h</sub>

In the object **error\_number** the main error number is specified whose reaction should be changed. The main error number is the one usually given before the hyphen (for example, error 08-2, main error number 8).

Sub-Index	01 <sub>h</sub>		
Name	error_number		
Info	--	rw	<del>DD</del> UINT8
Value	1...96	--	

The reaction of the error can be changed in the object `error_reaction_code`. If the response is less than the manufacturer's minimum response, the system limits the error to this. The actual reaction set can be determined by reading it back.

Sub-Index	02 <sub>h</sub>		
Name	error_reaction_code		
Info	--	rw	PDO UINT8
Value	0, 1, 3, 5, 7, 8	--	

Value	Description
0	No action
1	Entry into buffer
3	Warning on the 7-segment display
5	Disable servo drive
7	Stop at maximum current
8	Disable power stage immediately

### 3.18.2.2 Object 200F<sub>h</sub>: last\_warning\_code

Warnings are remarkable events of the drive (e.g. a following error), which, in contrast to an error, should not lead to a shutdown of the drive. Warnings are shown on the 7-segment display of the servo drive and are then automatically reset.

The last occurred warning can be read out via the following object: Thereby bit 15 indicates whether the warning is currently still active.

Index	200F <sub>h</sub>		
Name	last_warning_code		
Info	--	ro	PDO UINT16
Value	--	--	

Bit	Value	Description
0... 3	000F <sub>h</sub>	Warning sub-number
4...11	0FF0 <sub>h</sub>	Warning main number
15	8000 <sub>h</sub>	Warning is active

# 4 Device Control

## 4.1 Overview

The following chapter describes how the servo drive is controlled under CANopen, i.e. how the power stage is switched on or an error is acknowledged.

Under CANopen, the entire control of the servo drive can be realised via two objects: The host can operate the servo drive via the **controlword**, while the status of the servo drive can be read back in the **statusword**. The following terms are used to explain servo drive control:

Keyword	Explanation
State	The servocontroller is in different states depending on whether the power stage is switched on or an error has occurred. The states defined under CANopen are presented in the following chapter. Example: OPERATION_ENABLE
State Transition	Like the states, CANopen also defines how to go from one state to another (e.g. to acknowledge an error). State transitions are triggered by the host by setting bits in the <b>controlword</b> or internally by the servocontroller if it detects an error, for example
Command	To trigger state transitions, certain combinations of bits must be set in the controlword. Such a combination is called a command. Example: <input type="text" value="Enable Operation"/>
State Machine	The states and state transitions together form the State Machine diagram, i.e. the overview of all states and possible transitions.

## 4.2 State Machine

The status diagram can be roughly divided into three areas: "Power Disabled" means that the power stage is switched off and "Power Enabled" means that the power stage is switched on. The "Fault" area summarises the states necessary for error handling.





Figure 9: State diagram of the servo drive

After switching on, the servo drive initialises itself and finally reaches the SWITCH\_ON\_DISABLED state. In this state, the CAN communication is fully functional and the servo drive can be parameterised (e.g. the operating mode "speed control" can be set). The output stage is switched off and the motor shaft can therefore rotate freely. By means of the state transitions 2, 3, 4 - which in principle corresponds to the CAN servo drive enable - the OPERATION\_ENABLE state is reached. In this state, the power stage is switched on and the motor is controlled according to the set operating mode. Therefore, before doing so, make absolutely sure that the drive is correctly parameterised and a corresponding setpoint value is zero. State transition 9 corresponds to disabling the drive, i.e. a motor still running would coast down uncontrolled. If an error occurs, the drive (regardless of its current state) ultimately switches to the FAULT state. Depending on the severity of the fault, certain actions, such as emergency braking, can be carried out beforehand (FAULT\_REACTION\_ACTIVE).

To execute the mentioned state transitions certain bit combinations must be set in the **controlword** (see below). The lower 4 bits of the controlword are evaluated together to trigger a state transition. In the following only the most important state transitions 2, 3, 4, 9 and 15 are explained. A table of all possible states and state transitions can be found at the end of this chapter.

### > Important state transitions

The following table contains in the 1st column the desired state transition and in the 2nd column the necessary prerequisites for it (usually a command by the host, shown here with a frame). How this command is generated, i.e. which bits are to be set in the **controlword**, can be seen in the 3rd column (x = not relevant).

No.	Is carried out if	Bit combination (controlword)				Action	
		Bit	3	2	1		0
2	Power stage and Controller enable + Shutdown	Shutdown	x	1	1	0	No action
3	Switch On	Switch On	x	1	1	1	Switching on the power stage
4	Enable Operation	Enable Operation	1	1	1	1	Control according to set operating mode
9	Disable Voltage	Disable Voltage	x	x	0	x	Power stage will be disabled. Motor shaft is freely rotatable.
15	Cause of the error eliminated + Fault Reset	Fault Reset	Bit 7 = 				Error acknowledgement

### EXAMPLE

After the servo drive has been parameterised, the drive should be enabled, i.e. the power stage should be switched on:

1. The servocontroller is in SWITCH\_ON\_DISABLED state
2. The controller should be set to the OPERATION\_ENABLED state
3. The state transitions 2, 3 and 4 must be executed.
4. From the previous table follows:

Transition	controlword	New state
2	0006 <sub>h</sub>	READY_TO_SWITCH_ON
3	0007 <sub>h</sub>	SWITCHED_ON
4	000F <sub>h</sub>	OPERATION_ENABLE

Remarks:

- To illustrate the principle, no further bits are set in the **controlword**.
- The transitions 3 and 4 can be combined by writing 000F<sub>h</sub>, because the set bit 3 is not relevant for transition 3.
- In each case, it is necessary to wait until the controller has reached this state. This is explained in more detail in the following section.



## 4.2.1 State diagram: States

In the following table all states and their meaning are listed:

Name	Description
NOT_READY_TO_SWITCH_ON	The servo drive performs a self-test. The CAN communication is not yet working.
SWITCH_ON_DISABLED	The servo drive has completed its self-test. CAN communication is possible.
READY_TO_SWITCH_ON	The servo drive waits until the digital inputs "Power stage enable" and "Controller enable" are connected to 24 V. (Enable logic "Digital input and CAN").
SWITCHED_ON *1)	The power stage is switched on.
OPERATION_ENABLE *1)	The motor is supplied with voltage and is controlled according to the current operating mode.
QUICKSTOP_ACTIVE *1)	The Quick Stop Function is executed (see: <a href="#">quick_stop_option_code</a> ). The motor is connected to voltage and is controlled according to the Quick Stop Function.
FAULT_REACTION_ACTIVE *1)	An error has occurred. In the case of critical errors, the device immediately switches to the status <code>Fault</code> . Otherwise, the action specified in the <a href="#">fault_reaction_option_code</a> is executed. The motor is connected to voltage and is controlled according to the Fault Reaction Function.
FAULT	An error has occurred. The motor is voltage-free.

\*1) The power stage is switched on

## 4.2.2 State diagram: State transitions

### **DANGER** **Danger to life due to electric shock!**

**Power stage disabled** means that the power semiconductors are no longer driven. If this state is entered when the motor is rotating, it coasts down unbraked. A mechanical motor brake, if present, is automatically applied.

The signal does not guarantee that the motor is in fact voltage-free.


### **CAUTION** **Uncontrolled behaviour**

**Power stage enabled** means that the motor is controlled according to the selected operating mode. A mechanical motor brake, if present, is automatically released.

In the event of a defect or incorrect parameterisation (motor current, number of poles, resolver offset angle, etc.), the drive may behave in an uncontrolled manner.

The following table lists all state transitions and their meaning:

No.	Will be executed if	Bit combination (controlword)				Action	
		Bit	3	2	1		0
0	Switched on or reset	Internal transition				Perform self-test	
1	Self-test succesful	Internal transition				Activation of CAN communication	
2	Dig. inputs Power stage enable and Controller enable active + Shutdown	Shutdown	x	1	1	0	-
3	Switch On	Switch On	x	1	1	1	Power stage switched on
4	Enable Operation	Enable Operation	1	1	1	1	Control according to set operating mode
5	Disable Operation	Disable Operation	0	1	1	1	Power stage is disabled. Motor shaft is freely rotatable.
6	Shutdown	Shutdown	x	1	1	0	Power stage is disabled. Motor shaft is freely rotatable.
7	Quick Stop	Quick Stop	x	0	1	x	-
8	Shutdown	Shutdown	x	1	1	0	Power stage is disabled. Motor shaft is freely rotatable.
9	Disable Voltage	Disable Voltage	x	x	0	x	Power stage is disabled. Motor shaft is freely rotatable.
10	Disable Voltage	Disable Voltage	x	x	0	x	Power stage is disabled. Motor shaft is freely rotatable.
11	Quick Stop	Quick Stop	x	0	1	x	Braking according to <a href="#">quick_stop_option_code</a> .
12	Braking finished or Disable Voltage	Disable Voltage	x	x	0	x	Power stage is disabled. Motor shaft is freely rotatable.

No.	Will be executed if	Bit combination (controlword)				Action
		Bit	3	2	1	
13	Error occurred	Internal transition				For non-critical errors, reaction according to <code>fault_reaction_option_code</code> . For critical errors, transition 14 follows
14	Error handling is finished	Internal transition				Power stage is disabled. Motor shaft is freely rotatable.
15	Cause of error eliminated + Command <code>Fault Reset</code>	<code>Fault Reset</code>	Bit 7 = 			Error acknowledgement (on rising edge)

## 4.3 controlword

### Object 6040<sub>h</sub>: controlword


The **controlword** can be used to change the current state of the servo drive or directly trigger a specific action (e.g. start homing). The function of bits 4, 5, 6 and 8 depends on the current operating mode (**modes\_of\_operation**) of the servo drive, which is explained after this chapter.

Index	6040 <sub>h</sub>			
Name	controlword			
Info	--	rw	PDO	UINT16
Value	--			

Bit	Value	Function
0	0001 <sub>h</sub>	Control of the state transitions. (These bits are evaluated together)
1	0002 <sub>h</sub>	
2	0004 <sub>h</sub>	
3	0008 <sub>h</sub>	
4	0010 <sub>h</sub>	new_set_point / start_homing_operation / enable_ip_mode
5	0020 <sub>h</sub>	change_set_immediatly
6	0040 <sub>h</sub>	absolute / relative
7	0080 <sub>h</sub>	reset_fault
8	0100 <sub>h</sub>	halt
9	0200 <sub>h</sub>	Reserved, write 0.
10	0400 <sub>h</sub>	Reserved, write 0.
11	0800 <sub>h</sub>	Reserved, write 0.
12	1000 <sub>h</sub>	Reserved, write 0.
13	2000 <sub>h</sub>	Reserved, write 0.
14	4000 <sub>h</sub>	Reserved, write 0.
15	8000 <sub>h</sub>	Reserved, write 0.

### › Description of the commands (Bits 0...3, Bit 7)

As already extensively described, state transitions can be executed with bits 0..3. The commands required for this are shown here once again in an overview. The `Fault Reset` command is generated by a rising edge (from 0 to 1) of bit 7.

Commands:	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0
	0080 <sub>h</sub>	0008 <sub>h</sub>	0004 <sub>h</sub>	0002 <sub>h</sub>	0001 <sub>h</sub>
<code>Shutdown</code>	x	x	1	1	0
<code>Switch On</code>	x	x	1	1	1
<code>Disable Voltage</code>	x	x	x	0	x
<code>Quick Stop</code>	x	x	0	1	x
<code>Disable Operation</code>	x	0	1	1	1
<code>Enable Operation</code>	x	1	1	1	1
<code>Fault Reset</code>		x	x	x	x

#### **INFORMATION** State changes

Since some status changes take a certain amount of time, all status changes triggered by the `controlword` must be read back via the `statusword`. Only when the requested status can also be read in the `statusword` is it permitted to write another command into the `controlword`.

### › Description of the other bits

The remaining bits of the `controlword` are explained below. Some of the bits have different meanings depending on the operation mode (`modes_of_operation`), i.e. whether the servo drive is speed- or torque-controlled, for example:

Bit 4	Depends on <code>modes_of_operation</code> :
<code>new_set_point</code>	In <b>Profile Position Mode</b> : A rising edge signals the servocontroller that a new positioning job should be accepted. See also section 5.3 <i>Profile Position Mode</i> on page 134.
<code>start_homing_operation</code>	In <b>Homing Mode</b> : A rising edge causes the parameterised homing run to be started. A falling edge terminates an active homing run.
<code>enable_ip_mode</code>	In <b>Interpolated Position Mode</b> : This bit must be set to enable the interpolation data sets to be evaluated. It is acknowledged by the bit <code>ip_mode_active</code> in the <code>statusword</code> . For more information see section 5.4 <i>Interpolated Position Mode</i> on page 139

Bit 5	
change_set_immediatly	Only in <b>Profile Position Mode</b> : If this bit is not set, a possibly running positioning job is processed first and then the new one is started. If this bit is set, a running positioning is immediately aborted and replaced by the new positioning job. It is essential that you also refer to section 5.3 <i>Profile Position Mode</i> on page 134.
Bit 6	
relative	Only in <b>Profile Position Mode</b> : When this bit is set, the servocontroller adds the target position ( <b>target_position</b> ) of the current positioning job to the set position ( <b>position_demand_value</b> ) of the position controller.
Bit 7	
reset_fault	On a rising edge the servocontroller attempts to acknowledge the existing errors. This is only successful if the cause of the error has been eliminated.
Bit 8	
<b>Depends on <i>modes_of_operation</i>:</b>	
halt	In <b>Profile Position Mode</b> : If the bit will be set, the current positioning is aborted. Braking is done with the <b>profile_deceleration</b> . When the process is complete, the bit <b>target_reached</b> is set in the statusword. Clearing the bit has no effect.
halt	In <b>Profile Velocity Mode</b> : When the bit will be set, the speed is reduced to zero. Braking is done with the <b>profile_deceleration</b> . Clearing the bit causes the servocontroller to accelerate again.
halt	In <b>Profile Torque Mode</b> : When the bit will be set, the torque is reduced to zero. This is done with the <b>torque_slope</b> . Clearing the bit causes the servocontroller to accelerate again.
halt	In <b>Homing Mode</b> : When the bit will be set, the current homing run is aborted. Clearing the bit has no effect.

## 4.4 Reading the servo drive status

In the same way as various state transitions can be triggered by combining several bits of the **controlword**, the status of the servocontroller can be read out by combining different bits of the **statusword**. The following table lists the possible states of the state diagram and the corresponding bit combination with which they are displayed in the **statusword**.

State	Bit 6	Bit 5	Bit 3	Bit 2	Bit 1	Bit 0	Mask	Value
	0040 <sub>h</sub>	0020 <sub>h</sub>	0008 <sub>h</sub>	0004 <sub>h</sub>	0002 <sub>h</sub>	0001 <sub>h</sub>		
Not_Ready_To_Switch_On	0	x	0	0	0	0	004F <sub>h</sub>	0000 <sub>h</sub>
Switch_On_Disabled	1	x	0	0	0	0	004F <sub>h</sub>	0040 <sub>h</sub>
Ready_to_Switch_On	0	1	0	0	0	1	006F <sub>h</sub>	0021 <sub>h</sub>
Switched_On	0	1	0	0	1	1	006F <sub>h</sub>	0023 <sub>h</sub>
Operation_Enable	0	1	0	1	1	1	006F <sub>h</sub>	0027 <sub>h</sub>
Quick_Stop_Active	0	0	0	1	1	1	006F <sub>h</sub>	0007 <sub>h</sub>
Fault_Reaction_Active	0	x	1	1	1	1	004F <sub>h</sub>	000F <sub>h</sub>
Fault	0	x	1	1	1	1	004F <sub>h</sub>	000F <sub>h</sub>
Fault (as per DS402) <sup>1)</sup>	0	x	1	0	0	0	004F <sub>h</sub>	0008 <sub>h</sub>

### INFORMATION FAULT state not implemented according to DS402

<sup>1)</sup> In earlier CANopen implementations the FAULT state is not indicated according to DS 402. To get the state indicated according to DS 402, this must be selected in the **compatibility\_control** (see section 3.2 *Compatibility settings* on page 41). For compatibility to earlier firmware versions, no changes need to be made.

### EXAMPLE

The example on page 104 shows which bits must be set in the **controlword** to enable the servo drive. In this example, we will explain how the current status of the servo drive is then read from the **statusword**.

Transition	controlword	New state	Wait until
2	0006 <sub>h</sub>	READY_TO_SWITCH_ON	(statusword & 006F <sub>h</sub> ) = 0021 <sub>h</sub>
3+4	000F <sub>h</sub>	OPERATION_ENABLE	(statusword & 006F <sub>h</sub> ) = 0027 <sub>h</sub>

Remarks:

- To clarify the principle, no further bits are set in the controlword.
- To determine the controller status unambiguously, even bits that are not set must be checked in the **statusword**. The **statusword** must therefore be masked accordingly.

## 4.5 Statuswords

### 4.5.1 Object 6041<sub>h</sub>: statusword

Index	6041 <sub>h</sub>			
Name	statusword			
Info	--	ro	PDO	UINT16
Value	--			

Bit	Value	Name
0	0001 <sub>h</sub>	Status of the servo drive, see section 4.4 <i>Reading the servo drive status</i> on page 111. These bits must be evaluated together.
1	0002 <sub>h</sub>	
2	0004 <sub>h</sub>	
3	0008 <sub>h</sub>	
5	0020 <sub>h</sub>	
6	0040 <sub>h</sub>	
4	0010 <sub>h</sub>	voltage_enabled
7	0080 <sub>h</sub>	warning
8	0100 <sub>h</sub>	drive_is_moving
9	0200 <sub>h</sub>	remote
10	0400 <sub>h</sub>	target_reached
11	0800 <sub>h</sub>	internal_limit_active
12	1000 <sub>h</sub>	set_point_acknowledge / speed_0 / homing_attained / ip_mode_active
13	2000 <sub>h</sub>	following_error / homing_error
14	4000 <sub>h</sub>	manufacturer_statusbit
15	8000 <sub>h</sub>	trigger_result

All bits of the statusword are not buffered. They represent the current device status.

In addition to the servo drive status, various events are displayed in the **statusword**, whereby each bit is assigned a specific event, such as a following error. The individual bits have the following meaning:



<b>Bit 4</b>	
voltage_enabled	<p>This bit is set when the power stage transistors are <b>switched off</b>.</p> <p>In earlier CANopen implementations, contrary to the specification in DS 402, bit 4 (voltage_enabled) is returned inverted. For compatibility reasons, this has been retained. However, it is possible to select the behaviour according to DS402 via the object <b>compatibility_control</b> (see section 3.2 <i>Compatibility settings</i> on page 41).</p> <p>If bit 7 is set in object <b>6510<sub>h</sub>_F0h</b> (<b>compatibility_control</b>), the following applies: This bit is set if the power stage transistors are <b>switched on</b>. No changes need to be made for compatibility with earlier firmware versions.</p>
<b>Bit 5</b>	
quick_stop	If the bit is cleared, the drive executes a <b>Quick Stop</b> according to <b>quick_stop_option_code</b> .
<b>Bit 7</b>	
warning	The meaning of this bit is configurable: It can be set when any bit in <b>manufacturer_warnings_1</b> is set. See also section 4.5.5 <i>Object 2001h: manufacturer_warnings</i> on page 118.
<b>Bit 8</b>	<b>manufacturer specific</b>
drive_is_moving	This bit is set - independently of the <b>modes_of_operation</b> - if the actual speed ( <b>velocity_actual_value</b> ) of the drive is outside the associated tolerance window ( <b>velocity_threshold</b> ).
<b>Bit 9</b>	
remote	This bit indicates that the power stage of the servocontroller can be enabled via the CAN network. It is set if the controller enable logic is set accordingly via the <b>enable_logic</b> object.

Bit 10	Depends on <i>modes_of_operation</i> :
target_reached	In <b>Profile Position Mode</b> : This bit is set when the target position is reached and the actual position ( <b>position_actual_value</b> ) is in the parameterised position window ( <b>position_window</b> ). It is also set when the drive comes to a standstill after the <b>Halt</b> bit has been set. It is deleted as soon as a new positioning is started.
target_reached	In <b>Profile Velocity Mode</b> : The bit is set when the speed ( <b>velocity_actual_value</b> ) of the drive is within the tolerance window ( <b>velocity_window</b> , <b>velocity_window_time</b> ).
Bit 11	
internal_limit_active	This bit indicates that the I <sup>2</sup> t limitation is active.
Bit 12	Depends on <i>modes_of_operation</i> :
set_point_acknowledge	In <b>Profile Position Mode</b> : This bit is set when the servocontroller has recognised the set bit <b>new_set_point</b> in the controlword. It is cleared again after the <b>new_set_point</b> bit in the <b>controlword</b> has been set to zero. For more information see section 5.3 <i>Profile Position Mode</i> on page 134.
speed_0	In <b>Profile Velocity Mode</b> : This bit is set when the actual speed ( <b>velocity_actual_value</b> ) of the drive is within the associated tolerance window ( <b>velocity_threshold</b> ).
homing_attained	In <b>Homing Mode</b> : This bit is set if the homing run was completed without errors.
ip_mode_active	In <b>Interpolated Position Mode</b> : This bit indicates that the interpolation is active and the interpolation data sets are being evaluated. It is set if this was requested by the bit <b>enable_ip_mode</b> in the <b>controlword</b> . For more information see section 5.4 <i>Interpolated Position Mode</i> on page 139.

<b>Bit 13</b>	<b>Depends on <i>modes_of_operation</i>:</b>
following_error	In Profile Position Mode: This bit is set if the actual position ( <i>position_actual_value</i> ) differs from the target position ( <i>position_demand_value</i> ) so much that the difference lies outside the parameterised tolerance window ( <i>following_error_window</i> , <i>following_error_time_out</i> ).
homing_error	In Homing Mode: This bit is set if the homing run is interrupted ( <i>Halt</i> bit), both limit switches are activated simultaneously or the distance already travelled during the limit switch search is greater than the specified positioning range ( <i>min_position_limit</i> , <i>max_position_limit</i> ).
<b>Bit 14</b>	<b>manufacturer specific</b>
manufacturer_statusbit	The meaning of this bit is configurable: It can be set when any bit of the <i>manufacturer_statusword_1</i> is set or reset. See also section 4.5.2 <i>Object 2000h: manufacturer_statuswords</i> on page 115.
<b>Bit 15</b>	<b>manufacturer specific</b>
trigger_result	The meaning of this bit is configurable: It is set when a sample event has occurred and the sample mask is set accordingly. See also section 3.15 <i>Position capturing (Sampling)</i> on page 89.

## 4.5.2 Object 2000<sub>h</sub>: manufacturer\_statuswords


The object group *manufacturer\_statuswords* displays additional manufacturer-specific states of the servocontroller.

Index	2000 <sub>h</sub>		
Name	manufacturer_statuswords		
Type	RECORD		01 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	manufacturer_statusword_1		
Info	--	ro	PDO UINT32
Value	--	--	

Bit	Value	Name
0	00000001 <sub>h</sub>	is_referenced
1	00000002 <sub>h</sub>	commutation_valid
2	00000004 <sub>h</sub>	ready_for_enable
3	00000008 <sub>h</sub>	ipo_in_target
...		
8	00000100 <sub>h</sub>	safe_standstill

<b>Bit 0</b>	
is_referenced	The bit is set when the servocontroller is referenced. This is the case if either a homing run has been successfully performed or no homing run is necessary due to the connected encoder system (e.g. in the case of an absolute encoder).
<b>Bit 1</b>	
commutation_valid	The bit is set if the commutation information is valid. It is especially helpful for encoder systems without commutation information (e.g. linear motors), as the automatic commutation finding can take some time there. If this bit is monitored a timeout of the control can be prevented when enabling the servo drive.
<b>Bit 2</b>	
ready_for_enab	The bit is set when all conditions are present to enable the servo drive and only the controller enable itself is missing. The following conditions must be fulfilled: <ul style="list-style-type: none"> <li>• The drive is error-free</li> <li>• The DC link is loaded</li> <li>• The angle encoder evaluation is ready. No processes (e.g. serial transmission) are active that prevent an enable.</li> <li>• No blocking process is active (e.g. automatic motor parameter identification)</li> </ul>
<b>Bit 3</b>	
ipo_in_target	The bit is set when the trajectory generator has completed the positioning. In contrast to target_reached, no additional check is made whether the actual position also corresponds to the target position.
<b>Bit 8</b>	
safe_standstill	The bit is set when the controller has entered the safe state "Safe Torque Off" (STO). See also the relevant section in the product manual, e.g. section STO ( <i>Safe Torque Off</i> ) in the BL 4000-C product manual.

With the help of the objects `manufacturer_status_masks` and `manufacturer_status_invert` one or more bits of the `manufacturer_statuswords` can be mapped into bit 14 (manufacturer\_statusbit) of the `statusword` (6041<sub>h</sub>). All bits of the `manufacturer_statusword_1` can be inverted via the corresponding bit in `manufacturer_status_invert_1`. Thus, bits can also be monitored for the "reset" status. After the inversion the bits are masked, i.e. only if the corresponding bit in `manufacturer_status_mask_1` is set, the bit is further evaluated. If at least one bit is still set after masking, bit 14 of the `statusword` is also set. The following figure illustrates this as an example:



### EXAMPLE

Bit 14 of the statusword should be set if the drive is referenced:

Object	Value	
<code>manufacturer_status_invert_1</code>	0x00000000	Invert no bit
<code>manufacturer_status_mask_1</code>	0x00000001	Show bit 0

Bit 14 of the statusword should be set if the drive has **no** valid commutation position:

Object	Value	
<code>manufacturer_status_invert_1</code>	0x00000002	Invert bit 1
<code>manufacturer_status_mask_1</code>	0x00000002	Show bit 1

Bit 14 of the statusword should be set if the drive is not ready for enable OR referenced:

Object	Value	
<code>manufacturer_status_invert_1</code>	0x00000004	Invert bit 2
<code>manufacturer_status_mask_1</code>	0x00000005	Show bit 0 and bit 2

### 4.5.3 Object 2005<sub>h</sub>: manufacturer\_status\_masks

This object group is used to specify which set bits of the **manufacturer\_statuswords** are mapped into the **statusword**.

Index	2005 <sub>h</sub>			
Name	manufacturer_status_masks			
Type	RECORD	01 <sub>h</sub>		
Sub-Index	01 <sub>h</sub>			
Name	manufacturer_status_mask_1			
Info	--	rw	PDO	UINT32
Value	--	0		

### 4.5.4 Object 200A<sub>h</sub>: manufacturer\_status\_invert

This object group determines which bits of the **manufacturer\_statuswords** are inverted before masking.

Index	200A <sub>h</sub>			
Name	manufacturer_status_invert			
Type	RECORD	01 <sub>h</sub>		
Sub-Index	01 <sub>h</sub>			
Name	manufacturer_status_invert_1			
Info	--	rw	PDO	UINT32
Value	--	0		

### 4.5.5 Object 2001<sub>h</sub>: manufacturer\_warnings

The manufacturer-specific object group **manufacturer\_warnings** shows further states of the servo drive.

Index	2001 <sub>h</sub>			
Name	manufacturer_warnings			
Type	RECORD	01 <sub>h</sub>		
Sub-Index	01 <sub>h</sub>			
Name	manufacturer_warnings_1			
Info	--	ro	PDO	UINT32
Value	--	--		

Bit	Value	Name
0	00000001 <sub>h</sub>	l_lim_switch_lock
1	00000002 <sub>h</sub>	r_lim_switch_lock
2	00000004 <sub>h</sub>	warning_active

Bit 0	
l_lim_switch_lock	This bit indicates that the direction is locked because the left limit switch has been triggered. The setpoint lock is reset when an error acknowledgement is performed (See <a href="#">controlword</a> , <a href="#">fault_reset</a> ).
Bit 1	
r_lim_switch_lock	This bit indicates that the direction is locked because the right limit switch has been triggered. The setpoint lock is reset when an error acknowledgement is performed (See <a href="#">controlword</a> , <a href="#">fault_reset</a> ).
Bit 2	
warning_active	This bit indicates that a warning is active in the servo drive, see the corresponding section in the product manual, e.g. section <i>Fault messages</i> in the BL 4000 Product manual.

With the help of the [manufacturer\\_warning\\_masks](#) object, one or more bits of the [manufacturer\\_warnings](#) can be mapped into bit 7 (warning) of the [statusword](#) (6041<sub>h</sub>). Only if the corresponding bit in [manufacturer\\_warning\\_mask\\_1](#) is set, the bit is further evaluated. If at least one bit is still set after masking, bit 7 of the [statusword](#) is also set.

#### 4.5.6 Object 2006<sub>h</sub>: manufacturer\_warning\_masks

This object group determines which set bits of the [manufacturer\\_warnings](#) object are mapped into the [statusword](#).

Index	2006 <sub>h</sub>			
Name	manufacturer_warning_masks			
Type	RECORD	01 <sub>h</sub>		
Sub-Index	01 <sub>h</sub>			
Name	manufacturer_warning_mask_1			
Info	--	rw	PDO	UINT32
Value	--	0		

## 4.6 Description of further objects

### 4.6.1 Object 605B<sub>h</sub>: shutdown\_option\_code

The `shutdown_option_code` is used to specify how the servocontroller behaves during state transition 8 (from OPERATION\_ENABLE to READY\_TO\_SWITCH\_ON). The object indicates the unchangeable behavior of the servocontroller.

Index	605B <sub>h</sub>		
Name	shutdown_option_code		
Info	--	rw	<del>PBC</del> INT16
Value	0	--	

Value	Name
0	Output stage will be switched off, motor can rotate freely

### 4.6.2 Object 605C<sub>h</sub>: disable\_operation\_option\_code

The `disable_operation_option_code` object is used to specify how the servocontroller behaves during state transition 5 (from OPERATION\_ENABLE to SWITCHED\_ON). The object indicates the unchangeable behavior of the servocontroller.

Index	605C <sub>h</sub>		
Name	disable_operation_option_code		
Info	--	rw	<del>PBC</del> INT16
Value	-1	--	

Value	Name
-1	Decelerate with <code>quickstop_deceleration</code>

### 4.6.3 Object 605A<sub>h</sub>: quick\_stop\_option\_code

The Parameter `quick_stop_option_code` is used to specify how the servocontroller behaves in the event of a `Quick Stop`. The object indicates the unchangeable behavior of the servocontroller.

Index	605A <sub>h</sub>		
Name	quick_stop_option_code		
Info	--	rw	<del>PBC</del> INT16
Value	2	--	

Value	Name
2	Decelerate with <code>quickstop_deceleration</code>



#### 4.6.4 Object 605E<sub>h</sub>: fault\_reaction\_option\_code

The `fault_reaction_option_code` object is used to specify how the servo drive behaves in the event of a fault. Since the error reaction depends on the respective error, this object cannot be parameterised and always returns 0. To change the error reaction of the individual errors see section 3.18 *Error management* on page 100.

Index	605E <sub>h</sub>		
Name	fault_reaction_option_code		
Info	--	rw	<del>PBC</del> INT16
Value	0	--	

## 5 Operating modes

### 5.1 Setting the operating mode

#### 5.1.1 Overview

The servocontroller can be set to a variety of operating modes. Only a few are specified in detail under CANopen:

- torque-controlled operation (profile torque mode)
- speed-controlled operation (profile velocity mode)
- homing mode
- positioning mode (profile position mode)
- synchronous position mode (CANopen: interpolated position mode, Ethercat: cyclic synchronous position mode)

#### 5.1.2 Description of objects

##### 5.1.2.1 Object 6060<sub>h</sub>: modes\_of\_operation

The `modes_of_operation` object is used to set the operating mode of the servocontroller.

Index	6060 <sub>h</sub>			
Name	modes_of_operation			
Info	--	rw	PDO	INT8
Value	1, 3, 4, 6, 7, 8	--		

Value	Action
1	Profile Position Mode (Position control with positioning mode)
3	Profile Velocity Mode (Speed control with setpoint ramp)
4	Profile Torque Mode (Torque control with setpoint ramp)
6	Homing Mode (Reference run)
7	Interpolated Position Mode
8	Cyclic Synchronous Position Mode

#### **INFORMATION** Current operating mode

The current operating mode can only be read from the object `modes_of_operation_display`. Since changing the operating mode can take some time, you must wait until the newly selected mode appears in the object `modes_of_operation_display`.

### 5.1.2.2 Object 6061h: modes\_of\_operation\_display

The current operating mode of the servocontroller can be read with object `modes_of_operation_display`.

Index	6061 <sub>h</sub>		
Name	modes_of_operation_display		
Info	--	ro	PDO INT8
Value	-14, -13, -11, -1, 1, 3, 4, 6, 7, 8	--	

If an operating mode is set via object 6060<sub>h</sub>, in addition to setting the actual operating mode, the setpoint selector is also modified as follows to ensure operation of the servocontroller under CANopen:

Selector	Profile Velocity Mode	Profile Torque Mode
A	Speed setpoint (Fieldbus 1)	Torque setpoint (Fieldbus 1)
B	Torque limitation, if applicable	inactive
C	Speed setpoint (synchronous speed)	inactive

In addition, the setpoint ramp will always be switched on. Only if these settings are made in the mentioned way, one of the CANopen operating modes is displayed. If these settings are changed e.g. with the MPC ServoCommander, the appropriate "User" mode is displayed to indicate that the selectors have been changed.

Value	Mode
-1	Unknown operating mode / operating mode change
-11	User Position Mode
-13	User Velocity Mode
-14	User Torque Mode
1	Profile Position Mode
3	Profile Velocity Mode
4	Torque Profile Mode
6	Homing Mode
7	Interpolated Position Mode
8	Cyclic Synchronous Position Mode

#### **INFORMATION** Setting the operating mode

The operating mode can only be set via object `modes_of_operation`. Since changing the operating mode can take some time, you have to wait until the newly selected mode appears in object `modes_of_operation_display`. During this period, "invalid operating mode" (-1) may be displayed briefly.

## 5.2 Homing Mode

### 5.2.1 Overview

This chapter describes how the servo drive searches for the initial position (also called reference point or zero point). There are different methods to determine this position, either the limit switches at the end of the positioning range can be used or a reference switch (zero point switch) within the possible positioning range. In order to achieve the greatest possible reproducibility, the zero pulse of the angle encoder used (resolver, incremental encoder, etc.) can be included in some methods.




Figure 10: Homing

The user can determine the speed, acceleration and type of homing. The `home_offset` object can be used to move the zero position of the servo drive to any position. There are two homing speeds. The higher search speed (`speed_during_search_for_switch`) is used to find the limit switch or the reference switch. In order to subsequently be able to determine the position of the relevant switching edge exactly, the crawling speed (`speed_during_search_for_zero`) will be used. The maximum distance searched for switches is calculated from the difference of objects `607Dh_01h` und `607Dh_02h` (see section 3.7.2.14 *Object 607D<sub>h</sub>: software\_position\_limit* on page 70). If no switch is found within this distance, error 11-6 (Homing: end of search distance reached) is triggered.

#### **INFORMATION** Homing behaviour can be parameterised

The following homing behaviour can be modified:

- If the reference run is started via the `controlword`, the servo drive does not necessarily move to the zero position after the reference run. If the servo drive knows all the required values (e.g. because it already knows the position of the zero pulse), no physical movement is carried out.
- The maximum search distance is determined by object `607Dh`.

If bit 6 of the object `6510h_F0h` (`compatibility_control`) is set, the settings defined in the MPC ServoCommander are used instead (siehe section 3.2 *Compatibility settings* on page 41).

If the drive should not be referenced, but only the position should be set to a certain value, object `2030h` (`set_position_absolute`) can be used. For this see section 3.7.2.13 *Object 2030<sub>h</sub>: set\_position\_absolute* on page 69.

## 5.2.2 Description of objects

### 5.2.2.1 Important objects in other sections

Index	Name	Section	Page
6040 <sub>h</sub>	controlword	Device Control	102
6041 <sub>h</sub>	statusword		

### 5.2.2.2 Object 607C<sub>h</sub>: home\_offset

The **home\_offset** object specifies the offset of the zero position with respect to the determined reference position. The effect of this object can be customised. See also section section 3.2.2.1 *Object 6510h\_F0h: compatibility\_control* on page 41.

Index	607C <sub>h</sub>			
Name	home_offset			
Info	position_unit	rw	PDO	INT32
Value	--			

### 5.2.2.3 Object 6098<sub>h</sub>: homing\_method

A number of different methods are provided for a homing run. The variant required for the application can be selected via the **homing\_method** object. There are four possible homing signals: the negative and positive limit switches, the reference switch and the (periodic) zero pulse of the angle encoder.

In addition, the servo drive can reference to the negative or positive stop without any additional signal at all. If a method for referencing is set via the object **homing\_method**, the following settings are determined with this:

- The reference source (neg./pos. limit switch, the reference switch, neg. / pos. stop).
- The direction and the sequence of the homing
- The method of evaluation of the zero pulse from the used angle encoder

Index	6098 <sub>h</sub>			
Name	homing_method			
Info	--	rw	PDO	INT8
Value	-18, -17, -2, -1, 1, 2, 7, 11, 17, 18, 23, 27, 32, 33, 34, 35			

	Direction	Target	Reference point for zero	DS402
-18	positive	Stop	Stop	-18
-17	negative	Stop	Stop	-17
-2	positive	Stop	Zero pulse	-2
-1	negative	Stop	Zero pulse	-1
1	negative	Limit switch	Zero pulse	1
2	positive	Limit switch	Zero pulse	2
7	positive	Reference switch	Zero pulse	7
11	negative	Reference switch	Zero pulse	11
17	negative	Limit switch	Limit switch	17
18	positive	Limit switch	Limit switch	18
23	positive	Reference switch	Reference switch	23
27	negative	Reference switch	Reference switch	27
32	negative	Zero pulse	Zero pulse	<b>33</b>
33	positive	Zero pulse	Zero pulse	<b>34</b>
34		No movement	Current actual position	<b>35</b>

#### **INFORMATION** Homing methods not assigned according to DS402

In previous CANopen implementations the homing methods 32, 33, 34 and 35 are not assigned according to DS402. Therefore, it is possible to select the assignment according to DS402 via object `compatibility_control` (siehe section 3.2 *Compatibility settings* on page 41). In this case, the method numbers in the column "DS402" must be used.

For compatibility with previous versions, no changes need to be made and the previous numbers can be used.

The `homing_method` can only be changed if homing is not active. Otherwise the error message 08 00 00 22h is returned. The sequence of the individual methods is explained in detail in section 5.2.3 *Homing sequences* on page 128.

#### 5.2.2.4 Object 6099<sub>h</sub>: homing\_speeds

This object determines the speeds used during homing.

Index	6099 <sub>h</sub>			
Name	homing_speeds			
Type	ARRAY			02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	speed_during_search_for_switch			
Info	speed_unit	rw	PDO	UINT32
Value	--	--		

Sub-Index	02 <sub>h</sub>			
Name	speed_during_search_for_zero			
Info	speed_unit	rw	PDO	UINT32
Value	--	--		

**INFORMATION** Setting bit 6 in the object compatibility\_control

If bit 6 in object `compatibility_control`, (siehe section 3.2 *Compatibility settings* on page 41) is set, a movement to zero can be carried out after the homing, for example.

If this bit is set and object `speed_during_search_for_switch` is written, the speed for searching the switch as well as the speed for moving to zero are written together.

### 5.2.2.5 Object 609A<sub>h</sub>: homing\_acceleration

This object specifies the acceleration used for all acceleration and deceleration processes during the homing run.

Index	609A <sub>h</sub>			
Name	homing_acceleration			
Info	acceleration_unit	rw	PDO	UINT32
Value	--	--		

### 5.2.2.6 Object 2045<sub>h</sub>: homing\_timeout

The homing run can be monitored for its maximum execution time. For this purpose, the maximum execution time can be specified with the `homing_timeout` object. If this time is exceeded without the homing run being completed, error 11-3 is triggered. If 0 is written to the object, monitoring is deactivated.

Index	2045 <sub>h</sub>			
Name	homing_timeout			
Info	ms	rw	<del>PDO</del>	UINT16
Value	0, 1 ... 65535	--		

## 5.2.3 Homing sequences

### 5.2.3.1 Methods -17 and -18: Stop

If this method is used, the drive moves in the positive direction (-18) or negative direction (-17) until it reaches the stop. Normally, a 50% increase of the  $i^2t$  value is used as the criterion for detecting the stop. Alternatively, a comparison torque value at which the stop will be considered as detected can be specified (see section *Tab: Torques* in the respective product manual). The mechanical design of the stop must be such that it cannot be damaged with the parameterised maximum current. The home position refers directly to the stop. Since, in this case, the home position would be located directly at the stop, the parameter **Offset start position** should be used to shift the home position in a suitable manner.




Figure 11: Homing run to the stop




Figure 12: Use of "Offset start position"

### 5.2.3.2 Methods -1 and -2: stop with index pulse evaluation

These methods correspond to the methods -17 and -18. However, the home position also refers to the first index pulse of the angle encoder in the negative (-2) or positive (-1) direction as seen from the stop.




Figure 13: Homing run to the stop with index pulse evaluation



### 5.2.3.3 Methods 17 and 18: positive and negative limit switch

If these methods are used, the drive moves in the positive direction (18) or negative direction (17) at search speed until it reaches the limit switch. Then, the drive moves back at crawl speed and tries to find the exact position of the limit switch. The home position refers to the falling edge of the limit switch.




Figure 14: Homing run to the limit switch

### 5.2.3.4 Methods 1 and 2: positive and negative limit switch with index pulse evaluation

Like in the case of the previous method, the system tries to find the limit switch. However, in this case, the home position refers to the first index pulse of the angle encoder in the negative (1) or positive (2) direction as seen from the limit switch.




Figure 15: Homing run to the limit switch with index pulse evaluation

### 5.2.3.5 Methods 23 and 27: reference switch

These two methods use a reference switch which is active only over a certain part of the distance. This method is particularly suitable for rotary axis applications in which the reference switch is activated once during every rotation. If this method is used, the drive moves in the positive direction (23) or negative direction (27) at search speed until it reaches the reference switch. Then, the drive moves back at crawl speed and tries to find the exact position of the reference switch. The home position refers to the falling edge of the reference switch. If, at the beginning, the drive moves away from the reference switch, the associated limit switch causes a reversal of the direction of rotation so that the reference switch will be found.




Figure 16: Homing run to the reference switch

### 5.2.3.6 Methods 7 and 11: reference switch and index pulse evaluation

Like methods 23 and 27, methods 7 and 11 use the reference switch. In addition, however, the home position refers to the first index pulse in the negative or positive direction as seen from the reference switch.




Figure 17: Homing run to the reference switch with index pulse evaluation

### 5.2.3.7 Methods -23 and -27: homing run (positive/negative) to the reference switch

These methods are similar to the methods 23 and 27. However, in this case, the system tries to locate the end of the range of movement, e.g. the stop or a limit switch, in a first step. It is only then that the system searches for the reference switch. As a result, several switches can be connected to the same input for the reference switch. During the homing run, the "last" switch in the search direction will be used as the reference switch. In the case of method -23, the drive moves in the positive direction first, and in the case of method -27, it moves in the negative direction first. The home position refers to the falling edge of the reference switch.




Figure 18: Reference switch with an initial movement in the positive and negative direction

### 5.2.3.8 Methods 32 and 33: homing to the index pulse

In the case of method 32 and method 33, the direction of the homing run is negative or positive. The home position refers to the first index pulse of the angle encoder in the search direction.




Figure 19: Index pulse with a negative (32) and positive (33) initial movement

### 5.2.3.9 Method 34: homing to the current position

In the case of method 34, the home position refers to the current position, i.e. the current position of the drive is set to zero.

## 5.2.4 Homing control

The reference run is controlled and monitored by the **controlword** / **statusword**. Starting is done by setting bit 4 in the **controlword**.

Bit 4	Description
0	Homing is not active
0 ► 1	Start homing
1	Homing is active
1 ◀ 0	Interrupt homing

Successful completion of the homing is indicated by a set bit 12 in the **statusword**. A set bit 13 in the **statusword** indicates that an error occurred during the reference run. The cause of the error can be determined via the **error\_register** and **pre\_defined\_error\_field** objects.

Bit 13	Bit 12	Description
0	0	Reference run is not yet ready
0	1	Reference run carried out successfully
1	0	Reference run not carried out successfully
1	1	Illegal state

## 5.3 Profile Position Mode

### 5.3.1 Overview

The structure of this operating mode can be seen in *Figure 20: Trajectory generator and position controller*:

The `target_position` is transferred to the trajectory generator. This generates a position setpoint (`position_demand_value`) for the position controller, which is described in the Position Controller section (see section 3.7 *Position Controller* on page 63). These two function blocks can be set independently of each other.




Figure 20: Trajectory generator and position controller

### 5.3.2 Functional description

There are two ways to transfer a target position to the servo drive:

#### › Single driving task

When the servo drive has reached a target position, it signals this to the host with the `target_reached` bit (bit 10 in the `statusword` object). In this operating mode, the servo drive stops when it has reached the target.

#### › Sequence of driving tasks

After the servo drive has reached a target, it immediately starts moving to the next target. This transition can be carried out smoothly without the servo drive coming to a standstill in between.

These two methods are controlled by the `new_set_point` and `change_set_immediately` bits in the `controlword` object and `set_point_acknowledge` in the `statusword` object. These bits are in a question-answer relationship to each other. This makes it possible to prepare one motion task while another is still running.




Figure 21: Driving task transfer from a host

The figure above shows how the host and the servo drive communicate with each other via the CAN bus:

First, the positioning data (target position, profile velocity, end velocity and the acceleration) are transmitted to the servo drive. When the positioning data set is completely written (1), the host can start the positioning by setting the bit `new_set_point` in the `controlword` to "1" (2). After the servo drive has recognised the new data and accepted it into its buffer, it reports this to the host by setting the bit `set_point_acknowledge` in the `statusword` (3).

The host can then start writing a new positioning data set into the servo drive (4) and clear the `new_set_point` bit again (5). Only when the servo drive can accept a new motion task (6), it signals this by a "0" in the `set_point_acknowledge` bit. Before that, no new positioning may be started by the host (7).

On the left side of the following figure, a new positioning is started only after the previous one has been completed. The host evaluates the `target_reached` bit in the `statusword` object for this purpose.




Figure 22: Single driving task (left) and sequence of driving tasks (right)

On the right side, a new positioning is already started while the previous one is still being processed. The host transfers the subsequent target to the servo drive as soon as it signals that it has read the buffer and started the associated positioning by clearing the `set_point_acknowledge` bit. In this way, the positioning operations are linked together seamlessly. To prevent the servo drive from briefly decelerating to zero each time between the individual positionings, the object `end_velocity` should be written with the same value as the object `profile_velocity` for this operating mode.

If the bit `change_set_immediately` is set to "1" in the `controlword` in addition to the bit `new_set_point`, the host thereby instructs the servo drive to start the new motion task immediately. A motion task that is already being processed is canceled in this case.

## 5.3.3 Description of objects

### 5.3.3.1 Important objects in other sections

Index	Name	Section	Page
6040 <sub>h</sub>	controlword	4 <i>Device Control</i>	102
6041 <sub>h</sub>	statusword		
605A <sub>h</sub>	quick_stop_option_code		
607E <sub>h</sub>	polarity	3.3 <i>Factor Group</i>	43
6093 <sub>h</sub>	position_factor		
6094 <sub>h</sub>	velocity_encoder_factor		
6097 <sub>h</sub>	acceleration_factor		

### 5.3.3.2 Object 607A<sub>h</sub>: target\_position

The object **target\_position** determines to which position the servo drive should move. The current setting of the speed, acceleration, deceleration and the type of motion profile (**motion\_profile\_type**) must be taken into account. The target position (**target\_position**) is interpreted either as an absolute or relative value (**controlword**, Bit 6).

Index	607A <sub>h</sub>			
Name	target_position			
Info	position_unit	rw	PDO	INT32
Value	--	--		

### 5.3.3.3 Object 6081<sub>h</sub>: profile\_velocity

The **profile\_velocity** object specifies the velocity that is normally reached during a positioning at the end of the acceleration ramp. The **profile\_velocity** object is specified in speed\_unit.

Index	6081 <sub>h</sub>			
Name	profile_velocity			
Info	speed_unit	rw	PDO	UINT32
Value	--	--		



#### 5.3.3.4 Object 6082<sub>h</sub>: end\_velocity

The **end\_velocity** object defines the velocity that the drive must have when it reaches the **target\_position**. Normally this object is to be set to zero so that the servo drive stops when it reaches the target position. For gapless positioning, a velocity other than zero can be specified. The **end\_velocity** object is specified in the same unit as the **profile\_velocity** object.

Index	6082 <sub>h</sub>			
Name	end_velocity			
Info	speed_unit	rw	PDO	UINT32
Value	--	--		

#### 5.3.3.5 Object 6083<sub>h</sub>: profile\_acceleration

The **profile\_acceleration** object specifies the acceleration used to accelerate to the setpoint. It is specified in user-defined unit (acceleration\_unit).

Index	6083 <sub>h</sub>			
Name	profile_acceleration			
Info	acceleration_unit	rw	PDO	UINT32
Value	--	--		

#### 5.3.3.6 Object 6084<sub>h</sub>: profile\_deceleration

The **profile\_deceleration** object specifies the acceleration with which braking is performed. It is specified in user-defined unit (acceleration\_unit).

Index	6084 <sub>h</sub>			
Name	profile_deceleration			
Info	acceleration_unit	rw	PDO	UINT32
Value	--	--		

#### 5.3.3.7 Object 6085<sub>h</sub>: quick\_stop\_deceleration

The **quick\_stop\_deceleration** object specifies the deceleration with which the motor stops when a quick stop is executed (see section 4.2.2 *State diagram: State transitions* on page 105). The **quick\_stop\_deceleration** object is specified in the same unit as the **profile\_deceleration** object.

Index	6085 <sub>h</sub>			
Name	quick_stop_deceleration			
Info	acceleration_unit	rw	PDO	UINT32
Value	--	--		

### 5.3.3.8 Object 6086<sub>h</sub>: motion\_profile\_type

The **motion\_profile\_type** object is used to select the type of positioning profile.

Index	6086 <sub>h</sub>			
Name	motion_profile_type			
Info	--	rw	PDO	INT16
Value	0, 2	--		

Value	Profile
0	Linear profile
2	Jerkfree profile

## 5.4 Interpolated Position Mode

### 5.4.1 Overview

In Interpolated Position Mode (IP), the servo drive follows cyclical position setpoints, e.g. in a multi-axis application of the servo drive. For this purpose, synchronization telegrams (SYNC) and position setpoints are given by a superordinate control in a fixed time grid (synchronization interval,  $t_p$ ). Since the interval is usually greater than one position control cycle ( $t_x$ ), the servo drive interpolates the data values between two specified position values, as outlined in the following graphic.




Figure 23: Linear interpolation between two data values

In the following, the objects required for the Interpolated Position Mode are described first. In a subsequent functional description, the activation and the sequence of the parameterization are dealt with comprehensively.

### 5.4.2 Functional description

Before the servo drive can be switched to **Interpolated Position Mode**, various settings must be made: These include the setting of the interpolation interval (**interpolation\_time\_period**), i.e. the time between two SYNC telegrams, the interpolation type (**interpolation\_submode\_select**) and the type of synchronization (**interpolation\_sync\_definition**). In addition, access to the position buffer must be enabled via the object **buffer\_clear**. To change the interpolation interval (cycle time), the parameter set must be saved once and the servo drive restarted. Whether the correct interval is set can be read out via the object **synchronous\_window\_length** (1006<sub>n</sub>). If the correct interval is already set, the first four steps in the following example can be omitted.

## EXAMPLE

The example shows which steps are necessary to prepare the servo drive for interpolation operation:

Task	Action
Set time unit (1/10 ms)	60C2 <sub>h</sub> 02 <sub>h</sub> (interpolation_time_index) = -4
Set time interval (2 ms)	60C2 <sub>h</sub> 01 <sub>h</sub> (interpolation_time_units) = 20
Save parameters	1010 <sub>h</sub> 01 <sub>h</sub> (save_all_parameters) = 65766173 <sub>h</sub>
Execute reset	see section 6.6 <i>Network Management (NMT service)</i>
Wait for reboot	see section 6.7 <i>Bootup</i>
Set type of interpolation	60C0 <sub>h</sub> (interpolation_submode_select) = -2
Release buffer	60C4 <sub>h</sub> 06 <sub>h</sub> (buffer_clear) = 1
Start sending SYNC messages	see section 6.5 <i>SYNC message</i>

The further steps are described in the following sections.

The **Interpolated Position Mode** is activated via the object `modes_of_operation` (6060<sub>h</sub>). From this point on, the servo drive attempts to synchronise itself to the external time grid, which is specified by the SYNC telegrams. If the servo drive was able to synchronise successfully, it reports the **Interpolated Position Mode** in the object `modes_of_operation_display` (6061<sub>h</sub>). During synchronization, the servo drive returns "Invalid operation mode". If the SYNC telegrams are not sent in the correct interval after the synchronization has been completed, the servo drive reports "Invalid operating mode" again.

If the change of the operating mode is completed, the transmission of position data to the drive can start. For this purpose, the superordinate control first reads the current actual position from the servo drive and writes it cyclically as the new setpoint (`interpolation_data_record`) to the servo drive. The handshake bits of the `controlword` and the `statusword` are used to activate the acceptance of the data by the servo drive. By setting the bit `enable_ip_mode` in the `controlword` the host indicates that the evaluation of the position data is to be started. The data sets are not evaluated until the servo drive acknowledges this via the `ip_mode_active` status bit in the `statusword`. In detail therefore the following sequence results:




Figure 24: Start of synchronization and data enabling

## EXAMPLE

The example shows which steps are necessary to start the interpolation:

Taks	Action
Send SYNC messages	see 6.5
Request operating mode	6060 <sub>h</sub> (modes_of_operation) = 7
Wait until operating mode is accepted	6061 <sub>h</sub> (modes_of_operation_display) = 7
Read current actual position	6064 <sub>h</sub> (position_actual_value)
Set read actual position as setpoint	60C1 <sub>h_01</sub> (ip_data_position)
Enable interpolation	6040 <sub>h</sub> (controlword), set enable_ip_mode
Wait for acknowledgement by servo drive	6041 <sub>h</sub> (statusword), query ip_mode_active
Move interpolated	

After completion of the synchronous movement, further evaluation of position values can be prevented by clearing the enable\_ip\_mode bit. If necessary, you can then switch to another operating mode.

If a running interpolation (ip\_mode\_active set) is interrupted by the occurrence of a servo drive error, the drive initially behaves as specified for the respective error (e.g. disabling the servo drive and change to SWITCH\_ON\_DISABLED state). Interpolation can then only be continued by resynchronization, since the servo drive must be returned to the OPERATION\_ENABLE state, which clears the ip\_mode\_active bit.

## 5.4.3 Description of objects

### 5.4.3.1 Important objects in other sections

Index	Name	Section	Page
6040 <sub>h</sub>	controlword	4 <i>Device Control</i>	102
6041 <sub>h</sub>	statusword		
6093 <sub>h</sub>	position_factor	3.3 <i>Factor Group</i>	43
6094 <sub>h</sub>	velocity_encoder_factor		
6097 <sub>h</sub>	acceleration_factor		

### 5.4.3.2 Object 60C0<sub>h</sub>: interpolation\_submode\_select

The type of interpolation is defined via the `interpolation_submode_select` object. Currently, only the manufacturer-specific variant "Linear interpolation without buffer" is available.

Index	60C0 <sub>h</sub>		
Name	interpolation_submode_select		
Info	--	rw	PDO INT16
Value	-2	--	

Value	Type of interpolation
-2	Linear interpolation without buffer

### 5.4.3.3 Object 60C1<sub>h</sub>: interpolation\_data\_record

The `interpolation_data_record` object represents the actual data set. It consists of an entry for the position value (`ip_data_position`) and a control word (`ip_data_controlword`), which specifies whether the position value is to be interpreted absolutely or relatively. The control word can be provided optionally. If it is not provided, the position value is interpreted as absolute. If the control word is also to be specified, subindex 2 (`ip_data_controlword`) must be written first and then subindex 1 (`ip_data_position`) for reasons of data consistency, since internally the data transfer is triggered with write access to `ip_data_position`.

Index	60C1 <sub>h</sub>			
Name	interpolation_data_record			
Type	RECORD			02 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	ip_data_position			
Info	position_unit	rw	PDO	INT32
Value	--	--		
Sub-Index	02 <sub>h</sub>			
Name	ip_data_controlword			
Info	--	rw	PDO	UINT8
Value	0, 1	0		

Value	ip_data_position is
0	Absolute
1	Relative

#### **INFORMATION** Internal data transfer

The internal data transfer takes place with write access to sub-index 1. If sub-index 2 is also to be used, it must be written before sub-index 1.

### 5.4.3.4 Object 60C2<sub>h</sub>: interpolation\_time\_period

The synchronisation interval can be set via the `interpolation_time_period` object. The unit (ms or 1/10 ms) of the interval is defined via `ip_time_unit` and then set via `ip_time_index`. In Interpolated Position Mode the entire controller cascade (current, speed and position controller) is synchronised to the external clock. The change of the synchronisation interval therefore only becomes effective after a reset. If the interpolation interval is to be changed via the CAN bus, the parameter set must be saved (see section 3.1 *Loading and saving parameter sets* on page 38) and a reset must be executed (see section 6.6 *Network Management (NMT service)* on page 177) so that the new synchronisation interval takes effect. The synchronisation interval must be met exactly.

Index	<b>60C2<sub>h</sub></b>			
Name	<b>interpolation_time_period</b>			
Type	RECORD			02 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>			
Name	<b>ip_time_units</b>			
Info	according to ip_time_index	rw	PDO	UINT8
Value	ip_time_index = -3: 1, 2, ..., 10 ip_time_index = -4: 10, 20, ..., 100	--		
Sub-Index	<b>02<sub>h</sub></b>			
Name	<b>ip_time_index</b>			
Info	--	rw	PDO	INT8
Value	-3, -4	--		
<b>Value</b>	<b>ip_time_index is given in</b>			
-3	10 <sup>-3</sup> seconds (ms)			
-4	10 <sup>-4</sup> seconds (0.1 ms)			

**INFORMATION** Changing the synchronisation interval

Changing the interpolation cycle time only takes effect after a reset. If the interpolation cycle time is to be changed via the CAN bus, the parameter set must be saved and a reset must be executed.

#### 5.4.3.5 Object 60C3<sub>h</sub>: interpolation\_sync\_definition

Via the object `interpolation_sync_definition` the type (`synchronize_on_group`) and the number (`ip_sync_every_n_event`) of synchronisation telegrams per synchronisation interval is specified. Only the standard SYNC telegram and 1 SYNC per interval can be set.

Index	<b>60C3<sub>h</sub></b>			
Name	<b>interpolation_sync_definition</b>			
Type	ARRAY			02 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>			
Name	<b>synchronize_on_group</b>			
Info	--	rw	PDO	UINT8
Value	0	0		
<b>Value</b>	<b>Description</b>			
0	Use standard SYNC telegram			



Sub-Index	02 <sub>h</sub>			
Name	ip_sync_every_n_event			
Info	--	rw	PDO	UINT8
Value	1	1		

#### 5.4.3.6 Object 60C4<sub>h</sub>: interpolation\_data\_configuration

The object record **interpolation\_data\_configuration** is intended for the configuration of an intermediate buffer. With the only available interpolation type "Linear interpolation without buffer" most entries have no meaning. However, even with this type of interpolation, access to object 60C1<sub>h</sub> must be enabled via object **buffer\_clear**!

Index	60C4 <sub>h</sub>			
Name	interpolation_data_configuration			
Type	RECORD			06 <sub>h</sub>
Sub-Index	01 <sub>h</sub>			
Name	max_buffer_size			
Info	--	ro	<del>PDO</del>	UINT32
Value	0	0		
Sub-Index	02 <sub>h</sub>			
Name	actual_size			
Info	--	rw	PDO	UINT32
Value	0	0		
Sub-Index	03 <sub>h</sub>			
Name	buffer_organisation			
Info	--	rw	PDO	UINT8
Value	0	0		
Value	Description			
0	FIFO			

Sub-Index	04 <sub>h</sub>			
Name	buffer_position			
Info	--	rw	PDO	UINT16
Value	0	0		
Sub-Index	05 <sub>h</sub>			
Name	size_of_data_record			
Info	--	wo	PDO	UINT8
Value	2	2		

Sub-Index	06 <sub>h</sub>			
Name	buffer_clear			
Info	--	wo	PDO	UINT8
Value	0, 1	0		

Value	Description
0	Delete Buffer / Access to 60C1 <sub>h</sub> not allowed
1	Access to 60C1 <sub>h</sub> released

#### 5.4.3.7 Object 1006<sub>h</sub>: communication\_cycle\_period

The set interpolation interval (=bus cycle time) can be read out via object 1006<sub>h</sub> (**communication\_cycle\_period**). It is equal to the time  $t_p$  described in the section *Control circuit cycle times* in the Product manual BL 4000.

Index	1006 <sub>h</sub>			
Name	communication_cycle_period			
Info	μs	rw	<del>PDO</del>	UINT32
Value	--	00000000 <sub>h</sub>		

## 5.5 Cyclic Synchronous Position Mode

### 5.5.1 Overview

Just as in **Interpolated Position Mode (IP)**, in **Cyclic Synchronous Position Mode (CSP)** the servo drive follows cyclic position setpoints in a multi-axis application of the servo drive.

The main differences are:

- The setpoint is specified via the **target\_position (607A<sub>h</sub>)**
- The setpoints are evaluated directly after changing to **Cyclic Synchronous Position Mode**. It is not necessary to set the bit **enable\_ip\_mode** in the controlword and also the object **buffer\_clear (60C4<sub>h</sub>\_06<sub>h</sub>)** must not be written.

### 5.5.2 Description of objects

#### 5.5.2.1 Important objects in other sections

Index	Name	Section	Page
607A <sub>h</sub>	target_position	5.3.3.2 <i>Object 607Ah: target_position</i>	136
60C2 <sub>h</sub>	interpolation_time_ period	5.4 <i>Interpolated Position Mode</i>	102
6040 <sub>h</sub>	controlword	4 <i>Device Control</i>	102
6041 <sub>h</sub>	statusword		
6093 <sub>h</sub>	position_factor	3.3 <i>Factor Group</i>	43
6094 <sub>h</sub>	velocity_encoder_ factor		
6097 <sub>h</sub>	acceleration_factor		

The **Cyclic Synchronous Position Mode** does not define its own objects.

## 5.6 Profile Velocity Mode


### 5.6.1 Overview

The speed-controlled mode (Profile Velocity Mode) includes the following sub-functions:

- Setpoint generation by the ramp generator
- Speed control with suitable input and output signals
- Limitation of the torque setpoint (**torque\_demand\_value**)
- Monitoring of the actual velocity (**velocity\_actual\_value**) with the window function/threshold

The meaning of the following parameters is described in section 5.3

*Profile Position Mode* on page 134: **profile\_acceleration**, **profile\_deceleration**, **quick\_stop\_deceleration**.






Figure 25: Structure of speed-controlled operation (Profile Velocity Mode)

## 5.6.2 Description of objects

### 5.6.2.1 Important objects in other sections

Index	Name	Sections	Page
6040 <sub>h</sub>	controlword	4 <i>Device Control</i>	102
6041 <sub>h</sub>	statusword		
6064 <sub>h</sub>	position_actual_value	3.7 <i>Position Controller</i>	63
6071 <sub>h</sub>	target_torque	5.7 <i>Profile Torque Mode</i>	156
6072 <sub>h</sub>	max_torque_value		
6083 <sub>h</sub>	profile_acceleration	5.3 <i>Profile Position Mode</i>	134
6084 <sub>h</sub>	profile_deceleration		
6085 <sub>h</sub>	quick_stop_deceleration		
6094 <sub>h</sub>	velocity_encoder_factor		

### 5.6.2.2 Object 6069<sub>h</sub>: velocity\_sensor\_actual\_value

With the **object velocity\_sensor\_actual\_value** the value of a possible velocity encoder can be read out in internal units. No separate speed sensor can be connected to BL 4000 servo drives. Therefore, object 606C<sub>h</sub> should always be used to determine the actual speed value.

Index	6069 <sub>h</sub>			
Name	velocity_sensor_actual_value			
Info	rev / 4096 min	ro	PDO	INT32
Value	--	--		

### 5.6.2.3 Object 606A<sub>h</sub>: sensor\_selection\_code

The speed sensor can be selected with this object. Currently, no separate speed sensor is provided. Therefore, only the standard angle encoder can be selected.

Index	606A <sub>h</sub>			
Name	sensor_selection_code			
Info	--	rw	PDO	INT16
Value	0	0		

### 5.6.2.4 Object 606B<sub>h</sub>: velocity\_demand\_value

This object can be used to read out the current speed setpoint of the speed controller, which is generated by the ramp generator or the trajectory generator. If the position controller is activated, its correction speed is also added.

Index	606B <sub>h</sub>			
Name	velocity_demand_value			
Info	speed_unit	ro	PDO	INT32
Value	--	--		

### 5.6.2.5 Object 202E<sub>h</sub>: velocity\_demand\_sync\_value

The setpoint speed of the synchronisation encoder can be read out via this object. This is defined by object 2022<sub>h</sub> **synchronization\_encoder\_select** (section 3.11 *Setpoint / actual value selection* on page 78).

Index	202E <sub>h</sub>			
Name	velocity_demand_sync_value			
Info	speed_unit	ro	<del>PDO</del>	INT32
Value	--	--		

### 5.6.2.6 Object 606C<sub>h</sub>: velocity\_actual\_value

The actual speed value can be read out via this object.

Index	606C <sub>h</sub>			
Name	velocity_actual_value			
Info	speed_unit	ro	PDO	INT32
Value	--	--	--	--

### 5.6.2.7 Object 2074<sub>h</sub>: velocity\_actual\_value\_filtered

The **velocity\_actual\_value\_filtered** object can be used to read out a filtered **actual velocity value** that should only be used for display purposes. In contrast to **velocity\_actual\_value**, **velocity\_actual\_value\_filtered** is not used in the velocity control loop, but is used to protect the servo drive against overspeed. The filter time constant can be set via Object 2073<sub>h</sub> (**velocity\_display\_filter\_time**). See section 3.6.2.2 *Object 2073h: velocity\_display\_filter\_time* on page 62.

Index	2074 <sub>h</sub>			
Name	velocity_actual_value_filtered			
Info	speed_unit	ro	PDO	INT32
Value	--	--	--	--




Figure 26: Determining **velocity\_actual\_value** and **velocity\_actual\_value\_filtered**

### 5.6.2.8 Object 606D<sub>h</sub>: velocity\_window

The **velocity\_window\_time** and **velocity\_window** objects are used to set the window comparator for comparing the actual speed value with the **target velocity** (object 60FF<sub>h</sub>). To set bit 10 **target\_reached** in the **statusword** object, the speed must be within **velocity\_window** for the time specified in **velocity\_window\_time**.

Index	606D <sub>h</sub>			
Name	velocity_window			
Info	speed_unit	rw	PDO	UINT16
Value	--	--		

### 5.6.2.9 Object 606E<sub>h</sub>: velocity\_window\_time

The **velocity\_window\_time** and **velocity\_window** objects are used to set the window comparator for comparing the actual speed value with the **target velocity** (object 60FF<sub>h</sub>). To set bit 10 **target\_reached** in the **statusword** object, the speed must be within **velocity\_window** for the time specified in **velocity\_window\_time**.

Index	606E <sub>h</sub>			
Name	velocity_window_time			
Info	ms	rw	PDO	UINT16
Value	0...4999	0		

### 5.6.2.10 Object 606F<sub>h</sub>: velocity\_threshold

The **velocity\_threshold** and **velocity\_threshold\_time** objects specify the actual speed value at which the drive is considered to be standing still. If the drive exceeds the speed specified under **velocity\_threshold** for **velocity\_threshold\_time**, bit 12 (velocity = 0) is deleted in the **statusword**.

Index	606F <sub>h</sub>			
Name	velocity_threshold			
Info	speed_unit	rw	PDO	UINT16
Value	--	--		



### 5.6.2.11 Object 6070<sub>h</sub>: velocity\_threshold\_time

The **velocity\_threshold** and **velocity\_threshold\_time** objects specify the actual speed value at which the drive is considered to be standing still. If the drive exceeds the speed specified under **velocity\_threshold** for **velocity\_threshold\_time**, bit 12 (velocity = 0) is deleted in the **statusword**.

Index	<b>6070<sub>h</sub></b>			
Name	<b>velocity_threshold_time</b>			
Info	ms	rw	PDO	UINT16
Value	0...4999	0		

### 5.6.2.12 Object 6080<sub>h</sub>: max\_motor\_speed

The **max\_motor\_speed** object gives the highest permitted speed for the motor in min<sup>-1</sup>. The object is used to protect the motor and can be taken from the motor data sheet. The speed setpoint is limited to this value.

Index	<b>6080<sub>h</sub></b>			
Name	<b>max_motor_speed</b>			
Info	min <sup>-1</sup>	rw	PDO	UINT16
Value	0...32767	--		

### 5.6.2.13 Object 60FF<sub>h</sub>: target\_velocity

The **target\_velocity** object is the setpoint for the ramp generator.

Index	<b>60FF<sub>h</sub></b>			
Name	<b>target_velocity</b>			
Info	speed_unit	rw	PDO	INT32
Value	--	--		

### 5.6.2.14 Speed ramps

If Profile Velocity Mode is selected as `modes_of_operation`, the setpoint ramp is also activated. Thus it is possible to limit a step-shaped setpoint change to a certain velocity change per time via the `profile_acceleration` and `profile_deceleration` objects. The servo drive not only offers the possibility to use different values for deceleration and acceleration, but also to set different accelerations for positive and negative speed. The following figure illustrates this behavior:




Figure 27: Speed ramps

To be able to parameterise these 4 accelerations individually, the `velocity_ramps` object group is available. It should be noted that the `profile_acceleration` and `profile_deceleration` objects change the same internal accelerations as the `velocity_ramps`. If the `profile_acceleration` is written, `velocity_acceleration_pos` and `velocity_acceleration_neg` are changed together, if the `profile_deceleration` is written, `velocity_deceleration_pos` and `velocity_deceleration_neg` are changed together.

If a 1 is written to the `velocity_ramps_enable` object, the setpoints are passed through the ramp generator.

Index	2090 <sub>h</sub>		
Name	velocity_ramps		
Type	RECORD		05 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	velocity_rampe_enable		
Info	--	rw	<del>PBO</del> UINT8
Value	0, 1	--	
Sub-Index	02 <sub>h</sub>		
Name	velocity_acceleration_pos		
Info	acceleration_unit	rw	<del>PBO</del> INT32
Value	--	--	
Sub-Index	03 <sub>h</sub>		
Name	velocity_deceleration_pos		
Info	acceleration_unit	rw	<del>PBO</del> INT32
Value	--	--	

Sub-Index	<b>04<sub>h</sub></b>		
Name	<b>velocity_acceleration_neg</b>		
Info	acceleration_unit	rw	<del>PBC</del> INT32
Value	--	--	
Sub-Index	<b>05<sub>h</sub></b>		
Name	<b>velocity_deceleration_neg</b>		
Info	acceleration_unit	rw	<del>PBC</del> INT32
Value	--	--	

## 5.7 Profile Torque Mode

### 5.7.1 Overview

This chapter describes the torque controlled operation. This operating mode allows the servo drive to use an external torque setpoint (**target\_torque**), which can be smoothed by the integrated ramp generator. Thus it is possible to use the servo drive in applications where both the position controller and the speed controller are shifted to a superordinate control.




Figure 28: Structure of the torque-controlled operation mode

The **torque\_slope** and **torque\_profile\_type** parameters must be specified for the ramp generator. If bit 8 **halt** is set in the **controlword**, the ramp generator reduces the torque to zero. Accordingly, it increases it again to the **target\_torque**, if bit 8 is deleted again. In both cases the ramp generator considers the **torque\_slope** and the **torque\_profile\_type**. All definitions within this chapter refer to rotary motors. If linear motors are used, all "torque" objects must refer to a "force" instead. For simplicity, the objects are not duplicated and their names should not be changed. The operating modes **Profile Position Mode** and **Profile Velocity Mode** require the torque controller for their function. Therefore, it is always necessary to parameterise it.

## 5.7.2 Description of objects

### 5.7.2.1 Important objects from other sections

Index	Name	Section	Page
6040 <sub>h</sub>	controlword	4 <i>Device Control</i>	92
60F9 <sub>h</sub>	motor_parameters	3.5 <i>Current controller and motor adaption</i>	54
6075 <sub>h</sub>	motor_rated_current		
6073 <sub>h</sub>	max_current		

### 5.7.2.2 Object 6071<sub>h</sub>: target\_torque

This parameter is the input value for the torque controller in torque-controlled mode (section 5.7 *Profile Torque Mode* on page 156). It is specified in thousandths of the nominal torque (object 6076<sub>h</sub>).

Index	6071 <sub>h</sub>			
Name	target_torque			
Info	% (1000 = motor_rated torque)	rw	PDO	INT16
Value	--	--	--	--

### 5.7.2.3 Object 6072<sub>h</sub>: max\_torque

This value represents the maximum permissible torque of the motor. It is specified in thousandths of the nominal torque (object 6076<sub>h</sub>). If, for example, a twofold overload of the motor is permissible for a short time, the value 2000 must be entered here.

**INFORMATION** Object 6072<sub>h</sub> and Object 6073<sub>h</sub> are dependent on each other

Object 6072<sub>h</sub> (max\_torque) and object 6073<sub>h</sub> (max\_current) are dependent on each other and may only be written if object 6075<sub>h</sub> (motor\_rated\_current) has been written with a valid value beforehand.

Index	6072 <sub>h</sub>			
Name	max_torque			
Info	% (1000 = motor_rated torque)	rw	PDO	UINT16
Value	1000...65535	--	--	--

### 5.7.2.4 Object 6074<sub>h</sub>: torque\_demand\_value

This object can be used to read out the current torque setpoint in thousandths of the nominal torque (6076<sub>h</sub>). The internal limitations of the servo drive (current limits and I<sup>2</sup>t-monitoring) are taken into account here.

Index	<b>6074<sub>h</sub></b>			
Name	<b>torque_demand_value</b>			
Info	% (1000 = motor Rated torque)	ro	PDO	INT16
Value	--	--		

### 5.7.2.5 Object 6076<sub>h</sub>: motor Rated torque

This object indicates the nominal torque of the motor. This can be taken from the type plate of the motor. It must be entered in the unit 0.001 Nm.

Index	<b>6076<sub>h</sub></b>			
Name	<b>motor Rated torque</b>			
Info	0.001 Nm	rw	PDO	UINT32
Value	--	--		

### 5.7.2.6 Object 6077<sub>h</sub>: torque\_actual\_value

This object can be used to read out the actual torque value of the motor in thousandths of the nominal torque (object 6076<sub>h</sub>).

Index	<b>6077<sub>h</sub></b>			
Name	<b>torque_actual_value</b>			
Info	% (1000 = motor Rated torque)	ro	PDO	INT16
Value	--	--		

### 5.7.2.7 Object 6078<sub>h</sub>: current\_actual\_value

This object can be used to read out the actual current value of the motor in thousandths of the rated current (object 6075<sub>h</sub>).

Index	<b>6078<sub>h</sub></b>			
Name	<b>current_actual_value</b>			
Info	% (1000 = motor Rated current)	ro	PDO	INT16
Value	--	--		

### 5.7.2.8 Object 6079<sub>h</sub>: dc\_link\_circuit\_voltage

The DC link voltage of the servo drive can be read out via this object. The voltage is specified in the unit millivolts.

Index	6079 <sub>h</sub>			
Name	dc_link_circuit_voltage			
Info	mV	ro	PDO	UINT32
Value	--	--		

### 5.7.2.9 Object 6087<sub>h</sub>: torque\_slope

This parameter describes the rate of change of the setpoint ramp. This is to be specified in thousandths of the nominal torque per second. For example, the torque setpoint **target\_torque** is increased from 0 Nm to the value **motorRatedTorque**. If the output value of the torque ramp should reach this value in one second, then the value 1000 must be written into this object.

Index	6087 <sub>h</sub>			
Name	torque_slope			
Info	motorRatedTorque / 1000 s	rw	PDO	UINT32
Value	--	--		

### 5.7.2.10 Object 6088<sub>h</sub>: torque\_profile\_type

The **torque\_profile\_type** object is used to specify the waveform with which a setpoint step is executed. At present, only the linear ramp is implemented in this servo drive, so that this object can only be written with the value 0.

Index	6088 <sub>h</sub>			
Name	torque_profile_type			
Info	--	rw	PDO	INT16
Value	0	0		

Value	Description
0	Linear ramp

# 6 Detailed description of the CANopen protocol


## 6.1 Introduction

CANopen provides a simple and standardised way to access the parameters of the servo drive (e.g. the maximum motor current). For this purpose, each parameter (CAN object) is assigned a unique number (index and subindex). The totality of all parameters is called the object dictionary. Two main methods are available for accessing the CAN objects via the CAN bus: A confirmed access method, in which the servo drive acknowledges each parameter access (via SDOs) and an unconfirmed access method, in which no acknowledgement is made (via PDOs). As a rule, the servo drive is parameterised via SDOs, while the cyclic process data is exchanged via PDOs.

The following communication objects are defined in total:

SDO	Service Data Object	Are used for normal parameterization of the servo drive
PDO	Process Data Object	Fast exchange of process data (e.g. actual speed) possible
SYNC	Synchronization Message	Synchronization of multiple CAN nodes
EMCY	Emergency Message	Transfer of error messages
NMT	Network Management	Network service: For example, all CAN nodes can be acted upon simultaneously
BOOTUP	Error Control Protocol	Bootup message
HEARTBEAT	Error Control Protocol	Monitoring of communication participants through periodic messages
NODEGUARDING	Error Control Protocol	Monitoring of communication participants through periodic messages

Each message sent on the CAN bus contains a type of address which can be used to determine for which bus station the message is intended. This number is called identifier. The lower the identifier, the higher the priority of the message. Identifiers are defined for each of the communication objects mentioned above. The following figure shows the basic structure of a CANopen message:






## 6.2 Access via SDO

The object dictionary of the servo drive can be accessed via the **service data objects** (SDO). SDO accesses always originate from the superordinate control (host). The host sends either a write command to the servo drive to change a parameter of the object dictionary or a read command to read out a parameter. For each command, the host receives a response that either contains the read value or - in the case of a write command - serves as an acknowledgement. To allow the servo drive to recognise that the command is intended for it, the host must send the command with a specific identifier. **This identifier consists of the base 600h + node number of the servo drive concerned. The servo drive responds accordingly with the identifier 580h + node number.** The structure of the commands or the responses depends on the data type of the object to be read or written, since either 1, 2 or 4 data bytes must be sent or received. The following data types are supported:

UINT8	8-bit value unsigned	0 ... 255
INT8	8-bit value signed	-128 ... 127
UINT16	16-bit value unsigned	0 ... 65536
INT16	16-bit value signed	-32768 ... 32767
UINT32	32-bit value unsigned	0 ... $(2^{32} - 1)$
INT32	32-bit value signed	$-(2^{31})$ ... $(2^{31} - 1)$
VISSTR	Visible string	---

## 6.2.1 SDO sequences for reading and writing

In order to read or write objects of these number types, the sequences listed below are to be used. The commands for writing a value to the servo drive start with a different identifier depending on the data type. The response identifier, however, is always the same. Read commands always start with the same identifier and the servo drive responds differently depending on the data type returned. All numbers are in hexadecimal notation.



### EXAMPLE


<p>UINT8 / INT8</p> <p>Reading object <math>6061_h-00_h</math> Return data: <math>01_h</math></p> <p>Command: <math>40_h</math> <math>61_h</math> <math>60_h</math> <math>00_h</math></p> <p>Response: <math>4F_h</math> <math>61_h</math> <math>60_h</math> <math>00_h</math> <math>01_h</math></p>	<p>Writing object <math>1401_h-02_h</math> Data: <math>EF_h</math></p> <p>Command: <math>2F_h</math> <math>01_h</math> <math>14_h</math> <math>02_h</math> <math>EF_h</math></p> <p>Response: <math>60_h</math> <math>01_h</math> <math>14_h</math> <math>02_h</math></p>
<p>UINT16 / INT16</p> <p>Reading object <math>6041_h-00_h</math> Return data: <math>1234_h</math></p> <p>Command: <math>40_h</math> <math>41_h</math> <math>60_h</math> <math>00_h</math></p> <p>Response: <math>4B_h</math> <math>41_h</math> <math>60_h</math> <math>00_h</math> <math>34_h</math> <math>12_h</math></p>	<p>Writing object <math>6040_h-00_h</math> Data: <math>03E8_h</math></p> <p>Command: <math>2B_h</math> <math>40_h</math> <math>60_h</math> <math>00_h</math> <math>E8_h</math> <math>03_h</math></p> <p>Response: <math>60_h</math> <math>40_h</math> <math>60_h</math> <math>00_h</math></p>
<p>UINT32 / INT32</p> <p>Reading object <math>6093_h-01_h</math> Return data: <math>12345678_h</math></p> <p>Command: <math>40_h</math> <math>93_h</math> <math>60_h</math> <math>01_h</math></p> <p>Response: <math>43_h</math> <math>93_h</math> <math>60_h</math> <math>01_h</math> <math>78_h</math> <math>56_h</math> <math>34_h</math> <math>12_h</math></p>	<p>Writing object <math>6093_h-01_h</math> Data: <math>12345678_h</math></p> <p>Command: <math>23_h</math> <math>93_h</math> <math>60_h</math> <math>01_h</math> <math>78_h</math> <math>56_h</math> <math>34_h</math> <math>12_h</math></p> <p>Response: <math>60_h</math> <math>93_h</math> <math>60_h</math> <math>01_h</math></p>

#### **INFORMATION** Wait for the acknowledgement from the servo drive!

Only when the servo drive has acknowledged the request further requests may be sent.

## 6.2.2 SDO error response (abort codes)

In case of an error during reading or writing (e.g. because the written value is too large), the servo drive responds with an error code instead of acknowledging:



Error code F3 F2 F1 F0	Meaning
05 03 00 00 <sub>h</sub>	Toggle bit not alternated
05 04 00 01 <sub>h</sub>	Client/server command specifier not valid or unknown
06 01 00 00 <sub>h</sub>	Unsupported access to an object
06 01 00 01 <sub>h</sub>	Attempt to read a write only object
06 01 00 02 <sub>h</sub>	Attempt to write a read only object
06 02 00 00 <sub>h</sub>	Object does not exist in the object dictionary
06 04 00 41 <sub>h</sub>	Object cannot be mapped to the PDO (e.g. a ro-object in an RPDO)
06 04 00 42 <sub>h</sub>	The number and length of the objects to be mapped would exceed PDO length
06 04 00 43 <sub>h</sub>	General parameter incompatibility reason
06 04 00 47 <sub>h</sub>	General internal incompatibility in the device
06 06 00 00 <sub>h</sub>	Access failed due to an hardware error *1)
06 07 00 10 <sub>h</sub>	Data type does not match, length of service parameter does not match
06 07 00 12 <sub>h</sub>	Data type does not match, length of service parameter too high
06 07 00 13 <sub>h</sub>	Data type does not match, length of service parameter too low
06 09 00 11 <sub>h</sub>	Sub-index does not exist
06 09 00 30 <sub>h</sub>	Value range of parameter exceeded (only for write access)
06 09 00 31 <sub>h</sub>	Value of parameter written too high
06 09 00 32 <sub>h</sub>	Value of parameter written too low
06 09 00 36 <sub>h</sub>	Maximum value is less than minimum value
08 00 00 20 <sub>h</sub>	Data cannot be transferred or stored to the application *1)
08 00 00 21 <sub>h</sub>	Data cannot be transferred or stored to the application because of local control
08 00 00 22 <sub>h</sub>	Data cannot be transferred or stored to the application because of the present device state *3)
08 00 00 23 <sub>h</sub>	Object dictionary dynamic generation fails or no object dictionary is present *2)

\*1) This abort code is returned according to DS301 if `store_parameters` / `restore_parameters` are accessed incorrectly.

\*2) This abort code is returned e.g. if another bus system controls the servo drive or parameter access is not allowed.

\*3) "Device state" is to be understood generally here: It can be the wrong operating mode, as well as a non-existent technology module or similar.

## 6.2.3 Simulation of SDO accesses

The firmware of the servo drives offers the possibility to simulate SDO accesses via the parameterisation interface (e.g. the transfer window of the MPC ServoCommander). Thus, objects written via the CAN bus can be read and controlled via the parameterization interface. The syntax of the commands is:

Read commands		Write commands	
<b>UINT8 / INT8</b>			
Command:	? XXXX SU	= XXXX SU: WW	= XXXX SU: WW
Response:	= XXXX SU: WW	= XXXX SU: WW	= XXXX SU: WW
			
<b>UINT16 / INT16</b>			
Command:	? XXXX SU	= XXXX SU: WWWW	= XXXX SU: WWWW
Response:	= XXXX SU: WWWW	= XXXX SU: WWWW	= XXXX SU: WWWW
			
<b>UINT32 / INT32</b>			
Command:	? XXXX SU	= XXXX SU: WWWWWWWW	= XXXX SU: WWWWWWWW
Response:	= XXXX SU: WWWWWWWW	= XXXX SU: WWWWWWWW	= XXXX SU: WWWWWWWW
			
<b>Read error</b>		<b>Write error</b>	
Command:	? XXXX SU	= XXXX SU: WWWWWWWW <sup>1)</sup>	= XXXX SU: WWWWWWWW <sup>1)</sup>
Response:	! FFFFFFFF	! FFFFFFFF	! FFFFFFFF
			

<sup>1)</sup> In the case of an error, the response is structured the same for all 3 write commands (8, 16, 32 bits). The commands are entered as characters without any spaces.

### **INFORMATION** Test commands are not real-time capable

Access via the parameterisation interface is not suitable for real-time communication.

## 6.3 Access via PDO


Process data objects (PDOs) can be used to transfer data in an event-controlled manner. The PDO only transfers payload data. Which parameters are transferred is defined in advance between host and servo. In contrast to an SDO, there is no acknowledgement when a PDO is transmitted. The following types of PDOs are distinguished:

Transmit-PDO (TPDO)	Servo→ Host	Servo drive sends PDO on occurrence of a specific event
Receive-PDO (RPDO)	Host→ Servo	Servo drive evaluates PDO on occurrence of a specific event

The servo drive has four transmit and four receive PDOs.

Almost all objects of the object dictionary can be mapped into the PDOs, for example the actual speed value, the actual position value or similar.

In the example below, the position actual value would be transmitted in data bytes 0...3 of the PDO and the speed actual value in bytes 4...7.



In this way almost any data telegrams can be defined. The following chapters describe the settings required for this.

## 6.3.1 Description of objects

### › Identifier of the PDO

#### **COB\_ID\_used\_by\_PDO**

The identifier on which the respective PDO is to be sent or received must be entered in the object **COB\_ID\_used\_by\_PDO**. If bit 31 is set, the respective PDO is deactivated. This is the default setting for all PDOs. The COB-ID may only be changed if the PDO is deactivated, i.e. bit 31 is set. An identifier other than currently set in the servo drive may therefore only be written if bit 31 is set at the same time. The set bit 30 when reading the identifier indicates that the object cannot be queried by a remote frame. This bit is ignored on writing and is always set on reading.

### › Number of objects to be transferred

#### **number\_of\_mapped\_objects**

This object specifies how many objects are to be mapped into the corresponding PDO. The following restrictions must be observed:

- A maximum of 4 objects can be mapped per PDO
- A PDO may have a maximum of 64 bits (8 bytes)

### › Objects to be transferred

#### **first\_mapped\_object ... fourth\_mapped\_object**

For each object to be contained in the PDO, the servo drive must be given the corresponding index, subindex and length. The length specification must match the length specification in the Object Dictionary. Parts of an object cannot be mapped.

The mapping entry is composed as follows:

Index (16 Bit), Subindex (8 Bit), Length (8 Bit)

To simplify the mapping, the following procedure is prescribed:

1. The number of mapped objects must be set to 0.
2. The parameters **first\_mapped\_object...fourth\_mapped\_object** may be written (The total length of all objects is not relevant at this time).
3. The number of mapped objects is set to a value between 1...4. The length of all these objects must not exceed 64 bits now.

## › Transmission type

### transmission\_type and inhibit\_time

For each PDO it can be defined which event causes the transmission (Transmit-PDO) or the evaluation (Receive-PDO) of a message:

Value	Meaning	allowed with
01 <sub>h</sub> –F0 <sub>h</sub>	<b>SYNC message</b> The numerical value indicates how many SYNC messages must have arrived before the PDO is <ul style="list-style-type: none"> <li>• sent (T-PDO) or</li> <li>• evaluated (R-PDO)</li> </ul>	TPDOs RPDOs
FE <sub>h</sub>	<b>Cyclic</b> The Transmit PDO is updated and sent cyclically by the servo drive. The time period is defined by the object <b>inhibit_time</b> in 100µs steps. In contrast, receive PDOs are evaluated immediately after receipt.	TPDOs (RPDOs)
FF <sub>h</sub>	<b>Change</b> The Transmit PDO is sent when at least 1 bit has changed in the data of the PDO. This <b>transmission_type</b> is also permitted for Receive-PDOs. In addition, the <b>inhibit_time</b> can be used to define the minimum interval between the transmission of two PDOs in 100µs steps.	TPDOs

## › Masking

### transmit\_mask\_high and transmit\_mask\_low

If "Change" is selected as **transmission\_type**, the TPDO is always sent if at least 1 bit of the TPDO changes. But often it is needed that the TPDO is only sent if certain bits have changed. Therefore the TPDO can be provided with a mask: Only the bits of the TPDO that are set to "1" in the mask are used to evaluate whether the PDO has changed. Since this function is manufacturer specific, all bits of the masks are set by default.

## EXAMPLE

The following objects are to be transmitted together in one PDO:

Index_Subindex	Length	Object name
6041 <sub>h_00<sub>h</sub></sub>	10 <sub>h</sub>	statusword
6061 <sub>h_00<sub>h</sub></sub>	08 <sub>h</sub>	modes_of_operation_display
60FD <sub>h_00<sub>h</sub></sub>	20 <sub>h</sub>	digital_inputs

The first Transmit PDO (TPDO 1) is to be used, which is to be sent whenever one of the digital inputs changes, but at most every 10 ms. 187h is to be used as identifier for this PDO.

- Deactivate PDO** `cob_id_used_by_pdo = C0000187h`  
 If the PDO is active, it must first be deactivated, i.e. the identifier must be written with bit 31 set:
- Delete number of objects** `number_of_mapped_objects = 0`  
 To allow changing the object mapping, the number of mapped objects must be set to zero.
- Configuring objects** `first_mapped_object = 60410010h`  
`second_mapped_object = 60610008h`  
`third_mapped_object = 60FD0020h`  
 Index and subindex of the objects listed above must each be combined to a 32 bit value.
- Set number of objects** `number_of_mapped_objects = 3`  
 Three objects are to be transmitted in the PDO.
- Set transmission type** `transmission_type = FFh`  
 The PDO should be sent on change of the digital inputs. To ensure that only the change of the digital inputs leads to sending, the PDO is masked. The PDO should be sent at most every 10 ms (100x100µs). `transmit_mask_low = 000000FFh`  
`transmit_mask_high = FFFFFFF00h`  
`inhibit_time = 64h`
- Set identifier** `cob_id_used_by_pdo = 40000187h`  
 The PDO is to be sent with identifier 187h: Writing of the identifier with deleted bit 31:

### **INFORMATION** Changing the PDO settings

Note that the PDO configuration may generally only be changed if the network status (NMT) is not **Operational**. See also section 6.6 *Network Management (NMT service)* on page 177.

## 6.3.2 Objects for PDO configuration

The individual objects for configuring the PDOs are the same for all 4 TPDOs and all 4 RPDOs. Therefore only the parameter description of the first TPDO is explicitly listed below. It is to be used analogously also for the other PDOs, which are listed tabularly in the following:



Index	<b>1800<sub>h</sub></b>		
Name	<b>transmit_pdo_parameter_tpdo1</b>		
Type	RECORD		03 <sub>h</sub>
Sub-Index	<b>01<sub>h</sub></b>		
Name	<b>cob_id_used_by_pdo_tpdo1</b>		
Info	--	rw	<del>PDO</del> UINT32
Value	181 <sub>h</sub> ...1FF <sub>h</sub> , Bit 30 and 31 may be set		C0000181 <sub>h</sub>
Sub-Index	<b>02<sub>h</sub></b>		
Name	<b>transmission_type_tpdo1</b>		
Info	--	rw	<del>PDO</del> UINT8
Value	0...8C <sub>h</sub> , FE <sub>h</sub> , FF <sub>h</sub>		FF <sub>h</sub>
Sub-Index	<b>03<sub>h</sub></b>		
Name	<b>inhibit_time_tpdo1</b>		
Info	100μs (10 = 1ms)	rw	<del>PDO</del> UINT16
Value	--		0000 <sub>h</sub>

Index	<b>1A00<sub>h</sub></b>		
Name	<b>transmit_pdo_mapping_tpdo1</b>		
Type	RECORD		04 <sub>h</sub>
Sub-Index	<b>00<sub>h</sub></b>		
Name	<b>number_of_mapped_objects_tpdo1</b>		
Info	--	rw	<del>PDO</del> UINT8
Value	0...4		see Table
Sub-Index	<b>01<sub>h</sub></b>		
Name	<b>first_mapped_object_tpdo1</b>		
Info	--	rw	<del>PDO</del> UINT32
Value	--		see Table
Sub-Index	<b>02<sub>h</sub></b>		
Name	<b>second_mapped_object_tpdo1</b>		
Info	--	rw	<del>PDO</del> UINT32
Value	--		see Table
Sub-Index	<b>03<sub>h</sub></b>		
Name	<b>third_mapped_object_tpdo1</b>		
Info	--	rw	<del>PDO</del> UINT32
Value	--		see Table

Sub-Index	04 <sub>h</sub>			
Name	fourth_mapped_object_tpdo1			
Info	--	rw	<del>PDO</del>	UINT32
Value	--	see Table		

**INFORMATION** PDO must be deactivated before configuring.

Note that the object groups `transmit_pdo_parameter_xxx` and `transmit_pdo_mapping_xxx` can only be written if the PDO is deactivated (Bit 31 in `cob_id_used_by_pdo_xxx` set).

### 1. Transmit PDO

Index	Comment	Type	Acc.	Default Value
1800 <sub>h_00h</sub>	number of entries	UINT8	ro	03 <sub>h</sub>
1800 <sub>h_01h</sub>	COB-ID used by PDO	UINT32	rw	C0000181 <sub>h</sub>
1800 <sub>h_02h</sub>	transmission type	UINT8	rw	FF <sub>h</sub>
1800 <sub>h_03h</sub>	inhibit time (100 μs)	UINT16	rw	0000 <sub>h</sub>
1A00 <sub>h_00h</sub>	number of mapped objects	UINT8	rw	01 <sub>h</sub>
1A00 <sub>h_01h</sub>	first mapped object	UINT32	rw	60410010 <sub>h</sub>
1A00 <sub>h_02h</sub>	second mapped object	UINT32	rw	00000000 <sub>h</sub>
1A00 <sub>h_04h</sub>	fourth mapped object	UINT32	rw	00000000 <sub>h</sub>

#### tpdo\_1\_transmit\_mask

Index	Comment	Type	Acc.	Default Value
2014 <sub>h_00h</sub>	number of entries	UINT8	ro	02 <sub>h</sub>
2014 <sub>h_01h</sub>	tpdo_1_transmit_mask_low	UINT32	rw	FFFFFFFF <sub>h</sub>
2014 <sub>h_02h</sub>	tpdo_1_transmit_mask_high	UINT32	rw	FFFFFFFF <sub>h</sub>

### 2. Transmit PDO

Index	Comment	Type	Acc.	Default Value
1801 <sub>h_00h</sub>	number of entries	UINT8	ro	03 <sub>h</sub>
1801 <sub>h_01h</sub>	COB-ID used by PDO	UINT32	rw	C0000281 <sub>h</sub>
1801 <sub>h_02h</sub>	transmission type	UINT8	rw	FF <sub>h</sub>
1801 <sub>h_03h</sub>	inhibit time (100 μs)	UINT16	rw	0000 <sub>h</sub>
1A01 <sub>h_00h</sub>	number of mapped objects	UINT8	rw	02 <sub>h</sub>
1A01 <sub>h_01h</sub>	first mapped object	UINT32	rw	60410010 <sub>h</sub>
1A01 <sub>h_02h</sub>	second mapped object	UINT32	rw	60610008 <sub>h</sub>
1A01 <sub>h_03h</sub>	third mapped object	UINT32	rw	00000000 <sub>h</sub>
1A01 <sub>h_04h</sub>	fourth mapped object	UINT32	rw	00000000 <sub>h</sub>

**tpdo\_2\_transmit\_mask**

Index	Comment	Type	Acc.	Default Value
2015 <sub>h_00h</sub>	number of entries	UINT8	ro	02h
2015 <sub>h_01h</sub>	tpdo_2_transmit_mask_low	UINT32	rw	FFFFFFFFh
2015 <sub>h_02h</sub>	tpdo_2_transmit_mask_high	UINT32	rw	FFFFFFFFh

**3. Transmit PDO**

Index	Comment	Type	Acc.	Default Value
1802 <sub>h_00h</sub>	number of entries	UINT8	ro	03 <sub>h</sub>
1802 <sub>h_01h</sub>	COB-ID used by PDO	UINT32	rw	C0000381 <sub>h</sub>
1802 <sub>h_02h</sub>	transmission type	UINT8	rw	FF <sub>h</sub>
1802 <sub>h_03h</sub>	inhibit time (100 μs)	UINT16	rw	0000 <sub>h</sub>
1A02 <sub>h_00h</sub>	number of mapped objects	UINT8	rw	02 <sub>h</sub>
1A02 <sub>h_01h</sub>	first mapped object	UINT32	rw	60410010 <sub>h</sub>
1A02 <sub>h_02h</sub>	second mapped object	UINT32	rw	60640020 <sub>h</sub>
1A02 <sub>h_03h</sub>	third mapped object	UINT32	rw	00000000 <sub>h</sub>
1A02 <sub>h_04h</sub>	fourth mapped object	UINT32	rw	00000000 <sub>h</sub>

**tpdo\_3\_transmit\_mask**

Index	Comment	Type	Acc.	Default Value
2016 <sub>h_00h</sub>	number of entries	UINT8	ro	02h
2016 <sub>h_01h</sub>	tpdo_3_transmit_mask_low	UINT32	rw	FFFFFFFFh
2016 <sub>h_02h</sub>	tpdo_3_transmit_mask_high	UINT32	rw	FFFFFFFFh

**4. Transmit PDO**

Index	Comment	Type	Acc.	Default Value
1803 <sub>h_00h</sub>	number of entries	UINT8	ro	03 <sub>h</sub>
1803 <sub>h_01h</sub>	COB-ID used by PDO	UINT32	rw	C0000481 <sub>h</sub>
1803 <sub>h_02h</sub>	transmission type	UINT8	rw	FF <sub>h</sub>
1803 <sub>h_03h</sub>	inhibit time (100 μs)	UINT16	rw	0000 <sub>h</sub>
1A03 <sub>h_00h</sub>	number of mapped objects	UINT8	rw	02 <sub>h</sub>
1A03 <sub>h_01h</sub>	first mapped object	UINT32	rw	60410010 <sub>h</sub>
1A03 <sub>h_02h</sub>	second mapped object	UINT32	rw	606C0020 <sub>h</sub>
1A03 <sub>h_03h</sub>	third mapped object	UINT32	rw	00000000 <sub>h</sub>
1A03 <sub>h_04h</sub>	fourth mapped object	UINT32	rw	00000000 <sub>h</sub>

**tpdo\_4\_transmit\_mask**

Index	Comment	Type	Acc.	Default Value
2017 <sub>h_00h</sub>	number of entries	UINT8	ro	02h
2017 <sub>h_01h</sub>	tpdo_4_transmit_mask_low	UINT32	rw	FFFFFFFFh
2017 <sub>h_02h</sub>	tpdo_4_transmit_mask_high	UINT32	rw	FFFFFFFFh

### 1. Receive PDO

Index	Comment	Type	Acc.	Default Value
1400 <sub>h</sub> _00 <sub>h</sub>	number of entries	UINT8	ro	02 <sub>h</sub>
1400 <sub>h</sub> _01 <sub>h</sub>	COB-ID used by PDO	UINT32	rw	C0000201 <sub>h</sub>
1400 <sub>h</sub> _02 <sub>h</sub>	transmission type	UINT8	rw	FF <sub>h</sub>
1600 <sub>h</sub> _00 <sub>h</sub>	number of mapped objects	UINT8	rw	01 <sub>h</sub>
1600 <sub>h</sub> _01 <sub>h</sub>	first mapped object	UINT32	rw	60400010 <sub>h</sub>
1600 <sub>h</sub> _02 <sub>h</sub>	second mapped object	UINT32	rw	00000000 <sub>h</sub>
1600 <sub>h</sub> _03 <sub>h</sub>	third mapped object	UINT32	rw	00000000 <sub>h</sub>
1600 <sub>h</sub> _04 <sub>h</sub>	fourth mapped object	UINT32	rw	00000000 <sub>h</sub>

### 2. Receive PDO

Index	Comment	Type	Acc.	Default Value
1401 <sub>h</sub> _00 <sub>h</sub>	number of entries	UINT8	ro	02 <sub>h</sub>
1401 <sub>h</sub> _01 <sub>h</sub>	COB-ID used by PDO	UINT32	rw	C0000301 <sub>h</sub>
1401 <sub>h</sub> _02 <sub>h</sub>	transmission type	UINT8	rw	FF <sub>h</sub>
1601 <sub>h</sub> _00 <sub>h</sub>	number of mapped objects	UINT8	rw	02 <sub>h</sub>
1601 <sub>h</sub> _01 <sub>h</sub>	first mapped object	UINT32	rw	60400010 <sub>h</sub>
1601 <sub>h</sub> _02 <sub>h</sub>	second mapped object	UINT32	rw	60600008 <sub>h</sub>
1601 <sub>h</sub> _03 <sub>h</sub>	third mapped object	UINT32	rw	00000000 <sub>h</sub>
1601 <sub>h</sub> _04 <sub>h</sub>	fourth mapped object	UINT32	rw	00000000 <sub>h</sub>

### 3. Receive PDO

Index	Comment	Type	Acc.	Default Value
1402 <sub>h</sub> _00 <sub>h</sub>	number of entries	UINT8	ro	02 <sub>h</sub>
1402 <sub>h</sub> _01 <sub>h</sub>	COB-ID used by PDO	UINT32	rw	C0000401 <sub>h</sub>
1402 <sub>h</sub> _02 <sub>h</sub>	transmission type	UINT8	rw	FF <sub>h</sub>
1602 <sub>h</sub> _00 <sub>h</sub>	number of mapped objects	UINT8	rw	02 <sub>h</sub>
1602 <sub>h</sub> _01 <sub>h</sub>	first mapped object	UINT32	rw	60400010 <sub>h</sub>
1602 <sub>h</sub> _02 <sub>h</sub>	second mapped object	UINT32	rw	607A0020 <sub>h</sub>
1602 <sub>h</sub> _03 <sub>h</sub>	third mapped object	UINT32	rw	00000000 <sub>h</sub>
1602 <sub>h</sub> _04 <sub>h</sub>	fourth mapped object	UINT32	rw	00000000 <sub>h</sub>

#### 4. Receive PDO

Index	Comment	Type	Acc.	Default Value
1403 <sub>h</sub> _00 <sub>h</sub>	number of entries	UINT8	ro	02 <sub>h</sub>
1403 <sub>h</sub> _01 <sub>h</sub>	COB-ID used by PDO	UINT32	rw	C0000501 <sub>h</sub>
1403 <sub>h</sub> _02 <sub>h</sub>	transmission type	UINT8	rw	FF <sub>h</sub>
1603 <sub>h</sub> _00 <sub>h</sub>	number of mapped objects	UINT8	rw	02 <sub>h</sub>
1603 <sub>h</sub> _01 <sub>h</sub>	first mapped object	UINT32	rw	60400010 <sub>h</sub>
1603 <sub>h</sub> _02 <sub>h</sub>	second mapped object	UINT32	rw	60FF0020 <sub>h</sub>
1603 <sub>h</sub> _03 <sub>h</sub>	third mapped object	UINT32	rw	00000000 <sub>h</sub>
1603 <sub>h</sub> _04 <sub>h</sub>	fourth mapped object	UINT32	rw	00000000 <sub>h</sub>

### 6.3.3 Activation of PDOs

The following points must be fulfilled for the servo drive to **send** or **evaluate** PDOs:

- The object `number_of_mapped_objects` must be non-zero.
- Bit 31 in the `cob_id_used_for_pdos` object must be cleared.
- The communication status of the servo drive must be **Operational** (see section 6.6 *Network Management (NMT service)* on page 177)


The communication status of the servo drive must not be **Operational** so that PDOs can be **configured**.

## 6.4 EMERGENCY message

The servo drive monitors the function of its main assemblies. These include the power supply, the power stage, the angle encoder evaluation and the technology slots available on some servo drives. In addition, the motor (temperature, angle encoder) and the limit switches are continuously monitored. Incorrect parameterizations can also lead to error messages (division by zero, etc.).

### 6.4.1 Overview

The servo drive sends an EMERGENCY message when an error occurs or when an error is acknowledged. The identifier of this message is composed of the identifier 80h and the node number of the servo drive concerned.




After a reset, the servo drive is in the Error free state (which it may leave again immediately if an error has been present from the start). The following state transitions are possible:

Nr.	Cause	Description
0	Initialization completed	
1	Error occurs	There was no error and an error occurs. An EMERGENCY telegram with the error code of the occurred error is sent
2	Error acknowledgement	An error acknowledgement (see section 4.3 <i>controlword</i> on page 108) is attempted, but not all causes are resolved.
3	Error occurs	There is already an error and another error occurs. An EMERGENCY telegram with the error code of the new error is sent.
4	Error acknowledgement	An error acknowledgement is attempted and all causes are eliminated. An EMERGENCY telegram with error code 0000 is sent.

## 6.4.2 Structure of the EMERGENCY message

The EMERGENCY message consists of eight data bytes, where the first two bytes contain an `error_code`. The third byte is intended for another error code (object 1001<sub>h</sub>), but does not contain any relevant information. The remaining five bytes contain zeros.



An overview of all error codes that may occur can be found in section 7.3 *Error codes of the EMERGENCY message* on page 186

## 6.4.3 Description of objects

### Object 1003<sub>h</sub>: pre\_defined\_error\_field


The respective `error_code` of the error messages is additionally stored in a four-level error memory. This is structured like a shift register so that the last error that occurred is always stored in object 1003<sub>h</sub>\_01<sub>h</sub> (`standard_error_field_0`). By a read access to the object 1003<sub>h</sub>\_00<sub>h</sub> (`pre_defined_error_field`) it can be determined how many error messages are currently stored in the error memory. The error memory is cleared by writing the value 0 into the object 1003<sub>h</sub>\_00<sub>h</sub> (`pre_defined_error_field`). In order to be able to reactivate the output stage of the servo drive after an error, an error acknowledgement (`reset_fault`, see section 4.3 *controlword* on page 108) must also be performed.

Index	1003 <sub>h</sub>		
Name	pre_defined_error_field		
Type	ARRAY		04 <sub>h</sub>
Sub-Index	01 <sub>h</sub>		
Name	standard_error_field_0		
Info	--	ro	<del>DD</del> UINT32
Value	--		00000000 <sub>h</sub>
Sub-Index	02 <sub>h</sub>		
Name	standard_error_field_1		
Info	--	ro	<del>DD</del> UINT32
Value	--		00000000 <sub>h</sub>
Sub-Index	03 <sub>h</sub>		
Name	standard_error_field_2		
Info	--	ro	<del>DD</del> UINT32
Value	--		00000000 <sub>h</sub>

Sub-Index	04 <sub>h</sub>		
Name	standard_error_field_3		
Info	--	ro	<del>PDO</del> UINT32
Value	--	00000000 <sub>h</sub>	

## 6.5 SYNC message

Several devices of a plant can be synchronised with each other. For this purpose, one of the devices (usually the superordinate control) periodically sends out synchronization messages. All connected servo drives receive these messages and use them to handle the PDOs (siehe section 6.3 *Access via PDO* on page 165).



The identifier on which the servo drive receives the SYNC message is fixed at 80<sub>h</sub>. The identifier can be read out via the object `cob_id_sync`.


Index	1005 <sub>h</sub>		
Name	cob_id_sync		
Info	--	rw	<del>PDO</del> UINT32
Value	80 <sub>h</sub>	80 <sub>h</sub>	



## 6.6 Network Management (NMT service)

All CANopen devices can be controlled via the network management. The identifier with the highest priority (000h) is reserved for this purpose. Commands can be sent to one or all servo drives via NMT. Each command consists of two bytes, whereby the first byte contains the command code (**command specifier, CS**) and the second byte the node address (**node id, NI**) of the addressed servo drive. If zero is specified as node address, all nodes in the network will be addressed (broadcast). This makes it possible, for example, to trigger a reset in all devices at the same time. The servo drives do not acknowledge the NMT commands. It can only be concluded indirectly (e.g. by the Bootup message after a reset) that the reset was carried out successfully.

Structure of the NMT message:



States are defined in a state diagram for the NMT status of the CANopen node. State changes can be triggered via the **CS** byte in the NMT message. These are essentially oriented on the target state.




Figure 29: NMT-State machine

Transition	Name	CS	Target state	NMT state
1	Power on			
2	Bootup		Pre-Operational	7F <sub>h</sub>
3	Start Remote Node	01 <sub>h</sub>	Operational	05 <sub>h</sub>
4	Enter Pre-Operational	80 <sub>h</sub>	Pre-Operational	7F <sub>h</sub>
5	Stop Remote Node	02 <sub>h</sub>	Stopped	04 <sub>h</sub>
6	Start Remote Node	01 <sub>h</sub>	Operational	05 <sub>h</sub>
7	Enter Pre-Operational	80 <sub>h</sub>	Pre-Operational	7F <sub>h</sub>
8	Stop Remote Node	02 <sub>h</sub>	Stopped	04 <sub>h</sub>
9	Reset Communication	82 <sub>h</sub>	Pre-Operational	7F <sub>h</sub>
10	Reset Communication	82 <sub>h</sub>	Pre-Operational	7F <sub>h</sub>
11	Reset Communication	82 <sub>h</sub>	Pre-Operational	7F <sub>h</sub>
12	Reset Application	81 <sub>h</sub>	Pre-Operational	7F <sub>h</sub>
13	Reset Application	81 <sub>h</sub>	Pre-Operational	7F <sub>h</sub>
14	Reset Application	81 <sub>h</sub>	Pre-Operational	7F <sub>h</sub>

State transitions 2, 15 and 16 are executed automatically by the servo drive when initialization is complete.

Depending on the NMT status, certain communication objects cannot be used: For example, it is absolutely necessary to set the NMT status to **Operational** so that the servo drive sends PDOs.

State	Description	SDO	PDO	NMT
Reset Application	No communication. All CAN objects are reset to their reset values (application parameter set).	-	-	-
Reset Communication	No communication. The CAN controller is reinitialised.	-	-	-
Initialising	State after hardware reset. Resetting the CAN node, sending the bootup message.	-	-	-
Pre-Operational	Communication via SDOs possible. PDOs not active (No sending / evaluation).	X	-	X
Operational	Communication via SDOs possible. All PDOs active ( sending / evaluating).	X	X	X
Stopped	No communication except heartbeating.	-	-	X

**INFORMATION** Note the following instructions

- NMT telegrams must not be sent in a burst (one immediately after the other).
- There must be at least twice the position controller cycle time between two successive NMT telegrams on the bus (even for different nodes!) so that the servo drive can process the NMT telegrams correctly.
- The NMT command "Reset Application" is delayed, if necessary, until a running save operation is completed, as otherwise the save operation would remain incomplete (Defective parameter set). The delay can be in the range of a few seconds.
- The communication status must be set to **Operational** for the servocontroller to send and receive PDOs.


## 6.7 Bootup

### 6.7.1 Overview

After switching on the power supply or after a reset, the servo drive reports via a bootup message that the initialization phase has been completed. The servo drive then has the NMT status **Pre-Operational**.

### 6.7.2 Structure of the Bootup message

The bootup message is structured almost identically to the following heartbeat message. Only a zero is sent instead of the NMT status.




## 6.8 Heartbeat (Error Control Protocol)

### 6.8.1 Overview

To monitor the communication between slave (drive) and master, the so-called heartbeat protocol can be activated: The drive sends cyclic messages to the master. The master can check the cyclic occurrence of these messages and initiate appropriate measures if they fail to appear. Since both heartbeat and nodeguarding telegrams (see section 6.9 *Nodeguarding (Error Control Protocol)* on page 182) are sent with the identifier  **$700_{\text{h}} + \text{node number}$** , both protocols cannot be active at the same time. If both protocols are activated at the same time, only the heartbeat protocol is active.

## 6.8.2 Structure of the Heartbeat message

The heartbeat telegram is sent with the identifier **700<sub>h</sub> + node number**. It contains only 1 byte of user data, the NMT status of the servo drive (see section 6.6 *Network Management (NMT service)* on page 177).



NMT-State	State name
04 <sub>h</sub>	Stopped
05 <sub>h</sub>	Operational
7F <sub>h</sub>	Pre-Operational

## 6.8.3 Description of objects

### Object 1017<sub>h</sub>: producer\_heartbeat\_time

To activate the heartbeat functionality, the time between two heartbeat telegrams can be defined via the object **producer\_heartbeat\_time**.

Index	1017 <sub>h</sub>		
Name	producer_heartbeat_time		
Info	ms	rw	<del>DD</del> UINT16
Value	0...65536	0	

The **producer\_heartbeat\_time** can be stored in the parameter set. If the servo drive starts with a **producer\_heartbeat\_time** not equal to zero, the bootup message is considered the first heartbeat. The servo drive can only be used as a heartbeat producer. Object 1016<sub>h</sub> (**consumer\_heartbeat\_time**) is therefore only implemented for compatibility reasons and always returns 0.


## 6.9 Nodeguarding (Error Control Protocol)

### 6.9.1 Overview


The nodeguarding protocol can also be used to monitor the communication between slave (drive) and master. In contrast to the heartbeat protocol, with nodeguarding the master and slave monitor each other: The master cyclically asks the drive for its NMT status. A certain bit is toggled in each response from the servo drive. If these answers are missing or if the servo drive always answers with the same toggle bit, the master can react accordingly. Similarly, the drive monitors the regular arrival of nodeguarding requests from the master: if the messages remain missing for a certain period of time, the servo drive triggers error 12-4. Since both heartbeat and nodeguarding telegrams (see section 6.9 *Nodeguarding (Error Control Protocol)* on page 182) are sent with the identifier **700<sub>h</sub> + node number**, both protocols cannot be active at the same time. If both protocols are activated at the same time, only the heartbeat protocol is active.

### 6.9.2 Structure of the Nodeguarding messages

The request of the master must be sent as remote frame with the identifier **700<sub>h</sub> + node number**. With a remote frame a special bit is additionally set in the telegram, the remote bit. Remote frames have in principle no data.



The servo drive response is structured in the same way as the heartbeat message. It contains only 1 byte of user data, the togglebit and the NMT status of the servo drive.



Bit	Value	Name	Description
7	80 <sub>h</sub>	toggle_bit	Changes with every telegram
0...6	7F <sub>h</sub>	nmt_state	section 6.6 <i>Network Management (NMT service)</i> on page 177

The monitoring time for requests from the master can be parameterised. The monitoring starts with the first received remote request of the master. From this point on, the remote requests must arrive before the set monitoring time has elapsed, otherwise error 12-4 is triggered. The togglebit is reset by the NMT command **Reset Communication**. It is therefore deleted in the first response of the servo drive.

## 6.9.3 Description of objects

### 6.9.3.1 Object 100C<sub>h</sub>: guard\_time

To activate the node guarding monitoring, the maximum time between two remote queries of the master is parameterised. This time is determined in the servo drive from the product of **guard\_time** (100C<sub>h</sub>) and **life\_time\_factor** (100D<sub>h</sub>). It is therefore recommended to describe the **life\_time\_factor** with 1 and then to specify the time directly via the **guard\_time** in milliseconds.

Index	100C <sub>h</sub>		
Name	guard_time		
Info	ms	rw	<del>PBO</del> UINT16
Value	0...65536	0	

### 6.9.3.2 Object 100D<sub>h</sub>: life\_time\_factor

The **life\_time\_factor** should be set to 1 to specify the **guard\_time** directly.

Index	100D <sub>h</sub>		
Name	life_time_factor		
Info	--	rw	<del>PBO</del> UINT8
Value	0...1	0	

## 6.10 Table of identifiers

The following table gives an overview of the identifiers used:

Object type	Identifier (hexadecimal)	Remark
SDO (Host to Servo)	600 <sub>h</sub> + Node number	
SDO (Servo to Host)	580 <sub>h</sub> + Node number	
TPDO1	181 <sub>h</sub> / 180 <sub>h</sub> + Node number	These are the default values.  The node number can be added automatically if the corresponding option is set (see section 2.1.5 <i>Activate CANopen</i> on page 16).
TPDO2	281 <sub>h</sub> / 280 <sub>h</sub> + Node number	
TPDO3	381 <sub>h</sub> / 380 <sub>h</sub> + Node number	
TPDO4	481 <sub>h</sub> / 480 <sub>h</sub> + Node number	
RPDO1	201 <sub>h</sub> / 200 <sub>h</sub> + Node number	
RPDO2	301 <sub>h</sub> / 300 <sub>h</sub> + Node number	
RPDO3	401 <sub>h</sub> / 400 <sub>h</sub> + Node number	
RPDO4	501 <sub>h</sub> / 500 <sub>h</sub> + Node number	
SYNC	080 <sub>h</sub>	
EMCY	080 <sub>h</sub> + Node number	
HEARTBEAT	700 <sub>h</sub> + Node number	
NODEGUARDING	700 <sub>h</sub> + Node number	
BOOTUP	700 <sub>h</sub> + Node number	
NMT	000 <sub>h</sub>	



# 7 Appendix

## 7.1 CANopen

CANopen is a standard developed by the association "CAN in Automation". A large number of device manufacturers are organised in this association. This standard has now replaced all manufacturer-specific CAN protocols.

The relevant elements of the object dictionary and the associated access methods are described in this CANopen manual.

CAN in Automation (CiA)  
Kontumazgarten 3  
DE-90429 Nürnberg  
Tel.: +49-911-928819-0  
Fax: +49-911-928819-79  
headquarters(at)can-cia.org  
www.can-cia.de

The CANopen implementation of the servo drive is based on the following standards:

- CiA Draft Standard 301, Version 4.02, 13. Februar 2002
- CiA Draft Standard Proposal 402, Version 2.0, 26. Juli 2002

## 7.2 Characteristics of the CAN interface

The CAN interface has the following characteristics:

- CAN specification V2.0 Part A (Part B passive, i.e. messages of this type are tolerated but not processed)
- Physical layer: ISO 11898

## 7.3 Error codes of the EMERGENCY message

CAN code	Error number	Description
2300 <sub>h</sub>	31-x	Group 31: I <sup>2</sup> t
2311 <sub>h</sub>	31-1	I <sup>2</sup> t servo drive
2312 <sub>h</sub>	31-0	I <sup>2</sup> t motor
2313 <sub>h</sub>	31-2	I <sup>2</sup> t PFC
2314 <sub>h</sub>	31-3	I <sup>2</sup> t braking resistor
2320 <sub>h</sub>	6-x	Group 6: Short circuit in the power output stage
3200 <sub>h</sub>	32-x	Group 32: PFC
3210 <sub>h</sub>	7-x	Group 7: Overvoltage
3220 <sub>h</sub>	2-x	Group 2: Undervoltage
3280 <sub>h</sub>	32-0	DC bus circuit charging time exceeded
3281 <sub>h</sub>	32-1	Undervoltage for active PFC
3282 <sub>h</sub>	32-5	Brake chopper overload. DC bus circuit could not be discharged.
3283 <sub>h</sub>	32-6	Discharging period DC bus circuit exceeded
3284 <sub>h</sub>	32-7	Supply voltage missing for enabling
3285 <sub>h</sub>	32-8	Supply voltage breakdown while servo drive enabled
3286 <sub>h</sub>	32-9	Phase failure
4200 <sub>h</sub>	4-x	Group 4: Overtemperature
4210 <sub>h</sub>	4-0	Overtemperature power output stage
4280 <sub>h</sub>	4-1	Overtemperature DC bus circuit
4310 <sub>h</sub>	3-x	Group 3: Overtemperature motor
5080 <sub>h</sub>	90-x	Group 90: HW initialisation
5110 <sub>h</sub>	5-x	Group 5: Internal voltage supply
5114 <sub>h</sub>	5-0	Failure of internal voltage 1
5115 <sub>h</sub>	5-1	Failure of internal voltage 2
5116 <sub>h</sub>	5-2	Driver supply failure
5200 <sub>h</sub>	21-x	Group 21: Current measurement
5220 <sub>h</sub>	16-4	Unexpected hardware error
5280 <sub>h</sub>	21-0	Error 1 current measurement U
5281 <sub>h</sub>	21-1	Error 1 current measurement V
5282 <sub>h</sub>	21-2	Error 2 current measurement U
5283 <sub>h</sub>	21-3	Error 2 current measurement V
5410 <sub>h</sub>	5-3	Undervoltage digital I/Os
5410 <sub>h</sub>	5-4	Overcurrent digital I/Os
5430 <sub>h</sub>	24-x	Group 24: Analogue input monitoring

CAN code	Error number	Description
5500 <sub>h</sub>	26-x	Group 26: Flash
5580 <sub>h</sub>	26-0	No user parameter set
5581 <sub>h</sub>	26-1	Checksum error
5582 <sub>h</sub>	26-2	Flash: write error
5583 <sub>h</sub>	26-3	Flash: erase error
5584 <sub>h</sub>	26-4	Flash: error in internal flash
5585 <sub>h</sub>	26-5	No calibration data
5586 <sub>h</sub>	26-6	No user position data sets
6000 <sub>h</sub>	25-x	Group 25: Invalid device type
6000 <sub>h</sub>	91-x	Group 91: SW initialisation
6080 <sub>h</sub>	25-0	Invalid device type
6081 <sub>h</sub>	25-1	Device type not supported
6082 <sub>h</sub>	25-2	Hardware revision not supported
6083 <sub>h</sub>	25-3	Device functionality restricted
6100 <sub>h</sub>	16-x	Group 16: Program execution
6180 <sub>h</sub>	1-x	Group 1: Stack overflow
6181 <sub>h</sub>	16-0	Incorrect program execution
6182 <sub>h</sub>	16-1	Illegal interrupt
6183 <sub>h</sub>	16-3	Unexpected state
6184 <sub>h</sub>	15-x	Group 15: Mathematics
6185 <sub>h</sub>	15-0	Division by zero
6186 <sub>h</sub>	15-1	Out of range error
6187 <sub>h</sub>	16-2	Initialisation error
6188 <sub>h</sub>	82-x	Group 82: Internal sequence control
6320 <sub>h</sub>	36-x	Group 36: Parameters
6380 <sub>h</sub>	30-x	Group 30: Internal calculations
7122 <sub>h</sub>	14-x	Group 14: Motor and resolver identification
7300 <sub>h</sub>	8-x	Group 8: Angle encoder
7380 <sub>h</sub>	8-0	Resolver/Hall angle encoder error
7382 <sub>h</sub>	8-2	Incremental encoder: Z0 track signals error
7383 <sub>h</sub>	8-3	Incremental encoder: Z1 track signals error
7384 <sub>h</sub>	8-4	Digital incremental encoder: track signals error
7385 <sub>h</sub>	8-5	Incremental encoder: hall signals error
7386 <sub>h</sub>	8-6	Angle encoder communication error
7387 <sub>h</sub>	8-7	Master frequency input: Incorrect signal amplitude incremental track
7388 <sub>h</sub>	8-8	Internal angle encoder error

CAN code	Error number	Description
7389 <sub>h</sub>	8-9	Encoder at [X2B/X6] not supported
73A0 <sub>h</sub>	9-x	Group 9: Encoder parameter set
73A1 <sub>h</sub>	9-0	Encoder parameter set: out-of-date format
73A2 <sub>h</sub>	9-1	Encoder parameter set cannot be decoded
73A3 <sub>h</sub>	9-2	Encoder parameter set: unknown version
73A4 <sub>h</sub>	9-3	Encoder parameter set: corrupted data structure
73A5 <sub>h</sub>	9-7	Encoder EEPROM is write protected
73A6 <sub>h</sub>	9-9	Too small memory size of encoder EEPROM
7580 <sub>h</sub>	60-x	Group 60: Ethernet
7581 <sub>h</sub>	61-x	Group 61: Ethernet
8000 <sub>h</sub>	45-x	Group 45: IGBT driver supply
8080 <sub>h</sub>	43-x	Group 43: HW limit switches
8081 <sub>h</sub>	43-0	Limit switch: negative setpoint inhibited
8082 <sub>h</sub>	43-1	Limit switch: positive setpoint inhibited
8083 <sub>h</sub>	43-2	Limit switch: positioning suppressed
8084 <sub>h</sub>	45-0	Driver supply cannot be switched off
8085 <sub>h</sub>	45-1	Driver supply cannot be switched on
8086 <sub>h</sub>	45-2	Driver supply has been activated
8090 <sub>h</sub>	51-x	Group 51: FSM 2.0
8091 <sub>h</sub>	51-0	No / unknown FSM module or driver supply faulty
8093 <sub>h</sub>	51-2	FSM: unequal module type
8094 <sub>h</sub>	51-3	FSM: unequal module version
8095 <sub>h</sub>	51-4	FSM: error in SSIO communication
8096 <sub>h</sub>	51-5	FSM: error in brake activation
8097 <sub>h</sub>	51-6	FSM: unequal serial number
8098 <sub>h</sub>	52-x	Group 52: FSM 2.0 STO
8099 <sub>h</sub>	52-1	FSM: discrepancy time expired
809A <sub>h</sub>	52-2	FSM: STO/STOB deactivated while power output stage enabled
809B <sub>h</sub>	52-3	FSM: Limitation error
80A0 <sub>h</sub>	53-x	Group 53: FSM: Violation of safety conditions
80A1 <sub>h</sub>	53-0	USF0: safety condition violated
80A2 <sub>h</sub>	53-1	USF1: safety condition violated
80A3 <sub>h</sub>	53-2	USF2: safety condition violated
80A4 <sub>h</sub>	53-3	USF3: safety condition violated
80A9 <sub>h</sub>	54-x	Group 54: FSM: Violation of safety conditions
80AA <sub>h</sub>	54-0	SBC: safety condition violated

CAN code	Error number	Description
80AC <sub>h</sub>	54-2	SS2: safety condition violated
80AD <sub>h</sub>	54-3	SOS: safety condition violated
80AE <sub>h</sub>	54-4	SS1: safety condition violated
80AF <sub>h</sub>	54-5	STO: safety condition violated
80B0 <sub>h</sub>	54-6	SBC: brake not released for > 10 days
80B1 <sub>h</sub>	54-7	SOS: SOS requested for > 10 days
80C0 <sub>h</sub>	55-x	Group 55: FSM: Actual value evaluation 1
80C1 <sub>h</sub>	55-0	FSM: no actual speed / position value available or standstill for > 10 days
80C2 <sub>h</sub>	55-1	FSM: SINCOS encoder [X2B] - signal error
80C3 <sub>h</sub>	55-2	FSM: SINCOS encoder [X2B] - standstill > 10 days
80C4 <sub>h</sub>	55-3	FSM: Resolver [X2A] - signal error
80C6 <sub>h</sub>	55-7	FSM: other encoder [X2B] - Faulty angle information
80C7 <sub>h</sub>	55-8	FSM: impermissible acceleration detected
80D0 <sub>h</sub>	56-x	Group 56: FSM: Actual value evaluation 2
80D1 <sub>h</sub>	56-8	FSM: speed / angle difference encoder 1 - 2
80D2 <sub>h</sub>	56-9	FSM: error cross comparison encoder evaluation
80E0 <sub>h</sub>	57-x	Group 57: FSM: Inputs/Outputs
80E1 <sub>h</sub>	57-0	FSM: I/O - Self test error (internal/external)
80E2 <sub>h</sub>	57-1	FSM: digital inputs - signal level error
80E3 <sub>h</sub>	57-2	FSM: digital inputs - test pulse error
80E7 <sub>h</sub>	57-6	FSM: overtemperature
80E8 <sub>h</sub>	58-x	Group 58: FSM: Communication / Parameterisation
80E9 <sub>h</sub>	58-0	FSM: plausibility check of parameters
80EA <sub>h</sub>	58-1	FSM: general error parameterisation
80ED <sub>h</sub>	58-4	FSM: buffer internal communication
80EE <sub>h</sub>	58-5	FSM: communication safety module - servo drive
80EF <sub>h</sub>	58-6	FSM: error in cross comparison for processors 1 - 2
80F0 <sub>h</sub>	59-x	Group 59: FSM: Internal Error
80F1 <sub>h</sub>	59-1	FSM: failsafe supply / safe pulse inhibitor
80F2 <sub>h</sub>	59-2	FSM: error external power supply
80F3 <sub>h</sub>	59-3	FSM: error internal power supply
80F4 <sub>h</sub>	59-4	FSM: error management: too many errors
80F5 <sub>h</sub>	59-5	FSM: error writing to permanent event memory
80F6 <sub>h</sub>	59-6	FSM: error on saving parameter set
80F7 <sub>h</sub>	59-7	FSM: flash checksum error
80F8 <sub>h</sub>	59-8	FSM: internal monitoring, processor 1 - 2

CAN code	Error number	Description
80F9 <sub>h</sub>	59-9	FSM: other unexpected error
8100 <sub>h</sub>	12-x	Group 12: CAN communication
8100 <sub>h</sub>	13-x	Group 13: Timeout CAN bus
8120 <sub>h</sub>	12-1	CAN: communication error, bus OFF
8130 <sub>h</sub>	12-4	CAN: Node Guarding
8180 <sub>h</sub>	12-0	CAN: duplicate node number
8181 <sub>h</sub>	12-2	CAN: communication error (sending)
8182 <sub>h</sub>	12-3	CAN: communication error (receiving)
8183 <sub>h</sub>	12-9	CAN: protocol error
8184 <sub>h</sub>	13-0	Timeout CAN bus
8200 <sub>h</sub>	50-x	Group 50: CAN communication
8210 <sub>h</sub>	12-5	CAN: RPDO too short
8480 <sub>h</sub>	35-x	Group 35: Linear motor
8600 <sub>h</sub>	42-x	Group 42: Positioning
8611 <sub>h</sub>	17-x	Group 17: Max. following error exceeded
8611 <sub>h</sub>	27-x	Group 27: Following error monitoring
8612 <sub>h</sub>	40-x	Group 40: SW limit switches
8680 <sub>h</sub>	42-0	Positioning: no follow-up position: stop
8681 <sub>h</sub>	42-1	Positioning: reversal of rotation not permissible: stop
8682 <sub>h</sub>	42-2	Positioning: reversal of rotation after stop not permissible
8700 <sub>h</sub>	34-x	Group 34: Fieldbus
8780 <sub>h</sub>	34-0	No synchronisation via fieldbus
8781 <sub>h</sub>	34-1	Fieldbus synchronisation error
8A00 <sub>h</sub>	11-x	Group 11: Homing run
8A00 <sub>h</sub>	33-x	Group 33: Following error encoder emulation
8A80 <sub>h</sub>	11-0	Error when homing run is started
8A81 <sub>h</sub>	11-1	Error during homing run
8A82 <sub>h</sub>	11-2	Homing: no valid index pulse
8A83 <sub>h</sub>	11-3	Homing: timeout
8A84 <sub>h</sub>	11-4	Homing: incorrect / invalid limit switch
8A85 <sub>h</sub>	11-5	Homing: I <sup>2</sup> t / following error
8A86 <sub>h</sub>	11-6	Homing: end of search distance reached
8A87 <sub>h</sub>	33-0	Following error encoder emulation
F000 <sub>h</sub>	80-x	Group 80: IRQ_0_3
F080 <sub>h</sub>	80-0	Time overflow current control IRQ
F081 <sub>h</sub>	80-1	Time overflow speed control IRQ

CAN code	Error number	Description
F082 <sub>h</sub>	80-2	Time overflow position control IRQ
F083 <sub>h</sub>	80-3	Time overflow interpolator IRQ
F084 <sub>h</sub>	81-4	Time overflow low-level IRQ
F085 <sub>h</sub>	81-5	Time overflow MDC IRQ
FF00 <sub>h</sub>	28-x	Group 28: Operating hours meter
FF01 <sub>h</sub>	28-0	Missing operating hours meter
FF02 <sub>h</sub>	28-1	Operating hours meter: write error
FF03 <sub>h</sub>	28-2	Operating hours meter corrected
FF04 <sub>h</sub>	28-3	Operating hours meter converted